SONY. DIGITAL AUDIO RECORDER PCM-7040

MAINTENANCE MANUAL

1st Edition

PCM-7040 Serial No. 10001 and Higher (J)

PCM-7040 Serial No. 20001 and Higher (UC)

PCM-7040 Serial No. 50001 and Higher (CE)

▲警告

このマニュアルは、サービス専用です。

お客様が、このマニュアルに記載された設置や保守、点検、修理など行うと感電や火災、人身事故につながることがあります。

危険をさけるため、サービストレーニングを受けた技術者のみご使用ください。

A WARNING

This manual is intended for qualified service personnel only.

To reduce the risk of electric shock, fire or injury, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so. Refer all servicing to qualified service personnel.

⚠ WARNUNG

Die Anleitung ist nur für qualifiziertes Fachpersonal bestimmt.

Alle Wartungsarbeiten dürfen nur von qualifiziertem Fachpersonal ausgeführt werden. Um die Gefahr eines elektrischen Schlages, Feuergefahr und Verletzungen zu vermeiden, sind bei Wartungsarbeiten strikt die Angaben in der Anleitung zu befolgen. Andere als die angegeben Wartungsarbeiten dürfen nur von Personen ausgeführt werden, die eine spezielle Befähigung dazu besitzen.

AVERTISSEMENT

Ce manual est destiné uniquement aux personnes compétentes en charge de l'entretien. Afin de réduire les risques de décharge électrique, d'incendie ou de blessure n'effectuer que les réparations indiquées dans le mode d'emploi à moins d'être qualifié pour en effectuer d'autres. Pour toute réparation faire appel à une personne compétente uniquement.

CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

安全のために

ソニー製品は安全に十分に配慮して設計されています。しかし、電気製品はサービス時にまちがった扱い方をすると、火災や感電などにより死亡や大けがなど人身事故につながることがあり、危険です。

事故を防ぐために、サービストレーニングを受けた技術者以外はサービスを行なわないでください。

警告表示の意味

このサービス用のマニュアルおよび製品では、次のような表示をしています。表示の内容をよく理解してから本文をお読みください。

△警告

この表示の注意事項を守らないと、火災や感電などにより死亡や大けがなど人身事故につながる ことがあります。

注意

この表示の注意事項を守らないと、感電やその他の事故によりけがをしたり周辺の物品に損害を与えたりすることがあります。

注意 を促す記号



注意



火災



感雷



破裂



行為を 指示 する記号



強制





下記の注意を守らないと、 火災や感電による死亡や大けがにつながることがあります。



指定された部品を使用する

回路図,分解図,電気部品表中 ⚠ 印の部品 (ヒューズ,電源ユニットなど) は安全性を維持するために重要な部品です。指定以外の部品に交換すると、火 災や感電の原因となります。

必ずマニュアルで指定している部品を使用してください。

下記の注意を守らないと, けがをしたり周辺の物品に損害を与えることがあります。





指定されたラックマウントレールを使用する

指定以外のラックマウントレールを使用すると、レールの強度不足により、機 器が落下してけがをすることがあります。

ラックマウントは2人以上で行う

本機をラックマウントするとき、および取り外すときは、必ず2人以上で行っ てください。1人で行うと、バランスを崩し機器が落下してけがの原因となる ことがあります。

電池についての安全上の注意

ここでは、バックアップ用リチウム電池についての注意事項を記載しています。

万一, 異常が起きたら

- 煙が出たら機器の電源スイッチを切り、電源プラグを抜く。
- 電池の液が目に入ったらすぐきれいな水で洗い、ただちに医師の診療を受ける。
- ・電池の液が皮膚や衣服に付いたら すぐにきれいな水で洗い流す。
- ・バッテリー収納部内で液が漏れたらよくふき取ってから、新しい電池を接続する。

△警告





下記の注意事項を守らないと、破裂・発火・発熱により、死亡や大けがなどの人身事故になることがあります。

- ・充電、ショート、分解、変形、加熱、火に入れるなどしない。
- ・同じ型名または機器製造者指定の同等品と交換する。
- ・廃棄のときは+と-の端子が他の金属や電池に触れないように、テープ などを貼り絶縁する。

注意



下記の注意事項を守らないと、破裂・液漏れにより、けがをしたり周辺の物品に損害を与えたりすることがあります。

・+と-の向きを正しく接続する。

目次

このマニュアルについて

本書	の目的5	(J)
構成	5	(J)
関連	マニュアル	(T
1.	設置	
1-1.	使用環境1-1	Œ.
1-2.	電源1-1	Œ.
	1-2-1. 電源仕様1-1	
	1-2-2. 電源コード1-1	Œ,
1-3.	設置スペース1-2	O,
1-4.	ラックマウント13	Œ,
1-5.	接続コネクタ/ケーブル14	Œ,
1-6.	スイッチの設定と LED の機能15	Œ
1-7.	ISR1-8	
	1-7-1. 接続1-9	O)
	1-7-2. 対応コマンド1-9	()
2.	サービスインフォメーション	
2-1.	主要部品配置図2-1	(J)
2-2.	外装の取外し2-2	(1)
2-3.	主要部品の交換2-2	
	2-3-1. リチウム電池の交換2-2	
	2-3-2. ヒューズの交換	
	2-3-3. SSP-11 基板の交換2-3	
2-4.	緊急時のカセット取り出し方法24	
2-5.	エラー/コーションコード25	(J)
2-6.	サービスメニュー27	(J)
	2-6-1. プリントメニュー2-9	(1)
	2-6-2. ディスプレイメニュー2-10	
	2-6-3。 テストメニュー2-16	
	2-6-4. プリセットメニュー	(J)
^	→## と と *** (月 →)	
3.	定期点検および保守	
• •		
	クリーニング	
	定期交換のスケジュール3-2	(J)
2.3	セット修理後の保守 29	m

4. メカデッキの交換および調整

4-1.	メカデッ	キ ASSY およびメカデッキ部品(定期交換部品)の交換方法41	ഗ
4-2.	調整およ	び確認45	(1)
	4-2-1.		
		サービスメニューでの調整および確認49	
	4-2-3.	SV-147A 基板交換時の確認4-31	(J)
5	電気調整	数	
٠.	-ENIVE	E	
5-1.	準備	5-1	(J)
	5-1-1.	使用機器5-1	O
	5-1-2.	スイッチ, コントロール初期設定5-2	(1)
5-2.		系調整5-2	
		マスタークロック調整5-2	-
	5-2-2.	タイマクロック調整5-3	(J)
	5-2-3.	RF PLL 調整5-4	(J)
5-3.	A/D, D/.	A 系調整5-8	(1)
	5-3-1.	A/D 変換レベル調整5-9	(1)
	5-3-2.	D/A 変換レベル調整5-9	(J)
	5-3-3.	C.M.RR調整5-10	(1)
	5-3-4.	出力パランス調整5-11	(J)
5-4.	タイムコ	ード出力レベル調整5-12	(1)
_			
6.	Spare F	rans	
6-1.	Notes on	Repair Parts	6-1
6-2.	Exploded	d Views	6-2
6-3.	Electrica	l Parts Lists	j-10
6-4.	Accessor	ies Supplied6	5-27

2(J)

7. Semiconductor Pin Assignments

8.	Block	Diagrams	8
•			

	OVERALL	8-1
	MECHA DECK BLOCK	8-2
	SSP-11 BOARD	8-4
	KY-192 BOARD	8-17
9.	Board Layouts	
	SSP-11	9-1
	KY-192	9-6
	CP-268	9-8
	VR-109	
	SW-420	9-9
	LED-104	9-9
	HP-48	9-9
	PS-451	9-9
	PS-452	9-9
	CN-1487	9.9
	CP-269	9-10
	RF-53	
	Capstan Flexible	9-10
	Reel FG. Dew Flexible	
	Reel FG	
	Recogni End Flexible	
	SV-147A	
	Goma	
	Tenregi Motor Encoder Flexible	
	Tenregi	

10. Schematic Diagrams

55P-11	
AD Block	10-2
DA Block	10-3
PS Block	10-4
SY Block	10-6
RM Block	10-8
SP Block	10-10
MEM Block	10-12
TC Block	10-14
DIO Block	10-16
KY-192	10-18
CP-268A (UC,CE)	10-20
CP-268B (J)	10-21
RF-53	10-23
SV-147A	10-24
FRAME WIRING (1/2)	10-26
CN-1487	10-26
PS-451	10-26
PS-452	10-26
FRAME WIRING (2/2)	10-27
CP-269	10-27
HP-48	10-27
LED-104	10-27
SW-420	
VR-109	10-27

このマニュアルについて

本書の目的

本書は、デジタルオーディオレコーダ PCM-7040 のメンテナンスマニュアルです。 本書は、システム/サービスエンジニアの方々にご使用いただくことを想定し、本機 の部品レベルまでのサービスを前提とした情報 (回路図、マウント図、詳細なパーツ リストなど)を記載しています。

構成

本書の構成を把握していただくために、全章の概略を以下に説明します。

第1章 設置

電源,使用環境,ラックマウント方法,PCM-7040の設置に関する情報を記載しています。

第2章 サービスインフォメーション

リチウム電池の交換、ヒューズの交換、外装の取り外し、エラーメッセージ, サービスメニュー等について記載しています。

第3章 定期点検および保守

クリーニング、定期点検のスケジュールについて記載しています。

第4章 メカデッキの交換および調整

定期交換部品の交換方法、交換後の確認、調整について記載しています。

第5章 電気調整

基板、および基板内の電気部品を交換した際に必要な調整について記載しています。

第6章 Spare Parts

本機で使用しているメカ部品、電気部品、標準付属品について記載しています。

第7章 Semiconductor Pin Assignments

本機で使用している半導体の外形、ピン名称、機能説明等を記載しています。

第8章 Block Diagrams

本機のブロック図、回路概説を記載しています。

第9章 Board Layouts

本機で使用している基板のパターンとシンボル図を記載しています。

第10章 Schematic Diagrams

本機で使用している基板の回路図を記載しています。

関連マニュアル

- オペレーションマニュアル (PCM-7040 に付属しています)本機を実際に運用および操作するのに必要なマニュアルです。
- ・RS-232C プロトコルマニュアル (PCM-7040 に付属していません) RS-232Cインターフェースを介して、コンピュータ等で本機をコントロールする際に必要なコマンドについて説明しています。必要な方は、担当のサービス窓口にお問い合わせ下さい。
- 9-PIN プロトコルマニュアル (PCM-7040 に付属していません) RS-422Aインターフェースを介して、外部機器で本機をコントロールする際に必要なコマンドについて説明しています。必要な方は、担当のサービス窓口にお問い合わせ下さい。

6(J)

Table of Contents

Manual Structure

	pose of this manual	
Con	ntents	5 (E)
Rela	ated manuals	6 (E)
1.	Installation	
1-1.	Installation Environment	1-1 (E)
1-2.	Power Requirements	1-1 (E)
	1-2-1. AC Power Supply	
	1-2-2. Power cord	1-1 (E)
1-3.	. Dimensions	1-2 (E)
1-4.		
1-5.		
1-6.		
1-7.		
	1-7-1. Connection	
	1-7-2. Commands	
2.	Service Overview	
2-1.	. Boards Location	2.1 (E)
2-1. 2-2.		
2-2. 2-3.		
2-3 .	. Main Part Replacement	
	2-3-2. Fuse Replacement	
	2-3-3. SSP-11 Board Replacement	
2-4.		
2- -, . 2-5.		
2-6.	3	
	2-6-1. Print Menu	, ,
	2-6-2. Display Menu	
	2-6-4. Preset menu	
	2-0-4. Treset menu	2-21 (D)
3.	Periodical Inspection and Maintenance	
3-1.	. Cleaning	3-1 (E)
3-2.		
3_3	Maintenance after renaires	3_2 (F)

4. Replacement and Adjustment of Mechanism Deck

4-1.	Replacen	nent of Mechanical Deck Assy and Parts	4-1 (E)
4-2.		ents and Checks	
	4-2-1.	Preparations	
	4-2-2.	Adjustments and checks in the service menu	
	4-2-3.	Checking after SV-147A board replacement	
5.	Electric	al Alignment	
5-1.	Preparati	on	5-1 (E)
	5-1-1.	Equipment	
	5-1-2.	Switch and Control Initial Setting	
5-2.	Signal Pr	ocessing Block Adjustment	
	5-2-1.	Master Clock Adjustment	
	5-2-2.	Timer Clock Adjustment	
	5-2-3.	RF PLL Adjustment	
5-3.	AD/DA	Block Adjustment	
	5-3-1.	AD Conversion Level Adjustment	
	5-3-2.	DA Conversion Level Adjustment	
	5-3-3.	C. M. R. R. Adjustment	5-10 (E)
	5-3-4.	Output Balance Adjustment	5-11 (E)
5-4.	Time Co	de Output Level Adjustment	
6.	Spare P	arts	
6-1.	Notes on	Repair Parts	6-1
6-2.	Exploded	l Views	6-2
6-3.		Parts Lists	
6-4.		ies Supplied	

7. Semiconductor Pin Assignments

8.	Block	Diag	rams
----	--------------	------	------

	OVERALL	8-1
	MECHA DECK BLOCK	8-2
	SSP-11 BOARD	
	KY-192 BOARD	
9.	Board Layouts	
	SSP-11	9-1
	KY-192	9-0
	CP-268	9-6
	VR-109	9-9
	SW-420	9-9
	LED-104	9-9
	HP-48	9-9
	PS-451	9-9
	PS-452	9-9
	CN-1487	9-9
	CP-269	9-10
	RF-53	9-10
	Capstan Flexible	9-10
	Reel FG. Dew Flexible	9-10
	Reel FG	9-10
	Recogni End Flexible	9-10
	SV-147A	
	Goma	
	Tenregi Motor Encoder Flexible	
	Tenregi	

10. Schematic Diagrams

SSP-11	
AD Block	10-2
DA Block	10-3
PS Block	10-4
SY Block	10-6
RM Block	10-8
SP Block	10-10
MEM Block	
TC Block	
DIO Block	10-16
KY-192	10-18
CP-268A(UC,CE)	10-20
CP-268B(J)	10-21
RF-53	10-23
SV-147A	10-24
FRAME WIRING (1/2)	10-26
CN-1487	10-26
PS-451	10-26
PS-452	10-26
FRAME WIRING (2/2)	10-27
CP-269	10-27
HP-48	10-27
LED-104	
SW-420	
VP_100	10.27

Manual Structure

Purpose of this manual

This manual is the Maintenance Manual of the Digital Audio Recorder PCM-7040. This manual is intended for use by trained system and service engineers, and describes the detailed service information with the intention of servicing based on the component parts (schematic diagrams, board layouts, detailed spare parts list and so on).

Contents

This manual is organized by following sections.

Section 1 Installation

This section describes the information for the installation of the PCM-7040 (power supply, operating conditions and rack mounting).

Section 2 Service Overview

This section describes the replacement of lithium battery and fuse, cabinet removal, error messages and service menu.

Section 3 Periodical Inspection and Maintenance

This section describes the cleaning and schedule of periodical inspection.

Section 4 Mechanical Replacement and Alignment

This section describes the procedures for the parts at periodic replacement, and checks and adjustments required after replacement.

Section 5 Electrical Alignment

This section describes checks and adjustments required when the boards or its components have been replaced.

Section 6 Spare Parts

This section describes spare parts (mechanical parts list, electrical parts list and supplied accessories list).

Section 7 Semiconductor Pin Assignments

This section describes the appearance, pin assignments, and function descriptions of semiconductors.

Section 8 Block Diagrams

This section describes the block diagrams of circuit board and circuit description.

Section 9 Board Layouts

This section describes board layouts (the printed circuit patterns and printed symbols).

Section 10 Schematic Diagrams

This section describes the schematic diagrams of circuit board.

Related manuals

- Operation Manual (Supplied with the PCM-7040)
 This manual is necessary for application and operation of the PCM-7040.
- RS-232C Protocol Manual (Not supplied with the PCM-7040)
 This manual describes command which controls the PCM-7040 via RS-232C interface by computer, etc. If this manual is required, please contact to Sony's service organization.
- 9-PIN Protocol Manual (Not supplied with the PCM-7040)
 This manual describes command which controls the PCM-7040 via RS-422A interface by external equipment. If this manual is required, please contact to Sony's service organization.

第1章

1-1. 使用環境

動作温度 : 10℃~35℃ (性能保証)

5℃~40℃ (機能保証)

保存温度 :-20℃~55℃ (ただし, 結露なきこと)

質量 : 約 10 kg 設置禁止場所:・太陽光線または強力ライトが直接当たる場所

・ほこりや振動の多い場所

• 強電界や強磁界の場所

• 熱源のそば

・電気的なノイズの多い場所

・静電ノイズの発生しやすい場所

1-2. 電源

1-2-1. 電源仕様

· 電源電圧:

工場出荷時、電源電圧は、各仕向地に適応した電圧値に設定されている。

設定は、電源トランス一次側の PS-451 基板の CN1, CN2, または CN3 コネクタに、ショートコネクタを下記のように接続することで行っている。

また, この設定に合わせて, 電源ヒューズ (F1, SSP-11 基板) も設定されている。

電源電圧	ショートコネクタの PS-451 基板の接続先コネクタ	ヒューズの定格 (F1,SSP-11 基板)	任向	
100 V AC	CN1	2 A, 125 V	J	
120 V AC	CN2	2 A, 125 V	UC	
230 (220-240) VAC	CN3	1 A, 250 V	CE	

・電源周波数: 50/60 Hz (J, CE向け)


50 Hz (UC向け)

- 消費電力 : 37W at AC 100 V (J向け)

38W at AC 120 V (UC 向け) 0.3A at AC 230 V (CE 向け)


1-2-2. 電源コード

J向け




PCM-7040


・ UC 向け



· CE 向け



1-3. 設置スペース



1-2(J)

1-4. ラックマウント

PCM-7040は、19インチ標準ラックに組み込んで使用することができます。

ラックマウントは、ラックマウントアダプタ RMM-31 (別売品) およびラックマウントレール RMM-30 (別売品) を使用して行います。


用意する部品

- ・ ラックマウントアダプタ RMM-31 (別売品) :1 (取っ手; 2, ネジ B4×14; 4, 飾りワッシャ; 4, ネジ RK5 ×16; 4)
- ・ラックマウントレール RMM-30 (別売品) :1 (プラケット付レール; 2, ネジ B5 × 8; 8, 板ナット M4; 2, ネジ PWH4 × 10; 2)
- ・インナメンパー取付け用ネジ (B4×10) * :4
- *PCM-7040には、4本付属されています。

取付け時の注意


ラックへの取り付け作業は、必ず2人以上で行って下さい。

- (1) 19インチ標準ラックにPCM-7040および関連機器をラックマウントしたときは、ラック内の温度上昇を防止するため、換気用ファンを取り付けることをお薦めします。ラック内の全てのセットが10 ℃~35 ℃の範囲で使用できるように注意してください。
- (2) ラックマウントするときは,必ず推奨のレールをご使用 ください。ラックマウントアダプタだけでは,セットを ラックに固定できないため、危険です。
- (3) ラックは、しっかりした床にボルトで固定することを、 お薦めします。セットをラックから引き出す際に、倒れ かかってくるのを防止します。



取り付け方法

(1) ネジ4本を外し、セット底面の脚 (4個) を取り外す。



(2) ラックマウントレールおよびラックマウントアダプタを、取り付ける。


詳細については、RMM-30およびRMM-31に付属されている INSTALLATION MANUAL をご覧下さい。

注意

インナメンバーは、用意したネジ (B4×10) 4本でPCM-7040 に取り付けてください。

参考

PCM-7040をラックマウントしたときの最大移動距離は、下記の通りです。




1-5. 接続コネクタ/ケーブル

コネクタパネル部の各種コネクタにケーブルを接続する際には,その先端に,下記のコネクタ/ケーブル,または相当品を使用する。

PCM-7	040 側コネクタ	適合コネクタ/ケーブル		
使用先	名称	名称	ソニー部品番号	
ANALOG INPUT CH1 / CH2	XLR 3P, FEMALE (UC,CE)	XLR 3P,MALE (UC,CE)	1-508-084-11 (CANNON XLR-3-12C または相当品)	
	XLR 3P, MALE (J)	XLR 3P, FEMALE (J)	1-508-083-11 (CANNON XLR-3-11C または相当品)	
ANALOG OUTPUT CH1 / CH2	XLR 3P, MALE (UC, CE)	XLR 3P,FEMALE (UC,CE)	1-508-083-11 (CANNON XLR-3-11C または相当品)	
	XLR 3P, FEMALE (I)	XLR 3P,MALE (J)	1-508-084-11 (CANNON XLR-3-12C または相当品)	
DIGITAL INPUT	XLR 3P, FEMALE	ECD-3C/10C/30C (3m, 10m, 30m)	別売アクセサリ	
DIGITAL OUTPUT	XLR 3P, MALE	ECD-3C/10C/30C (3m, 10m, 30m)	別売アクセサリ	
TIME CODE INPUT	XLR 3P, FEMALE (UC,CE)	XLR 3P, MALE (UC,CE)	1-508-084-11 (CANNON XLR-3-12C または相当品)	
	XLR 3P, MALE (J)	XLR 3P, FEMALE (J)	1-508-083-11 (CANNON XLR-3-11C または相当品)	
TIME CODE OUTPUT	XLR 3P, MALE (UC,CE)	XLR 3P, FEMALE (UC,CE)	1-508-083-11 (CANNON XLR-3-11C または相当品)	
	XLR 3P, FEMALE (J)	XLR 3P, MALE (J)	1-508-084-11 (CANNON XLR-3-12C または相当品)	
REF VIDEO INPUT	BNC	BNC, PLUG	**	
WORD SYNC INPUT/OUTPUT	BNC	BNC, PLUG	_	
MONITOR CH-1/CH-2	PIN, JACK	PIN, PLUG	_	
REMOTE (37PIN)	D-SUB 37P, FEMALE	D-SUB 37P, MALE	1-566-357-11 (ユネクタ) 1-563-378-11 (シェル)	
REMOTE (9PIN)	D-SUB 9P, FEMALE	• D-SUB 9P, MALE	1-560-651-00 (コネクタ) 1-561-749-00 (シェル)	
		• RCC-5G / 10G / 15G (5m, 10m, 15m)	別売アクセサリ	
RS-232C (25PIN)	D-SUB 25P, FEMALE	· D-SUB 25P, MALE	1-560-904-11 (コネクタ) 1-563-377-11 (シェル)	
		・RS-232C クロスケーブル		
REMOTE (8PIN)	DIN 8P, SOCKET (FEMALE)	DIN 8P, PLUG (MALE)	-	

1-6. スイッチの設定と LED の機能

SSP-11 基板 (A面)



LED インジケータ

D301 (C2) (赤): CPU 初期化インジケータ

リセットがかかると点灯し、初期化処理

を終了すると消灯する。

D302 (B2) (黄): EEPROM アクセスインジケータ

EEPROM (IC308) のデータリード/ライ

ト中に点灯する。

D303 (A1) (赤): バックアップメモリーデータ初期化イン D307 (A1) (黄): RMW モードインジケータ

ジケータ

バックアップメモリー (IC309,310) を初

期化(クリア)した時に点灯する。

D304 (A1) (緑):正常動作インジケータ

メイン CPU (IC304) が正常動作している

時に点滅する。

D305 (A1) (黄): ミュートインジケータ

再生オーディオ信号にミュートをかけて いる時(STOPモードなど)に点灯する。

D306 (A1) (黄): DSP出力インジケータ

モニター音が DSP (IC604) 出力 (下記の いずれかの場合)の時に点灯する。

- ・ フロントパネルの SYNC REC ランプが 点灯(シンク記録モード)
- ・メモリージョグ、メモリーリハーサル、 メモリースタートプレイ

先行ヘッド:再生、後行ヘッド:記録(下 記のいずれかの場合)の時に点灯する。

- ・ フロントパネルの SYNC REC ランプが 点灯(シンク記録モード)
- ・ ワイドトラックピッチのテープを再生中
- ・ エラーレート選択 (サービスメニュー "rAtE SEL")が先行ヘッド再生モード

D308 (A1) (緑): 9ピン CPU I/F 正常インジケータ 9ピン CPU (IC318) とメイン CPU (IC304) との通信が確保された時に点灯

する。

D309 (A1) (赤):9ピンデータ受信 (9ピン CPU → メイン CPU) インジケータ メイン CPUが9ピン CPUからデータを受

信中に点灯する。

D310 (A1) (緑):9ピンデータ送信 (9ピン CPU ← メイン CPU) インジケータ メイン CPUが9ピン CPUにデータを送信 中に点灯する。

D316 (A1) (赤):9ピンデータ受信 (SCU→9ピンCPU) イ ンジケータ 9ピン CPU が SCU (Serial Control Unit, IC306) からデータを受信中に点灯する。

D317 (A1) (緑): 9ピンデータ送信 (SCU ~9ピン CPU) イ ンジケータ 9ピンCPU がSCUにデータを送信中に点 灯する。

D601 (A3) (赤): レコーダー (再生音) サウンドメモリー ライトインジケータ レコーダーサウンドメモリーにデータを 書き込み中に点灯する。

D602 (A3) (黄): レコーダー (再生音) サウンドメモリー リードインジケータ レコーダーサウンドメモリーからデータ を読み出し中に点灯する。

D603 (A3) (緑): レコーダー (再生音) サウンドメモリー イン点トリガーインジケータ イン点でレコーダーサウンドメモリー データにクロスフェードがかかった時に 点灯する。

D604 (A3) (緑): レコーダー (再生音) サウンドメモリー アウト点トリガーインジケータ アウト点でレコーダーサウンドメモリー データにクロスフェードがかかった時に 点灯する。

D605 (A3) (赤): プレーヤー (入力音) サウンドメモリー ライトインジケータ プレーヤーサウンドメモリーにデータを 書き込み中に点灯する。

D606 (A3) (黄): プレーヤー (入力音) サウンドメモリー リードインジケータ プレーヤーサウンドメモリーからデータ を読み出し中に点灯する。

D607 (A3) (緑): プレーヤー (入力音) サウンドメモリー イン点トリガーインジケータ イン点でプレーヤーサウンドメモリー データにクロスフェードがかかった時に 点灯する。

D608 (A3) (緑): プレーヤー (入力音) サウンドメモリー アウト点トリガーインジケータ アウト点でプレーヤーサウンドメモリー データにクロスフェードがかかった時に 点灯する。

スイッチ

S301 (C2): RESET スイッチ

CPU (IC304) のリセット用スイッチ

S302 (A2): モード設定

S302-1.2: 仕向け設定

S302-1	S302-2	仕向け設定	
OFF	OFF	UC 向け	
ON	OFF	J向け	
OFF	ON	CE向け	
ON	ON	UC 向け	

S302-3.4:デバイスタイプ設定

S302-3	S302-4	9 ピンデバイスタイプ設定
OFF	OFF	PCM-7030(工場出荷時)
ON	OFF	PCM-7050
OFF	ON	PCM-7040
ON	ON	PCM-7040

S302-5~7:予約済み

S302-8 : バックアップメモリー初期化設定

S302-8	バックアップメモリー初期化設定
OFF	電源投入時に初期化しない(工場出荷時)
ON	電源投入時に初期化する。この時ディスプレイに "ALL cLEAr-" が表示される。 次の場合に S302-1,2 で仕向けを設定してから初期化をする。 1. SSP-11 基板を交換したとき 2. SSP-11 基板 IC309 または IC310 (RAM) を交換したとき

S302-5~7のいずれかが ON の場合はフロントパネルの ALARM ランプが点滅し、cAution 1-50 が発生する。

工場出荷時の設定:1,2は仕向けによる。 3~8はOFF

S51 (E5)

: AD/DA信号経路スイッチ AD/DAデジタルオーディオ信号経路切

り替え用スイッチ

S51	信号経路設定	
NORMAL	通常経路(工場出荷時)	
TEST	AD 出力が DA 入力となる	

S101 (F6): 入力基準信号レベル (CH-1) スイッチ

S201 (E6): 入力基準信号レベル (CH-2) スイッチ

S102 (F4): 出力基準信号レベル (CH-1) スイッチ

S202 (E4): 出力基準信号レベル (CH-2) スイッチ

基準信号レベル(+4dBs/-20dBs)切り替え用

スイッチ

S101,S102 基準信号レベル設定 S201,S202	
+4dBs	+4dBs の入出力信号がレベルメーターで -20dB 表示される(工場出荷時)
-20dBs	−20dBs の入出力信号がレベルメーター で −20dB 表示される
	(0dBs = 0.775 Vrms)

基準信号レベルを切り替えた時は,次のボリュームを調整する.


RV102 (F6): 入力レベル (CH-1) 調整用

RV202 (E6): 入力レベル (CH-2) 調整用

RV103 (F4): 出力レベル (CH-1) 調整用

RV203 (E4): 出力レベル (CH-2) 調整用

CP-268 基板 (A面)



スイッチ

S11 (A1):アナログオーディオ (CH-1) 入力インピーダン

ス切り替えスイッチ

CH-1の入力インピーダンス切り替え用スイッ

#

S21 (A1):アナログオーディオ (CH-2) 入力インピーダン


ス切り替えスイッチ

CH-2の入力インピーダンス切り替え用スイッ

チ

S11, 21	入力インピーダンス設定	
OFF	10k Ω	
ON	600 Ω (工場出荷時)	

SV-147A 基板 (B面)



スイッチ

S1 (S1-1 to 1-4) : 調整モード設定スイッチ

(詳細は「第4章メカデッキの交換およ

び調整」参照)

工場出荷時の設定 :全てOFF (通常動作時の設定)

LED インジケータ

D1: CPU 動作表示

点滅(約1秒間隔) : 正常時 早い点滅(約0.5秒間隔): 異常検出時

点灯または消灯

: CPU 停止時

:調整モードOFF

: lock

D2:調整モード表示

消灯

点灯 : 調整モードON

D3:サーボ lock 表示

点灯

消灯 : unlock

1-7. ISR

PCM-7040は、ISR機能(Interactive Status Reporting: 統合機器管理機能)に対応しています。 この機能を利用すると、PCM-7040の状態や発生したエラーなどを、パーソナルコンピュータのモニタ画面上で集中監視・管 理することができます。

PCM-7040 が対応している主な機能は、以下のとおりです。

管理機能

• 識別情報

Manufacturer : SONY

Model

: PCM-7040

Device ID

:50字以内の識別番号または識別名。PCから設定可能。

Serial number : PCM-7040 本体 (サービスメニュー) で設定したシリアルナンバー

VM type

: 02 (VTR)

Destination

: 仕向け。UC, J, CE

ROM

:メイン CPU, サーボ CPU, 表示 CPUの ROM 情報。

(基板名称、ROM 名称、パージョン、基板アドレス)

• アワーメーター情報

Operation, Drum Running, Tape Running, Threading Counter の各積算計。

セットアップメニューデータのアップロードとダウンロード (一括設定)

監視機能

- エラー/コーションメッセージ エラーまたはコーション(ワーニング)番号、およびその内容の表示。また、エラー履歴の表示。
- 信号処理エラー(Channel Condition)メッセージ 信号処理エラーの表示。また、信号処理エラー履歴の表示。 Level:

0: GOOD,1: 一定数以上の訂正 (CORRECTION),2: 補間 (INTERPORATION),4: ミュート (MUTE)

• オペレーションステータス テープ走行モードの表示。

TAPE UNTHREAD, STOP, STANDBY OFF, PLAY, PLAY LOCK, REC, REC LOCK, EDIT, EDIT LOCK, F.FWD, REW, SHUTTLE STILL, SHUTTLE FWD, SHUTTLE REV, JOG STILL, JOG FWD, JOG REV, VAR STILL, VAR FWD, VAR REV, PREROLL, PREVIEW, AUTO EDIT, CHASE

テスト メイン CPU テスト, サウンドメモリーテスト

制御機能

• リモートコントロール EJECT, STANDBY ON/OFF, STOP, PLAY, REC, F.FWD, REW, CUEUP (TC LOCATE)

1-7-1. 接続

・セットアップメニュー "rS-232" (RS-232 MODE) と "bAud rAtE" (BAUD RATE) を設定する。

rs-232 : iSr (ISR)

bAud rAtE: 1200, 2400, 4800, 9600 のいずれか (9600 推奨)。パーソナルコンピュータの 設定と合わせる。

RS-232 MODE を ISR に設定した場合, パリティーとデータ長は, セットアップメニュー "PArity" (PARITY), "dAtA" (DATA BITS) の設定にかかわらず, それぞれ"ODD", "7" に固定される。

・ RS-232C クロスケーブルで、PCM-7040 の RS-232C コネクター(D-sub 25 ピン)とパーソナルコンピュータを接続する。

1-7-2. 対応コマンド

PCM-7040 が対応しているコマンドは、以下のとおりです。

Common Command List

Command from Controller	Response from Device	備考
*RST; (Reset)	*ATN:OPC;	
*IDN?; (Identify Query)	*ATN : QRESP ; id-data	
*TST ###### ; (Test)	*ATN:OPC;	
###### = TEST NUMBER		
*TST?; (Test Query)	*ATN: QRESP; test-result	
-	テスト結果がない場合 *ATN:QRESP;00Test:0	
*FLAGS? ; (Flag Query)	*ATN : QRESP ; flag-data	Power cycled on O &
*STATUS?; (Status Query)	*ATN : QRESP ; status-data	
*CMDERR?; (Command Error Query)	*ATN : QRESP ; command in error ->error-code : error-description	
	エラーがない場合 *ATN : QRESP ; 00*CMDFRR->No errors in queue	
*MSG? ##### ; (Message Register Query)	*ATN : QRESP ; message-data	VI for 11 1864
###### = REGISTER NUMBER	指定された番号がない場合 *ATN: QRESP; 00Not Active	
*UPLOAD? TYPE ; (Upload)	*ATN : QRESP ; setup-data	TYPE: SETFILE
TYPE = upload data の名称		
*UPLOAD? TYPE,size ; (Upload)	*ATN : QRESP ; size-data	TYPE: SETFILE
size = option Ø parameter		


Sony Private Command List

Command from Controller	Response from Device	備考
HRS?; (Hours Meter Query)	*ATN : QRESP ; item : value : unit	
HELP: TST?; (Help: Test-menu Query)	*ATN : QRESP ; ###### : test-description	
RDLOG? TYPE,D; (Read Log Query)	*ATN : QRESP ; log-data	TYPE: ERR
TYPE = Log の略称 D = Direction {F,L}	ログデータがない場合 *ATN : QRESP ; 00Empty	
CLRLOG TYPE ; (Clear Log)	*ATN:OPC;	TYPE: ERR
TYPE = Log の略称		
HELP: LOG? (Help: Log-menu Query)	*ATN : QRESP ; TYPE : descreption	
DEVID ; device-id (Device ID Set)	*ATN:OPC;	device-id は 50 字以内
DOWNLOAD TYPE ; data (Download)	*ATN : OPC ;	TYPE: SETFILE
TYPE = download data の名称		
DOWNLOAD TYPE,place; (Download)	*ATN:OPC;	TYPE: SEIFILE
place = device 内の data が入る場所 (option)		place: MEM
CHCOND?; (Channel Condition Query)	*ATN : QRESP ; channel-condition	
CHCOND : ALRDY? ; (Channel Condition : Already Query)	*ATN : QRESP ; time-code : channel-condition	
	ログデータがない場合 *ATN: QRESP; 00Empty	
RMCTL TYPE; (Remote Control)	*ATN: OPC;	
TYPE = control type		

1-10(J)

第2章 サービスインフォメーション

2-1. 主要部品配置図



① CP-269 : Connector ② CP-268 : Connector

③ SSP-11 : System Control, Signal Processor

④ CN-1487 : Power Relay (2次側)
 ⑤ PS-451 : Power Supply (1次側)
 ⑥ PS-452 : Power Supply (2次側)


7 VR-109 : REC Volume
8 SW-420 : Menu Switch
9 KY-192 : Display, Key Switch
10 LED-104 : LED Indicator
11 HP-48 : Headphones

RF-53 : RF Amplifier
 SV-147A : Servo

2-2. 外装の取外し

注意:取り外しは電源をOFFにして行ってください。


天板の取外し



フロントパネル組立の取外し

注意:

・フロントパネル組立の取外し、取付けを行う際は、カセットコンパートメントがイジェクト完了、またはカセットホルダーが下がりきった状態にして下さい。



2-2(J)

2-3. 主要部品の交換


2-3-1. リチウム電池の交換

PCM-7040 (SSP-11基板) には、メモリーバックアップ用として、リチウム電池が使用されています。交換時に使用するリチウム電池は、「Sec. 6.Spare Parts」の部品表に記載されている部品を、使用して下さい。

SSP-11 基板(Ref. No. BT301):リチウム電池 CR2450

注意

通常使用時における寿命は、3年を保証していますので、時 期を見て電池を交換して下さい。



交換手順

- PCM-7040本体の電源(POWER) スイッチを ON にして、10分以上通電しておく。
- (2) 電源 (POWER) スイッチを OFF にする。
- (3) スリットランド (SL301) のはんだを取る。
- (4) リチウム電池 (BT301) の*部を、矢印1方向へ動かして、SSP-11 基板より取り外す。
- (5) 新しいリチウム電池 (CR2450) の*部を、矢印2方向へ 動かして、SSP-11 基板に取り付ける。

注意

新しい電池の電圧が、2.6 V以上であることを確認してから、交換する。

(6) スリットランド (SL301) を、はんだ付け (はんだブリッジ) する。

注意

はんだを行う際、IC318の足などをショートしないよう に、注意する。


- (7) 電源 (POWER) スイッチを ON にする。
- (8) エラーメッセージが表示されずに起動することを、確認 する。

PCM-7040

2-3-2. ヒューズの交換

SSP-11 基板には、ヒューズが使用されています。 ヒューズを交換する際は、電源 (POWER) スイッチを OFF にして、電源コードをコンセントから抜いて下さい。 交換するヒューズは、「Sec. 6 Spare Parts」の部品表に記載 されている部品を、使用して下さい。

SSP-11 基板 (Ref. No. F1): ヒューズ 2A, 125V (J, UC向け) ヒューズ 1A, 250 V (CE向け)



2-3-3. SSP-11 基板の交換

SSP-11 基板は、以下の手順で交換して下さい。

交換手順

ステップ1:交換前の確認

(1) アワーメータ情報のメモ

各アワーメータ情報 "oPE-t", "Hour-t", "run-t", "tHrd-no", "A-Hour-t", "A-run-t", "A-tHrd" ([2-6-4. ディスプレイメニュー項目] 参照) をメモする。

または、サービスメニュー "Print" (「2-6-3. プリントメニュー項目」参照) を実行し、サービス情報をデータ出力する。

(2) SSP-11 基板上の S302 スイッチの各設定をメモする。

ステップ2:SSP-11 基板の取外し

「6-2. EXPLODED VIEWS」を参考にして、SSP-11 基板を本体より外す。

ステップ3:新しいSSP-11 基板の取付け

新しいSSP-11基板を本体に取り付ける前に、下記(1)から

- (3) の作業を行う。
- (1) リチウム電池 (BT301) の電圧を測定し、2.6 V以下の場合は、リチウム電池を交換する。(「2-3-1. リチウム電池の交換 | 参照)
- (2) 確認後、スリットランド (SL301) を、はんだブリッジ する。(「2-3-1, リチウム電池の交換 | 参照)
- (3) S302スイッチ (SSP-11基板) を、下記のように設定する。S302-1~-7 : ステップ1でメモした設定に合わせる。S302-8 : ON (バックアップメモリー初期化設定)

ステップ4: SSP-11 基板取り付け後の作業

(1) PCM-7040 の電源を ON にする。

確認:

- ディスプレイに "-ALL cLEAr-" が表示され、SSP-11 基板の D303 (赤) が点灯する。
- ② ディスプレイにエラー/コーションコードが表示されない。
- (2) S302-8 スイッチを "OFF" に設定する。
- (3) PCM-7040 の電源を入れ直す。(OFF/ON)確認:
 - ① D303 (赤) が、消灯 (点灯しない)。
 - ② ディスプレイにエラー/コーションコードが表示されない。
- (4) シリアルナンバーの設定を行う。(「2-6-6. プリセットメニュー項目」の "SEriAL" メニュー参照)
- (5) ステップ1の(1) でメモしたアワーメータ情報を、設定する。
- (6) 日付と時刻を、設定する。(セットアップメニュー dAtE SEt"を実行する。OPERATION MANUAL参照)
- (7)「第5章電気調整」の下記項目を行う。
 - 5-2. 信号処理系調整
 - 5-3. AD/DA 系調整
 - 5-2. タイムコード出力レベル調整

2-4. 緊急時のカセット取り出し方法

メカデッキASSYの不良や、イジェクト動作不良等で、電源の OFF 時にメカデッキ内のカセットを取り出す場合は、下記の方法で行う。


注意

テープの損傷を完全に防ぎたい場合は、この項目の手順 での取り出しは、行わないで下さい。

「62. EXPLODED VIEWS」を参考にして、カセットをカセットコンパートメントごと、メカデッキ ASSY より取り外して下さい。

取り出し方法

- (1) 本体の天板を外す。(「2-2. 外装の取外し」参照)
- (2) SSP-11 基板よりハーネス (4本) を外す。
- (3) ネジ (PWH3×6) 4本を外して、メカデッキ ASSY を本体より外す。



(4) MDプレート底面側の穴より、ドライブモータ回転用ギアを小型ドライバで時計方向 (SV-147A 基板上に UPと表示されている) に、スレッディング機構が初期位置に戻るまで回す。 (カセットがイジェクトされる方向に動く)


注意

カセットが完全に下降しきる以前に止まっている状態ならば、ドライブモータ回転ギアを小型ドライバで反時計方向に、カセットが完全に下降しきる位置まで回す。 その後、ドライブモータ回転用ギアを時計方向に回し、カセットをイジェクトする。

(5) スレッディング機構を初期位置に戻す際、テープがゆるむため、メカデッキ ASSY の側面にあるラチェット機構(下図参照)を繰り返し押して、テープのたるみをなくす。(この作業は、テープの損傷を防ぐために必ず行う。) 注意:

ラチェット機構は、必ずテープのたるみ具合を確認しな がら押す。 (6) カセットが取り出せる位置にくるまで、上記 (4), (5) の作業を行う。

(カセットホルダーが、完全に上昇しきるまで行う。)



2-5. エラー/コーションコード

ここでは、ディスプレイ上に表示されるエラー/コーションコードに対して、想定される不良箇所について述べます。

エラー (Error)

番号	内容	レベル	不良想定箇所
1-01	CPU (IC306) アドレスパスエラー	5	IC306
1-02	CPU (IC306) データパスエラー	5	IC306
1-03	ROM (IC307) エラー	5	IC307
1-04	RAM (IC309,310) エラー	5	IC309, 310
1-05	バックアップメモリー(IC309,310)データ破壊。 頻繁に発生する場合は、リチウム電池(BT301)の交換が必要。	5*	
1-06	EEPROM(IC308)データ破壊	5*	
1-07	パックアップメモリーデータと EEPROM データ破壊	5*	
1-08	EEPROM (IC308) エラー	4	IC308
1-09	4.9152 MHz クロックが発振しない	4	X301, IC301
1-10	割り込み信号エラー	5	IC306
1-20	9pin リモート CPU 通信エラー	4	IC306, IC318
1-21	37/8pin リモートエラー	4	IC306
1-30	時計ICエラー	4	IC314
2-00	サーボ CPU 通信エラー	5	IC306, SV-147A IC9
2-01	結 選 電源を入れたまま表示が消えるまで放置する。	5	
2-02	+12V電源エラー	5	
2-03	サーボ CPU(IC9)データパスエラー	5	SV-147A IC9
2-10	サーボRAM (IC9) エラー	5	SV-147A IC9
2-11	サーボ EEPROM(IC12)エラー	5	SV-147A IC12
2-20	スレディング動作が終了しない	5	
2-21	アンスレディング動作中リールが回転しない	5	
2-22	アンスレディング動作が終了しない	5	
2-23	カセットコンパートメントが動作しない	5	
2-24	テープガイドの位置がずれている	5	
2-25	ピンチローラーが圧着しない	5	
2-30	ドラムが回転しない	5	
2-31	ドラムの回転が速すぎる	5	
2-40	キャプスタンが回転しない	5	W-NIII -
2-41	キャプスタンの回転が速すぎる	5	
2-50	テイクアップ側リールが回転しない	5	
2-51	テイクアップ側リールの回転が速すぎる	5	
2-52	サプライ側リールが回転しない	5	
2-53	サプライ側リールの回転が速すぎる	5	
2-54	リールブレーキの動作電圧が異常	5	
3-02	SPブロックデータバスエラー	5	IC406
	先行 SBSY 信号エラー	5	10100

^{*:} STOPキーを押すとエラー表示が消える。

番号	内容	レベル	不良想定箇所
3-11	後行 SBSY 信号エラー	5	IC306, 406, 432
3-12	DAT FRAME 信号エラー	5	IC306, 406
3-13	先行 SWP 信号エラー	5	IC306, 406
3-14	先行 EXSY 信号エラー	5	IC306, 406, 418
3-15	後行 SWP 信号エラー	5	IC306, 406
3-16	後行 EXSY 信号エラー	5	IC306, 406, 432
3-20	先行 DMA CH-0 エラー	5	IC306, 418, 418
3-21	先行 DMA CH-1 エラー	5	IC306, 406, 418
3-22	後行 DMA CH-2 エラー	5	IC306, 406, 432
3-23	後行 DMA CH-3 エラー	5	IC306, 406, 432
5-02	TC ブロック データパスエラー	4	IC406
6-01	レコーダー用 MEM ブロック アドレスパスエラー	4	IC406
6-02	レコーダー用 MEM ブロック データパスエラー	4	IC406
6-04	レコーダー用サウンドメモリー(IC601)エラー	4	IC601
7-01	プレーヤー用 MEM ブロック アドレスパスエラー	4	IC406
7-02	プレーヤー用 MEM ブロック データバスエラー	4	IC406
7-04	プレーヤー用サウンドメモリー (IC601) エラー	4	IC601

コーション(cAution)

番号	内容	レベル	不良想定箇所
1-01	再生メイン ID 無効。 サンプリング周波数が 32 kHz(コンスーマ機の LP モード)や データストレージテープは再生できない。	1 .	
1-02	再生サブID 無効。	1	
1-10	記録中にサーボアンロックが発生し停止した。	2	
1-11	記録中に入力デジタルオーディオ信号にエラーが発生した。	2	
1-12	インサート記録中に未記録部を検出したため停止した。	2	
1-20	ロケート中にテープの始端か終端に達した。	2	
1-21	プログラム番号が不連続のためロケートを中止した。	2	
1-22	タイムコードが不連続か、見つからないためロケートを中止した。	2	
1-30	タイムコードが不連続か、編集点が見つからないため編集を中止した。	2	
1-40	時計クロックの発振が停止した。 日付 / 時刻を確認し、再設定する。 頻繁に発生する場合は、リチウム電池(BT301)の交換が必要。	2*	
1-50	SSP 基板の DIP スイッチ設定異常。S302 の設定を確認する。	3	S302
2-02	アワーメーター(ドラム回転時間)が点検時間に達した。 定期点検が必要。	2*	
2-50	SV 基板の DIP スイッチ設定異常。 SV-147 基板 S1 の設定を確認する。	3	SV-147A S1

レベル

2 (コーション): コーションコード自動表示。

フロントパネルの ALARM 点灯。

*:STOPキーを押すとエラー表示が消える。

2-6. サービスメニュー

サービスメニューは、下記メニューで構成され、セットアップメニューの後に位置する。

・プリントメニュー : RS-232C端子から各種情報を出力する

・ディスプレイメニュー :各種情報を表示する

・テストメニュー : 各種テスト (自己診断) を実行をする

・プリセットメニュー : シリアルNo. 等の設定を行う

1. サービスメニュー項目一覧

(1) プリントメニュー

Print : PRINT

プリントデータ出力

(2) ディスプレイメニュー

[DSPLy] open/close ディスプレイメニューの表示 / 非表示設定

Soft : SOFTWARE VERSION ソフトウエアパージョン

oPE-t : OPERATION TIME 通電時間計

Hour-t: DRUM RUNNING TIMEドラム回転時間計 (リセット可)run-t: TAPE RUNNING TIMEテープ走行時間計 (リセット可)

tHrd-no : THREAD/UNTHREAD COUNTER テープのスレッド/アンスレッド計 (リセット可)

A_Hour-t : DRUM RUNNING TIME ドラム回転時間計 A_run-t : TAPE RUNNING TIME テープ走行時間計

A_tHrd : THREAD/UNTHREAD COUNTER テープのスレッド/アンスレッド計

-----:セパレーター

Err : ERROR/CAUTION LOG エラー/コーションコードの履歴

Pb Aud id: PB MAIN ID再生 MAIN IDPb Sub id: PB SUB ID再生 SUB IDPb Pro-t: PB PRO R-TIME再生プロ R-TIME

tc Sno : TIME CODE MARKER 再生 / 記録タイムコードマーカー

Pb Abst : PB A-TIME 再生 A-TIME Pb yEAr : PB DATE 再生日付 Pb Hour : PB TIME 再生時刻

tc rdr : TIME CODE READER タイムコードリーダーステータス

dSno: dSNoタイムコード差分(ワード単位)FS cntr: Fs COUNTER外部同期信号周波数カウンター

PS Chit · FS COUNTER 外部同期信号周波数カウンター 9_6 cntr · 9.6k COUNTER 9.6 kHz 信号周波数カウンター

Pb SPEED: PB SPEED実際のバリスピードrAtE SEL: ERROR RATE SELECTエラーレート表示選択

rAtE SEL : ERROR RATE SELECT エラーレート表示選択 Err rAte : ERROR RATE エラーレート

FS id : Fs ID サンプリング周波数 (Fs) ID

din Err : DIN ERROR デジタル入力ステータス
Sy diP-S : SYS DIP SWITCH ディップスイッチ SSP-11 S302
Sr diP-S : SV DIP SWITCH ディップスイッチ SV-147A S1
inPut Au : INPUT AUDIO LEVEL 入力オーディオ信号レベル

inPut Au : INPUT AUDIO LEVEL 入力オーディオ信号レベル rEPro Au : REPRO AUDIO LEVEL 再生オーディオ信号レベル

232 StAt :RS-232C STATUS RS-232C ステータス

-----: セパレーター

(3) テストメニュー

[tESt]open/closeテストメニューの表示 / 非表示設定SyS cPu: SYS CPUTESTアドレス / データバス、RAM, ROM テストdiSPLAy: DISPLAY TESTフロントパネルのディスプレイ / ランプテスト

PAnELS: PANNEL KEYTEST フロントパネルのキーテスト

toGGLE-S:TOGGLE SWITCH TEST フロントパネルのトグルスイッチ / ダイヤルテスト

diAL : DIALTEST ダイヤルテスト

37Pin-1 : 37/8pin REMOTE TEST-1 37/8pin リモートテスト 37Pin-2 : 37/8pin REMOTE TEST-2 37/8pin リモート自動テスト rS-232 : RS-232C TEST RS-232C リモート自動テスト 9 Pin : 9pin REMOTE TEST 9pin リモート自動テスト Au PAth : AUDIO PATH TEST オーディオ信号経路テスト

Sound : SOUND MEMORY TEST サウンドメモリーテスト

-----: セパレーター

trnSP-1 : MECHANIZUM DECKTEST-1 メカデッキテスト-1
trnSP-2 : MECHANIZUM DECKTEST-2 メカデッキテスト-2
PAtH AdJ : TAPE PATH ADJUSTMENT テープパス調整

torq AdJ : FWD/REV TORQ CHECK FWD/REV トルク確認 rEcoG-S : RECOGNITION SWITCH レコグニッションスイッチ

d-SEnSor : DEW SENSOR 結露センサー tAPE LEn : TAPE LENGTH テープ長

Sr EEP : SV EEPROM DATA サーボ EEPROM データ

(4) プリセットメニュー

ProtEct : PROTECT セットアップメニュー登録の許可/禁止設定

tyPEcodE : 9pin DEVICE TYPE 9pin デバイスタイプ設定 SEriAL : SERIAL No. シリアルナンバー設定

2. サービスメニューの入り方 STOPキー+DISPLAYキー+SETキーを押す。 ディスプレイに、"Print" と表示されて、サービスメニューに入る。

サービスメニューの抜け方
 STOP キー + DISPLAY キー + RESET キーを押す。
 または、電源スイッチを OFF にする。

4. 各操作

・メニュー項目の変更 : MENU キー + サーチダイヤル

・ 設定データの桁移動 : MENU キー

・ 設定データの変更 : DATA キー + サーチダイヤル

データの設定またはテストの開始 : SET キー

・設定データのリセットまたはテスト中止 : DATA キー + RESET キー

メニュー項目	説明
Print : PRINT	各種情報(テキストデータ)をリアパネルの RS-232C 端子から出力する。 パソコンまたはプリンターとの接続は、クロスケーブルを使用する。
	・ 条件 :STOPモードまたはカセットなし。
	・ 出力方法:DATA キーを押しながらダイヤルを回して出力するデータを選択 し、SET キーを押す。
	inFo :サービス情報
	(パージョン、仕向け、シリアルナンパー、アワーメー ター、サーボデータ)
	Err LoG :エラー/コーション撮歴
	corr LoG : 信号処理エラー (ミュート / 補間 / 一定数以上の訂正) 履歴
	• 通信条件
	フロー制御 :ハードウエア (RTS/CTS)
	ストップビット:1bit
	データピット :セットアップメニュー"dAtA" (DATA BITS) に従う
	パリティー :セットアップメニュー "PArity" (PARITY) に従う
	ボーレート :セットアップメニュー "bAud rAtE"(BAUD RATE)に従う
	・ 中断方法:DATA キー + RESET キー

2-6-2. ディスプレイメニュー

メニュー項目 [DSPLy] open/close		説明			
		ディスプレイメニューの表示 / 非表示を設定する。OPEN:表示			
SoFt	: SOFTWARE VERSION	ソフトウエアパージョン			
		_ * * *_* * *_* *_*			
		MENU キーを押すと、メイン CPU のパージョン変更日付(年・月・日)が表示される			
oPE-t	: OPERATION TIME	通電時間計 0~99,999 時間			
Hour-t	: DRUM RUNNING TIME (リセット可)	ドラム回転時間計(リセット可)0~99,999時間			
run-t	: TAPE RUNNING TIME (リセット可)	テープ走行時間計(リセット可)0~99,999時間			
tHrd-no	: THREAD/UNTHREAD COUNTER (リセット可)	テープのスレッド/アンスレッド計(リセット可)0~99,999回			
A_Hour-t	: DRUM RUNNING TIME	ドラム回転時間計(リセット不可)0~99,999 時間			
A_run-t	: TAPE RUNNING TIME	テープ走行時間計(リセット不可)0~99,999時間			
A_tHrd	: THREAD/UNTHREAD COUNTER	テープのスレッド/アンスレッド計 (リセット不可) 0~99,999回			
Err	: ERROR/CAUTION LOG	エラー / コーションコードの履歴(100 個分)。エラーまたはコ ーションが発生した時のコードと日時、およびテープ走行モードとテープカウンター値を表示する			
		 DATA キー+ダイヤル : アドレス増減 MENU キー : アドレス +10 DATA キー+ RESET キー : 履歴のクリア DATA キー+ SET キー : RS-232C 出力 (サービスメニューの "Print" で "Err LoG" を実行した場合と同じ) 			
		左側表示 Err ***アドレス (1~100)			
		・右側表示 1) コード *** *-**			
		ー コード Err:エラー CAu:コーション			
		2) 日付(年・月・日)3) 時刻(時・分・秒)4) テープカウンター、テープ走行モード			
		** ** ** ** rープ走行モード cout : デープなし cuE : CUE FWD StoP : STOP cuE : CUE REV Ejct : EJECT FF : FF PLAy : PLAY rE : REW rEc : REC テープカウンター (時・分)			

説明

Pb Aud id : PB MAIN ID

テープから再生した MAIN ID データ。

* * * * * * * * * (8) (7) (6) (5) (4) (3) (2) (1)

X:未規定

			人 木規正
番号	ID名	表示	内容
Θ	フォーマットID	0 1 2 3	AUDIO USE X X X
@	ID1: エンファシス	0 1 2 3	OFF 50/15 µs × ×
3	ID2:サンプリング間波数	0 1 2 3	48 kHz 44.1 kHz 32 kHz ×
④	ID3:チャンネル数	0 1 2 3	2チャンネル 4チャンネル × ×
(5)	ID4:量子化数	0 1 2 3	16 ビット直線 12 ビット非直線 × ×
6	ID5:トラックピッチ	0 1 2 3	ノーマル ワイド ×
Ø	ID6:コピー	0 1 2 3	許可 × 禁止 記録済み
8	ID7:パック	_	

メニューゴ	Ę
Pb Sub id	:

説明

Pb Sub id : PB SUB ID

テープから再生した SUB ID データ。

- * * * - * * * 4 3 2 1


X:未規定

			A · 不然足
番号	ID名	表示	内容
1	データID	0 1 2 3	AUDIO USE X X X
2	コントロールID	4 ピット HEX 表示	bit0:TOC bit2:SHORTENING (SKIP) bit3:START bit4:PRIORTTY
3	パック ID	0~7	記録されているパックの数
④	プログラム番号	000 001 ~ 799 0AA 0BB 0EE	プログラム番号なし プログラム番号 無効 リード イン エリア リード アウト エリア (END ID)

Pb Pro-t : PB PRO R-TIME テープから再生したプロR-TIMEデータ。時・分・秒・フレーム $(0 \sim 33)$ tc Sno : TIME CODE MARKER プロ R-TIME のタイムコードマーカー値。 P * * * (HEX) T*** 記録 再生 Pb Abs-t : PB A-TIME テープから再生した A-TIME データ。時・分・秒・フレーム $(0 \sim 33)$ Pb yEAr : PB DATE テープから再生した日付データ。曜日・年・月・日 曜日 年 月 日 曜日1:日曜,2:月曜…7:土曜 Pb Hour : PB TIME テープから再生した時刻データ。時・分・秒 ** ** ** 時 分 秒

tordr : TIME CODE READER

タイムコードリーダーおよび入力タイムコードステータス。



メニュー項目 説明 dSno : dSNo ターゲットタイムコードと再生タイムコードの差分 (ワード単位)。 符号000**** (HEX) FS cntr : Fs COUNTER 入力同期信号(D-I, WORD, VIDEO)の周波数カウンター値。この値から周波数 を算出できる。 **** (HEX) 入力信号周波数(Hz) =カウントクロック周波数 (Hz) x256/Fs COUNTER カウントクロック周波数 (128Fs) 48 kHz : 6.1440 MHz 44.1 kHz : 5.6448 MHz 9_6 cntr : 9.6k COUNTER 37pin パラレルリモートの 9.6 kHz 入力信号の周波数カウンター値。この値から周 波数を算出できる。 *** (HEX) — カウンター値の平均値 --- カウンター値 入力信号周波数(Hz) =カウントクロック周波数 (Hz) x 256 /9.6 k COUNTER カウントクロック間波数 (32Fs) 48 kHz : 1.536 MHz 44.1 kHz : 1.4112 MHz Pb SPEED: PB SPEED 実際のテープ再生速度。 符号***(%) 例) -125:-12.5% rAtE SEL: ERROR RATE SELECT Err rAtE(エラーレート)を算出する再生データのヘッドとチャンネルを選択す る。STOP時のみ有効。Auto以外を設定した時は、フロントパネルの ALARM ラ ンプが点滅する。 • DATA キー+ダイヤル : 設定データ変更 · SET +-: 設定

d-b

後行

表示 ヘッド チャンネル Auto RMW: 先行, RAW: 後行 A-ch と B-ch の平均 A-Ab 先行 A-ch と B-ch の平均 A-A 先行 A-ch A-b 先行 B-ch d-Ab 後行 A-ch と B-ch の平均 d-A 後行 A-ch

B-ch

メニュー項目	説明		
Err rAte: ERROR RATE	rAtE SELで選択したヘッド,チャンネルからの再生データから算出したエラーレート。再生開始後、約6秒後に表示する。		
	_-* 例)1_0-4:1.0E-4		
FSid: FsID	Fs(サンプリング周波数)ID。		
	E* d* t* S* SW : フロントパネルスイッチ TAPE: テープの再生 MAIN ID (ID2) DIN : デジタルオーディオ入力 EXT : 入力同期信号の計測値		
	8 : 48 kHz 4 : 44.1 kHz 0 : 44.056 kHz 3 : 32 kHz — : 上記以外		
EP id : EMPHASIS ID	エンファシス ID。		
	r* d* t* S* SW :セットアップメニューのプリエンファシス設定 TAPE:テープの再生 MAIN ID (ID1) DIN :デジタルオーディオ入力 REC :テープに記録する MAIN ID (ID1)		
	0 : OFF		
	1 :50/15 µsec ON 2 :CCTTT ON — :上記以外		
coPy id : COPY ID	コピーID。		
	r * d * t * S * SW :セットアップメニューのコピー ID 設定 TAPE:テープの再生 MAIN ID (ID6) DIN :デジタルオーディオ入力 REC :テープに記録する MAIN ID (ID6)		
	0 : 許可 2 : 禁止 3 : 記録済み - : 上記以外		

メニュー項目 説明 din Err : DIN ERROR 入力デジタルオーディオ信号のタイプ (プロ/コンスーマ) とディスプレイの "D-I" 点滅時の理由。 Pro - DIN PLL アンロック ワードスリップ (同期をかけないでデジタル接続した場合など) ID ミスマッチ 0: 発生していない 1: 発生している - Pro:プロ用, con:コンスーマ用 Sy diP-S : SYS DIP SWITCH SSP-11 基板 DIP SW (S302) 設定。 0:OFF No. 8 7 6 5 2 3 1 1:0N Sr diP-S : SV DIP SWITCH SV-147A 基板 DIP SW (S1) 設定。 0:OFF No. 4 3 2 1:0N inPut Au : INPUT AUDIO LEVEL 絶対値変換した 16bits 入力オーディオ信号データとビットマップメーター。 ビットマップメーター:オーディオデータの各ピットを1つのメーターセグメ ントに対応させ、1の時に点灯する。 **** (HEX) 0000~7FFF, 8000: OVER *** CH-1 CH-2 bit0 (右端) bit14 OVER 絶対値変換した 16bits 再生オーディオ信号データとピットマップメーター。 なお、メモリージョグ、リハーサル時は表示しない。 rEPro Au : REPRO AUDIO LEVEL **** (HEX) 0000~7FFF, 8000: OVER *** CH-1 CH-2 bit0 (右端) OVER bit14 232 StAt : RS-232C STATUS RS-232Cのステータス表示 送信データ (HEX) 受信データ (HEX) DSR (0:OFF, 1:ON) DCD (0: OFF, 1: ON) - 受信エラー (HEX) bit0:パリティーエラー bit1:オーバーランエラー bit2:フレーミングエラー

2-6-3. テストメニュー

メニュー項目	説明				
[tESt] open/close	テストメニューの表示 / 非表示を設定する。OPEN:表示				
SyS cPu : SYS CPU TEST	システムコントロール CPU (SSP-11 基板 IC304) のアドレスバスとデータバス, および ROM (IC307), RAM (IC309, 310) のテスト。(約20秒)				
	条件 :STOPモードまたはカセットなし。テスト方法 :SETキーを押す。				
	・ テスト結果				
	結果 ディスプレイ表示				
	エラーなし **** **** (HEX)				
	エラーあり 0000 **** アドレスパス データパス ROM (IC307) RAM (IC309, 310)				
display : Display Test	フロントパネルの FL ディスプレイ,LED ランプのテスト。				
	 条件 :STOPモードまたはカセットなし。 テスト方法 :SETキーを押す。 全点灯→LEDランプ順次点灯→FLディスプレイのセグメント順次点灯→FLディスプレイのグリッド順次点灯を繰り返す。 (1サイクル:約30秒) 				
	・中断方法 : DATA キー + RESET キー				

説明

PANELS : PANELKEY TEST

フロントパネルのキーのテスト。

- 条件 :STOPモードまたはカセットなし。
 テスト方法 :SETキーを押す。次にフロントパネルの27個のキーをすべて押 す。 結果がディスプレイに表示される。

• テスト結果

77. ALA	/ 八:相木				
結果	ディスプレイ表示				
エラーなし	no Error				
エラーあり	- * * * * * * * (HEX) ⑦ ⑤ ⑤ ④ ③ ② ① HEX表示のデータをバイナリーに変換し、0のビットに 対応したキーがエラー				
	例) - FFFFFdF (HEX) ② "d":1101 (バイナリ) ② の bit1 が "0"、対応表から CUE キーがエラー				

• 対応表

1						
桁	bit	+-	桁	bit	+-	
1	0 1 2 3	EJECT STOP STANDBY FF	(5)	0 1 2 3	MARK DISPLAY MENU DATA	
2	0 1 2 3	REW CUE PLAY REC	6	0 1 2 3	SET RESET MEMORY START INSERT SUB	
3	0 1 2 3	WRITE ERASE NEXT PREVIOUS	T	0 1 2	INSERT AUDIO ASSEMBLE SYNC REC	
④	0 1 2 3	LOCATE VARI CHASE INPUT MONITOR				

・中断方法 : DATA キー+ RESET キー

説明

toGGLE-S

: TOGGLE SWITCH TEST

フロントパネルのトグルスイッチ、サーチダイヤルのテスト。

:STOPモードまたはカセットなし。

・テスト方法 : SETキーを押す。次にフロントパネルの4個のトグルスイッチを切り換え、サーチダイヤルを時計方向/反時計方向に回す。 結果がディスプレイに表示される。

• テスト結果

結果	ディスプレイ表示			
エラーなし	no Error			
エラーあり	0 * * * (HEX) 3 2 ①			
	HEX表示のデータをパイナリーに変換し、()のビットに 対応したスイッチがエラー			

• 対応表


AJACISA.				
桁	bit	+-		
①	0 1 2 3	REMOTE LOCAL EXT INT		
@	0 1 2 3	VIDEO ANALOG DIGITAL 44.1 kHz		
3	0 1 2	48 kHz DIAL右回し DIAL左回し		

・中断方法 : DATA キー + RESET キー

dial : DIAL TEST

サーチダイヤルの位置表示。

・ テスト方法 :サーチダイヤルを回し、一周した時に右側の表示がほぼ"0"に なることを確認する。



- ・リセット方法: RESET キー
- · 不良想定箇所: KY-192 基板ロータリーエンコーダ

SSP-11 基板 IC306 CXD8970,

SSP-11 基板 CN303

説明

37Pin-1 : 37pin REMOTE TEST-1

37/8pin リモートのテスト。

条件 :STOPモードまたはカセットなし。テスト方法 :SETキーを押す。

1) 次の順序でステータス出力をオンにする。

(1 サイクル:約12 秒) 5:REW→3:FF→4:PLAY→2:STOP→6:STANDBY →8:REC→9:LOCATE→7:INPUT MONITOR

→ 14: ALARM → 18: SERVO LOCK → 11: START ID → 12: SKIP ID → 13: END ID → 10: Reserved → 8pin 4: PLAY → 8pin 5: STOP

2) 37pin/8pin リモートに接続されたキーを押す。結果がディスプレイに表示される。

• テスト結果

結果	ディスプレイ表示		
エラーなし	no Error		
エラーあり	* * * * * * * (HEX) ⑥ ⑤ ④ ③ ② ① HEX 表示のデータをパイナリーに変換し、0のピットに 対応したコマンドがエラー		

• 対応表

桁	bit	コマンド	桁	bit	コマンド
1	0 1 2 3	21: STOP 22: FF 23: PLAY 24: REW	•	0 1 2 3	33: CHASE 34: EJECT 35: Reserved 36: EXT SOURCE
@	0 1 2 3	25: STANDBY 26: INPUT MONITOR 27: REC 28: ID NEXT	(5)	0 1 2 3	16: SPEED A "0" 16: SPPED A "1" 17: SPPED B "0" 17: SPEED B "1"
3	0 1 2 3	29: ID PREVIOUS 30: START ID WRITE 31: SKIP ID WRITE 32: END ID WRITE	6	0 1 2 3	15: REVERSE "0" 15: REVERSE "1" 8pin 2: STOP 8pin 1: PLAY

• 中断方法 : DATA + - + RESET + - 37Pin-2 : 37pin REMOTE TEST-2

37/8pin リモートの自動テスト。コネクター治具(下記参照)を使用する。

- : STOPモードまたはカセットなし。
- ・ テスト方法
 - (1) 下記の端子間を接続した D-sub 37pin (オス) コネクタ、および DIN 8pin (オス) コネクタを、それぞれ、リアパネルの REMOTE (37P)、および REMOTE (8P) コネクタに差し込む。
 - ・D-sub 37pin (オス) コネクタ

2ピン (STOP) ←→ 21ピン (STOP) と35ピン (Reserved)

3ピン (FF) ←→22ピン (FF) と36ピン (EXT SOURCE SELECT)

4 ピン (PLAY) → 23 ピン (PLAY) と 15 ピン (REVERSE) 5 ピン (REW) → 24 ピン (REW) と 16 ピン (SPEED A)

6ピン (STANDBY) ←→ 25ピン (STANDBY) と17ピン (SPEEDB)

7ピン (INPUT MONITOR) ←→26ピン (INPUT MONITOR)

8ピン (REC) --- 27ピン (REC)

9 ピン (LOCATE) --- 28 ピン (ID NEXT) 10 ピン (Reserved) --- 29 ピン (ID PREVIOUS) 11 ピン (START ID) --- 30 ピン (START ID WRITE)

12ピン (SKIP ID) ←→ 31ピン (SKIP ID WRITE)

13 $\mbox{$\mathbb{C}$}\mbox{$\vee$}$ (END ID) $\mbox{$\longleftrightarrow$}$ 32 $\mbox{$\mathbb{C}$}\mbox{$\vee$}$ (END ID WRITE) 14 $\mbox{$\mathbb{C}$}\mbox{$\vee$}$ (ALARM) $\mbox{$\longleftrightarrow$}$ 33 $\mbox{$\mathbb{C}$}\mbox{$\vee$}$ (CHASE)

18ピン (SERVO LOCK) -- 34ピン (EJECT)

DIN 8pin (オス) コネクタ 2ピン (STOP) ←→5ピン (STOP) 1ピン (PLAY) ←→4ピン (PLAY)

(2) SET キーを押す。

• テスト結果

結果	ディスプレイ表示
エラーなし	по Еггот
エラーあり	* * * * (HEX) ④ ③ ② ①
	HEX表示のデータをパイナリーに変換し、0のビットに対応した接続線がエラー

・対応表

桁	bit	接続	桁	bit	接続
1	0 1 2 3	(1) STOP (2) FF (3) PLAY (4) REW	3	0 1 2 3	(9) Reserved (10) STARTID (11) SKIPID (12) ENDID
2	0 1 2 3	(5) STANDBY (6) INPUT MONITOR (7) REC (8) LOCATE	(4)	0 1 2 3	(13) ALARM (14) SERVO LOCK (15) 8pin STOP (16) 8pin PLAY

- 不良想定箇所:IC306 CXD8970,IC320~321 TD62381,IC322~324 HC245
- 中断方法 : DATA キー+ RESET キー

説明

rS-232: RS-232C TEST

RS-232Cの自動テスト。コネクター治具(下記参照)を使用する。

- · 条件 :STOPモードまたはカセットなし。
- テスト方法 :
 - (1) 下記の端子を接続した D-sub 25pin (オス) コネクタを、リアパネルの RS-232C コネクタに差し込む。
 - D-sub 25pin (オス) コネクタ
 - 2 ピン (TXD) ←→3 ピン (RXD) 4 ピン (RTS) ←→5 ピン (CTS) 6 ピン (DSR) ←→20 ピン (DTR)
 - (2) SET キーを押す。

• テスト結果

結果	ディスプレイ表示
エラーなし	no Error
エラーあり	0 0 0 0 0 * * * * (3) DSR/DTR (2) RTS/CTS (1) TXD/RXD

- 不良想定箇所: IC306 CXD8970, IC317 LT1134
- 中断方法 : DATA キー+ RESET キー

9 Pin : 9pin REMOTE TEST

9pinリモートの自動テスト。コネクター治具(下記参照)を使用する。

- ・条件
- :STOPモードまたはカセットなし。
- ・テスト方法
 - (1) 下記端子間を接続した D-sub 9pin (オス) コネクタを、リアパネルの REMOTE (9P) コネクターに差し込む。
 - D-sub 9pin (オス) コネクタ
 - 2 ピン (Transmit A) ーー8 ピン (Receive A) 7 ピン (Transmit B) ーー3 ピン (Receive B)

 - 6ピン (Transmit Common) ←→4ピン (Receive Common)
 - (2) SET キーを押す。

• テスト結果

結果	ディスプレイ表示
エラーなし	no Error
エラーあり	000000** 9pin CPUと MAIN CPU間通信エラー Transmit/Receive Data
	1: エラー

- ·不良想定箇所:IC306 CXD8970, IC318 uPD78C11, IC319 MC34051
- ・中断方法 : DATA キー+ RESET キー

談明

Au PAth : AUDIO PATH TEST

SSP-11 基板のオーディオ信号経路のテスト。

:カセットなし。

・ テスト方法 :アナログ/デジタル入力端子に異なるオーディオ信号を入力す

る。信号経路番号を切り替えて、アナログ、またはデジタル入

力音が出力されることを確認する。

音が出ない場合は、下記のブロック図と表から不良 IC を特定す

る。

なお、SSP-11 基板の S51 を "TEST" にすると、AD コンバー


ター出力がそのまま DA コンパーターに入力される。

・ DATA キー+ダイヤル :信号経路番号の変更

• SET +-

: 設定

オーディオ信号経路ブロック図 (SSP-11 基板)



オーディオ信号経路番号と経路IC (SSP-11 基板)

番号	出力	IC 51	IC 801	IC4 CXD	406 8971	ICe	301	IC 603	IC 602	IC 604		406 8971	IC 417	IC 431		406 98971	IC 806	IC57, 58
7	шл	AD	DI RECV	DI DEC	DI SC	P MEM	R MEM	DSP #1	DSP #2	DSP #3	REC SC	PB SC	SP- L	SP-	DO SC	DO ENC	DO DRV	DA
1	A	0						0							0	0	0	0
2	D		0	0	0			0							0	0	0	0
3	D		0	0	0			0		0					0	0	0	0
4	D		0	0	0	0		0		0					0	0	0	0
5	D		0	0	0				0	0					0	0	0	0
6	D		0	0	0		0		0	0					0	0	0	0
7	D		0	0	0			0		0	0	0	0		0	0	0	0
8	D		0	0	0				0	0	0	0	0		0	0	0	0
9	D		0	0	0			0		0	0	0		0	0	0	0	0

出力 A : Analog, D: Digital

SC : Slot Converter (16 - 32bits)

SP-L : Signal Processor (Leading: 先行)

SP-T : Signal Processor (Trailing:後行)

説明

Sound: SOUND MEMORY TEST

SSP-11 基板 IC406 CXD8971 のメモリーコントロールプロックのアドレスバスと データバス、およびサウンドメモリー (IC601) のテスト。(約70秒)

:STOP モードまたはカセットなし。

• テスト方法 :SETキーを押す。

• テスト結果

結果	ディスプレイ表示
エラーなし	no Error
エラーあり	* 0 * * * 0 * *

tmSP-1 : MECHANIZUM DECK TEST-1

メカデッキの各デバイスのテスト。

条件 :空カセットを用意する。
 テスト方法 :SETキーを押し、空カセットを挿入する。 テスト終了後、空カセットが自動でイジェクトされる。

• テスト結果

结果	ディスプレイ表示
エラーなし	no Error
エラーあり	①************************************

メニュー	項目	說明						
troSP-2	: MECHANIZUM DECK TEST-2	・条件	プランジャーのテスト。 :カセットなし。 :SET キーを押す。動作音を確認する。					
		結果	ディスプレイ表示					
		エラーなし	no Error					
		エラーあり	000000 * *					
			1: エラー					
	: TAPE PATH ADJUSTMENT	テープバスを調整する。 ・ 使用テストテープ:テストテープ TY-7251 ・ 調整方法:DATA キーを押しながら、サーチダイヤルを回して ATF OFFSET (oFF:off, 0:0%, 50:50%, 100:100%) を変更し、SET キーを押す。 調整の詳細は、「4-2-2. サービスメニューでの調整および確認」の 11. TAPE PATH ADJUSTMENT を参照のこと。						
torq AdJ	: FWD/REV TORQ CHECK	FWD/REV 時のリールトルクを確認する。						
		・ 使用テストテープ:トルクカセット TW-7131						
		(DATA キーを押しながら、サーチダイヤルを回して"on"表示に し、SET キーを押す。 トルクカセットを挿入し、PLAY キーを押して FWD 走行させるか CUE キーを押してからサーチダイヤルを左に回して、REV 走行さ せ、各トルクを確認する。 トルク規格値は、「42-2. サービスメニューでの調整および確認」 9. FWD/REV TORQUE ADJUSTMENT を参照のこと。					

説明

rEcoG-S : RECOGNITION SWITCH


カセットホールスイッチのオン/オフを表示する。

* * * * * * 5 4 3 2 1

桁	ホール名	表示	OPEN/CLOSE
1	HOLE-1 (RESERVED)	0 1	OPEN (RESERVED) CLOSE
@	HOLE-2 (THIN)	0	OPEN (THIN) CLOSE
3	HOLE-3 (WIDE)	0	OPEN (WIDE) CLOSE
4	HOLE-RECINH	0	OPEN (REC INHIBIT) CLOSE
(§	HOLE-4 (SOFT TAPE)	0	OPEN (SOFT TAPE) CLOSE

d-SEnSor : DEW SENSOR

デューセンサーデータと電圧値を表示する。



tAPE LEn: TAPE LENGTH

テープ長を表示する。カセットを挿入してから表示されるまでの時間は、FLAYで約10秒、FF/REWで瞬時。

Sr EEP : SV EEPROM DATA

SV-147A 基板 IC12の EEPROM データの表示。

• DATA キー+ダイヤル:アドレス増減

アドレス	データ	アドレス	データ	アドレス	データ
00	SWP POSITION	12	EQ-LX2	24	
01		13	EQ-H-X2	25	
02		Н	EQ-Q-X2	26	
03	FWD TORQ S	15	EQ-P-X2	27	
04	FWD TORQ T	16	REC-L-PCMA1	28	
05	REV TORQ S	17	REC-L-PCMB1	29	
06	REVTORQT	18	REC-LATFA1	30	
07	OFFSET TORQ	19	REC-LATFB1	31	
08	EQ-LX1	20	REC-T-PCMA1	32	ENDSL)VV
09	EQ-H-X1	21	REC-T-PCMB1	33	END SHG-H
10	EQ-Q-X1	22	REC-T-ATFA1	34	END TL) W
11	EQ-P-X1	23	REC-T-ATFB1	35	ENDTHGH

2-6-4. プリセットメニュー

メニュー項目	説明						
ProtEct : PROTECT	セットアップメニュー登録"-sto-"の許可/禁止設定。設定はバックアップされる。禁止の設定でメニュー登録をしようとした場合、ディスプレイに"-ProtEct-"が表示される。						
	oFF :許可(工場出荷時の設定)						
	on :禁止						
tyPEcodE: 9pin DEVICE TYPE	9pin リモートのデバイスタイプを設定する。設定はバックアップされる。						
	注意: 00 00 以外に設定しても、EDIT DELAY などの VTR 定数は変わらない。						
	** ** (HEX) DATA1 DATA2						
	00 00 : PCM-7030/7050 または PCM-7040 のデバイスタイプ (工場出荷時) PCM-7030/7050/7040 のデバイスタイプ設定は、SSP-11 基板の						
	S302 No.3, 4 スイッチで行う。 その他 :設定したデータをそのまま返答。例)2025 : DVW-75						
SEriAL : SERIAL No.	シリアルナンバーを設定する。設定はバックアップされる。 ISRの識別情報要求コマンド(*IDN?;)に対する返答に使用される。						
	* * * *						

第3章 定期点検および保守

3-1. クリーニング

機械の性能の維持のためにクリーニングを行います。 クリーニングは、下記の方法で行ってください。 クリーニング後、カセットを挿入する前に、ドラム表面の空 拭きを十分に行ってください。

空拭きが不完全な場合、結露と同様の作用でテープを破損 する危険性があります。

- 1) 通常のクリーニング
 - ー週間に一度程度、下記のクリーニングカセットを使用してドラム及びテープパス系をクリーニングする。 クリーニングカセット: DT-10CL (ソニー商品扱い) 注意: クリーニング時間は、30 秒以内にすること。
- 2) クリーニングカセットでは汚れが十分に取れない場合 (この場合ドラムのヘッドに無理な力を加えないよう、 特に注意が必要となる。)

ドラムクリーニング

- (1) アルコールを浸したクリーニングピースで、下ドラムを リードに沿ってクリーニングする。この時、ドラム側面 に手を触れないように注意する。
- (2) 乾いたクリーニングピースで(1) と同じ部分を空拭きする。
 - (2) は (1) の直後に行うこと。アルコールが完全に蒸発した後では、残った汚れを空拭きで除去するのが難しい。
- (3) アルコールを浸したクリーニングピースで上ドラムをクリーニングする。この時、上ドラム側面には決して手を触れないようにしながら、ドラムを矢印方向 (⇒) へ回し、上ドラム側面及びヘッドを拭く。この動作を上ドラムが約3回転するまで行う。


- (4) 乾いたクリーニングピースで(1) と同様に上ドラムを 約2回転にわたって空拭きを行う。
 - (4) は (3) の直後に行うこと。アルコールが完全に蒸発した後では、残った汚れを空拭きで除去するのが難しい。
- (5) 上ドラム全周を目視で検査し、アルコール蒸発時のしみ や、指紋が残ってないことを確認する。 クリーニングピース: 部品番号 2-034-697-00

注意:

- 1. ドラムを駆動させながらのクリーニングは、絶対に行わ ないこと。
- 2. クリーニングピース (鹿皮) をヘッドチップに対して、 決して垂直方向に動かしてクリーニングしないこと。 ヘッドチップが破損する危険性が非常に大きい。
- 3. ドラムクリーニングの際、LED に手を触れないように すること。
- 4. クリーニングローラにほこり等が付着していた場合には、ピンセットで確実に取り除くこと。

テープ走行系のクリーニング

- (1) キャプスタン軸、ピンチローラ、傾斜ガイドピンはアルコールを浸したクリーニングピースで汚れを拭き取った 後、空拭きを行う。
- (2) 回転ローラ (T1, T2, T3, S1, S2, テンションアームローラ) 部は汚れがひどくなる前に、竹ぐし等のやわらかいもので汚れをはぎ取った後、クリーニングピースで空拭きを行う。



3-2 定期交換のスケジュール

セットの機能及び性能を十分に発揮させるために、主な部品の定期点検時間および定期交換時間を、表に示します。 定期点検は、SERVICEメニュー内にあるHOUR METER (アワーズメータ)の読みを1つの目安として行うことを推奨します。(「2-6.サービスメニュー」参照) 下記、部品の交換方法および調整方法については、「第4章

下記、部品の交換方法および調整方法については、「第4章 メカデッキの交換および調整」に記載されています。

定期点検、保守スケジュール

注意 表に示す時間は部品の保証時間ではありません。

3-3. セット修理後の保守

セット修理後は、セットの使用時間の長短に関係なく、下記 項目の保守を行ってください。

- 1. ドラムヘッドのクリーニング
- 2. テープ走行面のクリーニング

部品名称			ドラ	ム時間計	(H)			備老
(部品番号)	1週間	1000H	2000Н	3000H	4000H	5000H	6000H	调专
メカデッキ ASSY MT-PCM 7040-103 (A-8311-799-)							☆	6000Hごとに交換
ドラム ASSY、DOU-21B/J-N (8-848-696-)				☆			(☆)	1週間ごとにクリーニング 3000Hごとに交換
キャプスタンモータ、U-21A (8-835-329-)	0			☆			(☆)	1週間ごとにクリーニング 3000Hごとに交換
リールモータ (1-698-227-)		☆	☆	☆	☆	*	(☆)	1000Hごとに交換
ピンチローラASSY (X-3363-976-)	0			ជ			(☆)	1週間ごとにクリーニング 3000Hごとに交換
ドライブモータASSY (A-8267-759-)							(☆)	6000Hごとに交換
HCローラ (3-375-727-)	}			☆			(☆)	3000Hごとに交換
ロータリーエンコーダ (1-466-670-)				☆			(☆)	3000Hごとに交換
カセットコンパートメントASSY (A-8267-998-)				☆			(☆)	3000Hごとに交換

○: クリーニング、☆:交換、(☆): これらの部品は MT-PCM7040-103 の構成部品のため、メカデッキ ASSY を交換することにより、自動的に交換される。

第4章 メカデッキの交換および調整

4-1. メカデッキ ASSY およびメカデッキ部品(定期交換部品)の交換方法


定期交換部品 (「第3章 定期点検および保守」参照) の交換は下表に従って行う。

- ・定期交換部品を交換する際に、取り外す必要のある部品を○印で示す。 また、○印の中の数字は、取り外しの必要な部品の取り外し順序を表す。
- ・部品の組み立ては取り外しの逆の手順で行う。交換後は「42. 調整および確認」を行う。


注意:作業は、POWER スイッチを OFF にして行う。


					取り外しの	必要な部品	2			
定期交換部品	RF シールド ケース (上)	カセット 窓 ASSY	MD 侧板 (L)	MD 側板 (R)	RF-53 ASSY	フレキ シールド 板	SV-147A 基板	MD シールド 板	カセット コンパート メント ASSY	リール モータ
メカデッキ ASSY	_	_	-	_	_	_	_	_	_	_
ドラムASSY DOU-21B/J-N	•	2	3	•	6	6	Ø	8		
キャプスタンモータ、 U-21A	_	0	@	3	_	_	@	(5)	-	_
リールモータ	_	0	@	3	_	_	4	(5)	_	_
ピンチローラASSY	_	0	@	3	_	_	•	5	6	⑦
ドライブモータASSY	1	@	3	•	6	_	6	Ø	_	_
НС□ − ラ	_	_	_	_	_	_	_	_	_	_
ロータリーエンコーダ	_	0	@	3	_	_	@	3	_	_
カセットコンパートメント ASSY	_	0	@	3	_		•	(5)	_	

HC ローラ、メカデッキ ASSY




RFシールドケース (上) 、カセット窓 ASSY、MD 側板 (L) / (R)、MD プレート






カセットコンパートメント ASSY



ドライブモータ ASSY、ロータリーエンコーダ、 キャプスタンモータ、ピンチローラ ASSY



4-2. 調整および確認

PCM-7040メカデッキASSYおよびメカデッキ部品 (定期交換部品) を交換後、表Aに従って調整および確認を行ってください。

調整および確認は、PCM-7040メカデッキ ASSY を PCM-E7700に装着して、PCM-E7700に内蔵のサービスメニューを使用して行います。したがって、PCM-E7700 (完動品)を、別途調整用として用意してください。


· PCM-E7700への取り付け方法

調整する PCM-7040 メカデッキ ASSY を下記手順に従って、PCM-E7700 のメカデッキ (レコーダ) ASSY の位置に取り付ける。


手順

注意:取り付けは、PCM-E7700の電源をOFFにして行ってください。


(1) ネジ (PWH3×6) 3本を外して、天板を取り外す。




(2) ディスプレイ ASSY を矢印方向に開く。



(3) ネジ (PWH3×6) 2本を外し、キーASSYを矢印方向 に少し移動させる。



- (4) メカデッキ (レコーダ) ASSYの接続ハーネス (3ヵ所) および、ネジ (PWH3×5) 3本を外して、メカデッキ (レコーダ) ASSY を、PCM-E7700より取り外す。
- (5) 調整する PCM-7040 メカデッキ ASSY をネジ (PWH3×5) 3本で、取り付ける。



(6) 下記コネクタからのハーネス (3本) を、取り付けた PCM-7040メカデッキ ASSY に接続する。

PCM-7040 メカデッキ ASSY に接続する。
PCM-E7700 PCM-7040 メカデッキ ASSY
CN501, SSP-8 基板 → CN7, SV-147A 基板
CN708, SSP-8 基板 → CN11, SV-147A 基板
CN711, SSP-8 基板 → CN2, RF-53 基板

(7) 手順(3)で、動かしたキーASSYをネジ(PWH3×6)2本で取り付ける。

注意: RF-53 ASSY からのハーネスは接続不要

(8) [4-2-2. サービスメニューでの調整および確認]を行う。

表 A: 調整項目一覧

メカデッキ ASSY およびメカデッキ部品 (定期交換部品) を交換した際、表中の〇印の項目が必要な調整項目。

交換部品	メカテ・ッキ	h* 7 4	かセコン	1.242.	DC I /	リール	t">#	D-\$1)-	нс	70	つ他
	組立	ASSY	ASSY	1 / 3 ASSY	和プス 妙	1-9	D-7 ASSY	I>3-3°	D-7	SV-147A ASSY	ASSY
調整項目 (サービスモード)									ļ	(RP)	(RP)
1. SERVO DATA PRESET											
2. PLUNGER CHECK						0					
3. MECHANICAL DEVICE TEST		0	0	0	0	0	0	0	0	0	
4. RECOGNITION SWITCH CHECK							0	0			
5. END SENSOR LEVEL CHECK (HIGH)			0							0	
6. END SENSOR LEVEL CHECK (LOW)			0							0	
7. DEW SENSOR CHECK											
8. REEL TORQUE CHECK						0					
9. FWD/REV TORQUE ADJUSTMENT						0				0	
10. DRUM/CAPSTAN SPEED & WOW CHECK		0									
11. TAPE PATH ADJUSTMENT		0			0	0	0				
12. SWP POSITION ADJUSTMENT		0								0	
13. PATH & FF/REW TIME CHECK		0			0	0	0				
14. PB ERROR RATE CHECK	0	0			0	0	0			0	0
15. REC CURRENT ADJUSTMENT (LEADING)		0								0	0
16. REC CURRENT ADJUSTMENT (TRAILING)		0								0	0
17. REC/PB ERROR RATE CHECK	0	0								0	0
18. SERVO DATA SAVE		0				0				0	0
19. SERVO DATA DISPLAY											
4-2-3. SV-147A基板交換時の確認										0	
5-2-3. RF PLL調整	0	0									0

4-2-1. 準備

使用機器

名称	仕様	機器名
オシロスコープ	- 4CH INPUT - DC to 150MHz	TEKTORONIX 2445Aまたは相当品
デジタルマルチメータ (テスター)		アドバンテストR6341Aまたは相当品

治工具

名称	部品番号	備考
SONY PCM-E7700	製品	完動品
調整ドライバー	J-6225-100-A	テープパス微調整用
RF LEVEL CHECKER PD-817	J-6228-170-A	記録再生系調整用
RF LEVEL CHECKER用 I/F ボックス PF-534	J-6405-340-A	PCM-E7700用

テストテープおよびトルクカセット

名称	部品番号	備考
テストテープ TY-7111DX	8-909-825-00	再生レベル確認用
テストテープ TY-7251	8-909-813-00	トラッキング調整用
テストテープ TY-30BX	8-892-332-38	記録レベル調整用 (ブランクテープ)
テストテープ TY-7212	8-960-081-01	エラーレート確認用
トルクカセット TW-7131	8-909-708-71	FWD/REVトルク調整用
トルクカセット TW-7231	8-909-708-72	FF/REWトルク確認用

以下のテストテープは、市販のテープを表に従って使用する。

名称	使用方法
空カセット	テープなし (市販のDATテープを改造)
テストテープ (01010)	空カセットでカセット識別穴 (孔) が以下のテープ (市販のDATテープを改造)
	10 10 10 10 10 123 REC INH 4 ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○
テストテープ (10101)	空カセットでカセット識別穴 (孔) が以下のテープ (市販のDATテープを改造) 101 01 123 REC INH
	O O: OPEN •: CLOSE
テストテープ (エンドセンサLOW)	市販の120分テープ (テープ中央付近で使用)
テストテープ (TOP)	市販の120分テープ (テープTOP付近で使用)
テストテープEND)	市販の120分テープ (テープEND付近で使用)
テストテープ (FF/REW TIME)	市販の30分テープ (テープ全長記録済みで使用)

4-2-2. サービスメニューでの調整および確認

サービスメニューの入り方

PCM-7040メカデッキ ASSY を PCM-E7700 に取り付け後、SV-147A 基板 (PCM-7040メカデッキ ASSY) のBITスイッチ (S1) を以下のように設定する。

S1/SV-147A 基板の設定

S1-3: ON

S1-1, -2, 4; OFF

- (2) PCM-E7700の POWER スイッチを ON にする。
- (3) SHIFT キー+ MODE キーを同時 (2 重押し) に押す。 (サービスメニューの設定)

EL ディスプレイ画面表示

SERVICI	MENU				
1 PLAS	ER MECHAN	TICAL DECE	ADJUSTMEN	Т	
2 REC	ORDER MEC	HANICAL DI	ECK ADJUSTM	ENT	
3 TEST			,		
4 INFO	RMATION				
4 INFO	R-MD	TEST	INFORM		

注意:F1~F7;ファンクションキー

(4) F2 (R-MD) キーを押す。

EL ディスプレイ画面表示

RE	ECORDE	R ADJUSTN	IENT				
D:	CEDUO	DECK PR	PCFT		SERVO	BOARD B	IT SW
-		ER CHECK				nn	
_		DEVICE	_			FF MAN I	
				-		FF EEPRO	
			WITCH CHE			N ERROR	
1			VEL CHECK		BIT4 O	FF	
			VEL CHECK	(LOW)			
1		ENSOR CE					
			DJUSTMENT		•		i
9	FWD/R	VS TORQL	ie adjustm	ENT	;		!
10	DRAM/	CAPSTAN	SPEED & W	OW CHECK	i		
					1		
	MF	SSAGE					
l							
ĺ							
l	_						
REC	ORDER :	STOP					
TEST	ON	EXIT					
F	1	F2	F3	F4	F5	F6	F7

*:SERVICE MENU 時のモード設定操作キー表示

操作キー モード

[SHUTTLE]: STILL

[PREVIOUS]: SHUTTLE -16

[NEXT]: SHUTTLE + 16 [PGM SEARCH]: SHUTTLE - 1

[LOCATE]: SHUTTLE +1

[1]: SHUTTLE - 8

[2]: SHUTTLE +8

[4]: SHUTTLE - 2 [5]: SHUTTLE + 2

[7]: SHUTTLE -0.2 [8]: SHUTTLE +0.2

サービスメニューの抜け方 (通常動作への復帰) 調整終了後、サービスメニューから通常動作モードへの復帰 は以下のように行う。

- SV-147A 基板 (PCM-7040 メカデッキ ASSY) の BIT スイッチ (S1) を以下のように設定する。
 S1-1、-2、-3、4; すべて OFF
- (2) PCM-E7700の POWER スイッチを OFF にする。
- (3) PCM-E7700のPOWERスイッチをONにする。
- (4) 通常動作モードへ復帰後、PCM-E7700の POWERスイッチを OFF にして、PCM-7040メカデッキ ASSY を、PCM-E7700より取り外す。

1. SERVO DATA PRESET (1. サーボデータプリセット)

通常、メカデッキ部品 (定期交換部品) を交換した際は、この調整および確認は行う必要はない。

注意:誤ってサーボデータープリセットを行った場合は、PCM-E7700の POWERスイッチを OFF にし、再度 ON にする。

使用機器、治工具;使用せず 使用テストテープ;使用せず

手順 :	確認
(1) ① 、	ELディスプレイ画面 注意:画面に表示されるプリセット値は、ROMのパージョンによって異なることがある。
(2) FI (TEST ON) キーを押す。	RECORDER ADJUSTMENT 1. SERVO DECK PRESET
 (3) ELディスプレイ画面にMESSAGE: PRESETTING IS COMPLETED!が表示される。 (4) 表示後、FI (TEST OFF) キーを押す。 (プリセット終了) 注意: FI キーを1回押すとTEST ONの状態からTEST OFF (画面表示)へと切り換 	SWP POSITION = 117 (75H)
わる。	PRESETTING IS COMPLETED!
	RECORDER: NO TAPE
	TEST ON
	F1 F2 F3 F4 F5 F6 F7

2. PLUNGER CHECK (2. プランジャ回路動作確認)

使用機器、治工具;使用せず 使用テストテープ;使用せず

手順	確認
(I) ↑、↓キーで"2. PLUNGER CHECK" を選択する。	ELディスプレイ画面
(2) [FI] (TEST ON) キーを押す。(3) プランジャが動作する音を確認する。	RECORDER ADJUSTMENT 2. PLUNGER CHECK PLUNGER KICK PASS PLUNGER RELEASE PASS
また、ELディスプレイ画面の結果表示 を確認する。	TEST OFF
(4) [F] キーを押す。	F1 F2 F3 F4 F5 F6 F7
	結果表示:PASS ···正常 FAULT····異常

3. MECHANICAL DEVICE TEST (3. メカデバイステスト)

使用機器、治工具;使用せず


使用テストテープ;空カセット (「421.準備」参照)


Į	手順	確認
	(1) ↑、↓キーで"3. MECHA DEVICE TEST"を選択する。	ELディスプレイ画面
	 (2) FI (TEST ON) キーを押す。 (3) 空カセットを挿入する。 メカデバイステストが実行され、テスト結果が画面に表示される。表示後、空カセットが自動的にイジェクトされ 	RECORDER ADJUSTMENT 3. MECHANICAL DEVICE TEST CASSETTE UP SWITCH PASS CASSETTE DOWN SWITCH PASS ROTARY ENCORDER PASS DRUM MOTOR PASS CAPSTAN MOTOR PASS SUPPLY REEL MOTOR PASS TAKEUP REEL MOTOR PASS
	3 。	RECORDER: NO TAPE TEST OFF
	(4) 表示を確認後、[FI]キー (TEST OFF) を 押す。	F1 F2 F3 F4 F5 F6 F7
		結果表示:PASS ···正常
		FAULT…異常
		注意: メカデバイステストモードに設定した場合、1度テストを実行しないと次のモード に移ることができない。

4. RECOGNITION SWITCH CHECK (4. レコグニションスイッチおよびストップ位置確認)

使用機器、治工具; 使用せず

使用テストテープ; テストテープ (01010) (「42-1. 準備」参照)





5. END SENSOR LEVEL CHECK (HIGH) (5. エンドセンサ動作確認 (HIGH))

使用機器、治工具;使用せず 使用テストテープ;空カセット

手順	確認/規格				
(1) 「 、	ELディスプレイ画面				
(2) FI (TEST ON) キーを押す。	RECORDER ADJUSTMENT 5. END SENSOR LEVEL CHECK (HIGH) T-END SENSOR LEVEL = X. XX V (XXH) S-END SENSOR LEVEL = X. XX V (XXH)				
(3) 空カセットを挿入する。ELディスプレイ画面にセンサーレベルが表示される。センサーレベルが規格	RECORDER: SBOFF TEST OFF				
を満足することを確認する。	F1 F2 F3 F4 F5 F6 F7				
(4) [FI] (TEST OFF) キーを押す。自動的に 空カセットがイジェクトされる。	規格: センサーレベル=1.0 V以上				

6. END SENSOR LEVEL CHECK (LOW) (6. エンドセンサ動作確認 (LOW))

使用機器、治工具;使用せず

使用テストテープ; テストテープ (エンドセンサ (LOW)) (「42-1.準備」参照)

手順	確認/規格
(1) ↑、↓キーで"6. END SENSOR LEVEL CHECK (LOW)"を選択する。	ELディスプレイ画面 RECORDER ADJUSTMENT 6. END SENSOR LEVEL CHECK (LOW)
(2) FI (TEST ON) キーを押す。	T-END SENSOR LEVEL - X. XX V (XXH) S-END SENSOR LEVEL - X. XX V (XXH)
(3) テストテープ (エンドセンサ (LOW)) を 挿入する。	RECORDER: SBOFF
神人りる。 注意;テストテープ(エンドセンサ	TEST OFF
(LOW))は、テープの巻き取り中 央付近で使用する。 ELディスプレイ画面にセンサー レベルが表示される。センサー レベルが規格を満足することを 確認する。	F1 F2 F3 F4 F5 F6 F7 規格;センサーレベル=0.2 V以下
(4) F1 (TEST OFF) キーを押す。自動的に テストテープ (エンドセンサ (LOW)) が イジェクトされる。	

7. DEW SENSOR CHECK (7. DEW センサーレベル確認)

使用機器、治工具;使用せず 使用テストテープ;使用せず

手順	確認/規格						
(1) ① (1) (1) キーで "7. DEW SENSOR LEVEL CHECK" を選択する。	ELディスプレイ画面						
	RECORDER ADJUSTMENT 7. DEW SENSOR LEVEL CHECK						
(2) F1 (TEST ON) キーを押す。ELディス プレイ画面にセンサーレベルが表示さ	DEW SENSOR LEVEL - X. XX V (XXH)						
れる。センサーレベルが規格を満足し	RECORDER: NO TAPE						
ていることを確認する。	TEST OFF						
(3) Fi (TEST OFF) キーを押す。	F1 F2 F3 F4 F5 F6 F7						
	規格;センサーレベル=0.1 V< <u>X.XX V</u> <0.4 V						
	表示レベル						

8. REEL TORQUE CHECK (8. FF/REW 最大、最小トルク確認)

使用機器、治工具;使用せず

使用テストテープ;トルクカセット TW-7231

手順	確認/規格								
(1) 計、↓キーで "8. REEL TORQUE	ELディスプレイ画面 (TEST ON画面)								
CHECK"を選択する。	RECORDER ADJUSTMENT 8. REEL TORQUE CHECK								
(2) F1 (TEST ON) キーを押す。(3) トルクカセット (TW-7231) を挿入す	CHECK OFF REEL TORQUE CHECK FF L (1.5V) CHECK OFF REEL TORQUE CHECK REW L (1.5V)								
کی (۱۳۰۰-۱۳۵۱) داخل کا در این این کا در این داخل ک کا در این داخل کا در	CHECK OFF REEL TORQUE CHECK FF H (4.3V)								
	CHECK OFF REEL TORQUE CHECK FF L (4.3V) CHECK OFF OFFSET TORQUE								
	RECORDER: SBOFF								
	TEST OFF								
	F1 F2 F3 F4 F5 F6 F7								
(4) ↑、↓ キーで "REEL TORQUE CHECK FFL" を選択する。トルクカセット (T側リール) のトルク値が 規格内(右記) であることを確認する	注意;T=TAKE UPリール側、S=SUPPLYリール側 規格;T-REEL トルク=0.0004~0.001 N·m (4~10 g·cm)								
(5) 1、 ↓ キーで "REEL TORQUE CHECK REW L" を選択する。	規格; S-REEL トルク=0.0004~0.001 N·m (4~10 g·cm)								
トルクカセット (S側リール) のトルク値									
が規格内(右記)であることを確認する									
(6) []、[]キーで "REEL TORQUE CHECK	規格;T-REEL トルク=0.0026 N·m以上 (26 g·cm以上)								
FFH"を選択する。									
トルクカセット (T側リール) のトルク値が 規格内(右記) であることを確認する									
(7) 「一、「「十一で "REEL TORQUE CHECK	規格:S-REEL トルク=0.0026 N·m以上 (26 g·cm以上)								
REW H"を選択する。									
トルクカセット (S側リール) のトルク値	•								
が規格内(右記)であることを確認する									
(8) FI (TEST OFF) キーを押す。									
自動的にトルクカセットがイジェクト									
される。									

9. FWD/REV TORQUE ADJUSTMENT (9. FWD/REV トルクおよびバックテンション調整)

使用機器、治工具;使用せず

使用テストテープ; トルクカセット TW-7131

手順	確認/規格							
(1) 1, 1+−で、"9. FWD/REV	ELディスプレイ画面 (TEST ON画面)							
TORQUE ADJUSTMENT"を 選択する。	RECORDER ADJUSTMENT 9. FWD/RVS TORQUE ADJUSTMENT							
(2) FI (TEST ON)キーを押す。	FWD T-REEL TORQUE = XXX (XXH) FWD S-REEL TORQUE = XXX (XXH) REV T-REEL TORQUE = XXX (XXH) REV T-REEL TORQUE = XXX (XXH)							
(3) トルクカセット(TW-713 I)を挿 入する。	OFFSET TORQUE - XXX (XXH)							
A, 50.	RECORDER: PLAY							
	TEST OFF † ↓							
	F1 F2 F3 F4 F5 F6 F7							
(4) ↑、↓キーで、"FWD T-REEL TORQUE"を選択する。 (5) PLAY キーを押す。	規格;T-REEL トルク=0.00050±0.00005 N·m(5.0±0.5 g·cm) 調整;F6 (UP)キー、F7 (DOWN)キーを押して行う。							
(6) ①、↓キーで、"FWD S-REEL	規格;S-REEL トルク=0.00065±0.00005 N·m(6.5±0.5 g·cm)							
TORQUE"を選択する。	讃整;[F6] (UP)キー, [F7] (DOWN)キーを押して行う。							
(7) ① 、	規格:T-REEL トルク=0.0013±0.0001 N·m(13±1 g·cm)							
TORQUE"を選択する。	調整: F6 (UP)キー, F7 (DOWN)キーを押して行う。							
(8) SHUTTEL(-IX[PGM SEARCH] キー)を押す。								
(9) ①、↓ キーで、"REV S-REEL	規格;S-REEL トルク=0.0008±0.0001 N·m(8±1 g·cm)							
TORQUE"を選択する。	調整; F6 (UP)キー, F7 (DOWN)キーを押して行う。							
(10)F1 (TEST OFF)キーを押す。								
自動的にトルクカセット(TW-								
7131)がイジェクトされる。								

10. DRUM/CAPSTAN SPEED & WOW CHECK(10. ドラム死点確認)

使用機器、治工具;使用せず

使用テストテープ;空カセット (「4-2-1.準備」参照)

レディスプレ <i>・</i>	7 画面	74	*******		-			
DE								
I ALE	RECORDER ADJUSTMENT DRUM SPEED = 2000 rpm				10. DRUM/CAPSTAN SPEED & WOW CHECK			
REG	CORDER:	PLAY						
TES	T OFF		SPEED					
F	71	F2	F3	F4	F5	F6	F 7	
1:1	TES	RECORDER:	RECORDER: PLAY TEST OFF F1 F2	RECORDER: PLAY TEST OFF SPEED F1 F2 F3	RECORDER: PLAY TEST OFF SPEED F1 F2 F3 F4	RECORDER: PLAY TEST OFF SPEED F1 F2 F3 F4 F5	RECORDER: PLAY TEST OFF SPEED	

11. TAPE PATH ADJUSTMENT (11. テープパス調整)


使用機器、治工具

オシロスコープ 調整用ドライバ (J-6225-100-A)

使用テストテープ

テストテープ TY-7251

接続



手順					確認/規格	+	**********	
(1) オシロスコープをRF-53 ASSYの	ELディン	スプレイ画面						
下記箇所に接続する。 <u>オシロスコープ</u> <u>RF-53 ASSY</u>		RECORDE	R ADJUSTME	NT	11. TAPE P	ATH ADJUST	TMENT	
CH1 \rightarrow TP1(RF-A) CH2 \rightarrow TP2(RF-D)			OFFSET = 0	%				
CH3 → TP3(SWP-A,TRIG) GNDは、メカデッキの板金等に		RECORDE TEST OFI		0%	50%	100%		
接続する。		F1	F2	F3	F4	F5	F6	F7
(2) [1]、[1] キーで、"11. TAPE PATH ADJUSTMENT"を選択する。	:							
(3) FI (TEST ON)キーを押す。								
(4) テストテープ(TY-7251)を挿入す								
る。								
(5) PLAY キーを押す。	規格:R	F波形 (TP1)カ	『四角くなる	ようにする	 3.			
					支形 (TP1)			
				24 0	a.			
			50.	SAL	000,1	April 19.		
	調整;S	Iガイド, T1カ	イドの高さ	を調整ドラ	ライバ (J-622	25-100-A)を	使用して微	調整する。

(6) F5(100%)キーを押す。 確認;RF波形(TPI)が平行に変化することを確認する。 (ATF OFF) 調整:S1ガイド、T1ガイドの高さを調整してRF波形が平行に変化するようにする。 (7) F4(50%)キーを押す。 確認:RF波形(TP1)が下記規格を満足することを確認する。 (ATF OFFSET) 規格:・波高値50%でRFの波形が長方形になること。 ・波形フラット部に対しての落込みが変動を含めて10%以内 RF波形 (TP1) 規格: B/A ×100 (%) ≥ 80% 確認(規格):2秒以内にRF波形(TPI)が安定すること。 (8) F3 (0%)キーを押す。(ATF ON) (9) SHUTTEL(-16) キーを押す。 (10) PLAY キーを押した時のRF波形 の立ち上がり時間を確認する。 (11) EJECT キーを押し、テストテー 確認(規格):2秒以内にRF波形(TPI)が安定すること。 プをイジェクトする。 (12)テストテープ(TY-7251)を挿入 し、PLAYキーを押し、RF波形 の立ち上がり時間を確認する。 (13) F1 (TEST OFF)キーを押す。 自動的にテストテープ(TY-7251) がイジェクトされる。

12. SWP POSITION ADJUSTMENT (12. SWP 位置調整)

使用機器、治工具

オシロスコープ

使用テストテープ

テストテープ TY-7251

接続

"11. TAPE PATH ADJUSTMENT"に同じ

手順	調整/確認/規格
(1) オシロスコープをRF-53 ASSYの	ELディスプレイ画面
下記箇所に接続する。 *** ** ** ** ** ** **	RECORDER ADJUSTMENT 12. SWP POSITION ADJUSTMENT SWP POSITION = XXX (XXH) RECORDER: PLAY
(2) Fi (TEST ON)キーを押す。	TEST OFF
(3) テストテープ(TY-7251)を挿入す る。	F1 F2 F3 F4 F5 F6 F7
(4) PLAY キーを押す。 F6 (UP)キー、F7 (DOWN)キーでSWP 位置を調整する。	規格: SWPの立ち下がりからRF波形のマーカーの立ち下がりまでの時間(T) T=650±15 μsec T CH1: TP1 (RF-A) CH3(TRIG): TP3 (SWP-A) (SHIFT キー+ F6 (UP)キーまたは、F7 (DOWN)キーを押す。(10ステップ単位での調整) ・ F6 (UP)キーまたは「F7 (DOWN)キーを押す。(1ステップ単位での調整)
(5) Fil (TEST OFF)キーを押す。自動的にテストテープ(TY-7251)がイジェクトされる。	

13. PATH & FF/REW TIME CHECK(13. テープ走行確認およびテープカール確認)

使用機器、治工具

オシロスコープ

使用テストテープ

テストテープ (TOP) (「4-2-1. 準備」参照) テストテープ (END) (「4-2-1. 準備」参照) テストテープ (FF/REW TIME) (「4-2-1. 準備」参照)

接続

"11. TAPE PATH ADJUSTMENT"に同じ

手順	調整/確認/規格
(1) オシロスコープをRF-53 ASSYの	ELディスプレイ画面
下記箇所に接続する。	
オンロスコープ RF-53 ASSY	RECORDER ADJUSTMENT 13. PATH & FF/REW TIME CHECK
CH1 → TP1(RF-A)	FF TIME = 0 SEC
CH3 → TP3(SWP-A, TRIG)	REW TIME - 0 SEC
(2) [†]、[↓]キーで、"13. FF/REW	RECORDER: NO TAPE
TIME CHECK"を選択する。	TEST OFF
(3) Fi (TEST ON)キーを押す。	F1 F2 F3 F4 F5 F6 F7
(4) テストテープ(TOP)を挿入する。	
(5) SHUTTLE (+1) (LOCATE + -)	規格;ピンチローラの前後で、テープ折れやガイドからのテープ脱落がないこと。
および SHUTTLE (-1)	
(PGM SEARCH キー)を交互に	
繰り返し押す。	
テープ走行が規格を満足するこ	
とを確認する。	
(6) SHUTTLE (+16) (NEXT +−)	規格:ピンチローラの前後で、テープ折れやガイドからのテープ脱落がないこと。
および SHUTTLE (-16)	
(PREVIOUS) キー)を交互に繰り	
返し押す。	;
テープ走行が規格を満足するこ	
とを確認する。	
(7) EJECT キーを押してテストテー	
プ(TOP)をイジェクトする。	
(8) テストテープ(END)を挿入する。	規格;ビンチローラの前後で、テープ折れやガイドからのテープ脱落がないこと。
(9) SHUTTLE (+1) (LOCATE [‡] −)	
および SHUTTLE(-1)	
(PGM SERCH キー)を交互に繰り	
返し押す。この時のテープ走行が	
COLLY OCANALAN Y VOIT VI.	

規格;ピンチローラの前後で、テープ折れやガイドからのテープ脱落がないこと。
規格: · FF動作テープ巻取り時間=20秒以内
REW動作テープ巻取り時間=20秒以内
· FFおよびREW中にテープの当り抜けが発生しないことを、オシロスコープのRF波形で
確認すること。

14. PB ERROR RATE CHECK (14. 再生エラーレート確認)

使用機器、治工具

オシロスコープ

使用テストテープ

テストテープ TY-7212

注意:1. ERROR RATE 測定は必ず PCM-E7700 の天板を取り付けて行う。

2. 確認を行う前に、クリーニングテープを使用して、10 秒間クリーニングする。

手順			i	整/確認/規格	·			
(1) 1 キーで、"14. PB ERROR	ELディスプレイ画面							
RATE CHECK"を選択する。	RECORD	ER ADJUSTME	ENT	14. PB ERROR	RATE CH	IECK		
(2) [FI] (TEST ON)キーを押す。	1	L-X1-L = 64 H-X1-H = 66		PB SPEED	X 1			
(3) テストテープ(TY-7212)を挿入す	1 1	Q-X1-Q = 59 P-X1-P = 44		PB HEAD ERROR RATE		DING H X. XE-X		
& .	EQ-I	L-X2-L = 21 H-X2-H = 44 Q-X2-Q = 37 P-X2-P = 21	(2CH) 7 (25H)	Drave Mile		H X. XE-X		
	RECORD	ER: PLAY		TIME CODE:	00:10	: 58 : 40		
	TEST OF	PF		HEAD		t	1	
	F1	F2	F3	F4	F5	F6	F 7	
(4) PLAY キーを押し、規格を満足 することを確認する。	規格;再生エラーレ 再生エラーレ	- トB-CH=	(表示: 5E	5-3以下) 下				
(5) STOP キーを押す。 (6) F4 (HEAD)キーを押し、画面の	規格:再生エラーレ	ha.CH=	5 X 103 U	F				
"PB HEAD TRAILING"を確認す る。	, MIR 1 17 1 - 7 - 7		(表示: 5E	•				
	再生エラーレ	B-CH=	5×10³以	下				
(7) PLAY キーを押し、規格を満足 することを確認する			(表示: 5E	-3以下)				
(8) STOP キーを押す。								
(9) FI (TEST OFF)キーを押す。								
自動的にテストテープ TY-7212								
がイジェクトする。								

15. REC CURRENT ADJUSTMENT (LEADING) (15. 記録レベル調整 (先行ヘッド))

使用機器、治工具

オシロスコープ

RF レベルチェッカ PD-817

RF レベルチェッカ用 I/F ボックス PF-534


使用テストテープ

テストテープ TY-7111DX テストテープ TY-30BX

接続

接続は、PCM-E7700のPOWERスイッチをOFFにして行う。


I/F ボックス PF-534 のケーブル (15P) の CN302/SSP-8 基板への接続は、キーパネル ASSY を外して行う。 調整は、ケーブル (15P) を、はさまないようにして、 キーパネル ASSY を本体に取り付けてから行う。



手順				1	整/確認/	見格		
(1) (1) (1) キーで、"15. REC CURRENT ADJUSTMENT (LEADING)"を選択する。	ELディス	プレイ画面 RECORDE	R ADJUSTM	IENT	15. REC CU	RRENT ADJ	USTMENT (L	EADING)
(2) FI (TEST ON)キーを押す。		REC REC	CURRENT CURRENT CURRENT CURRENT	PCM-B ATF-A	XXX (XXH) XXX (XXH) XXX (XXH)			
(3) テストテープ(TY-7111DX)を挿 入する。		RECORDE	R: REC			E: 00 : 10	: 58 : 40	
		TEST OF	•				1	1
(4) テストテープ(TY-7111DX)に添 付されている校正値表に従っ て、校正値をRFレベルチェッ カ(PD-817)のオフセットダイヤ ルで設定する。*!		F1	F2	F3	F4	F5	F6	F7
(5) PLAY キーを押す。 RF波形(オシロスコープ)が安定 することを確認する。								
(6) RFレベルチェッカ(PD-817)の CAL キーを押す。								

- (7) CAL 終了後、RFレベルチェッカ (PD-817)のCAL キーのLEDが点 減から点灯に変わったら、
 EJECT キーを押して、テスト テープ(TY-7111DX) をイジェクトさせる。
- (8) テストテープ(TY-30BX,ブランク部分)を挿入する。
- (9) RFレベルチェッカ(PD-817)の
 [LEADING (A/B)] キーを押す。
 先行ヘッドのPCM/ATF(Ach, Bch) 記録電流レベルの自動測定
 (自己記録・再生)が行われる。
- (10) 自動測定終了後([LEADING]キーのインジケータが点滅から点灯に変わる)、記録レベルがRFレベルチェッカのレベルメータに表示される。記録レベルが規格を満足するように手順(8), (9), (10)を繰り返し行う。
- (i1) FI (TEST OFF)キーを押す。 自動的にテストテープ(TY-30BX)がイジェクトされる。

規格: PCM-AおよびPCM-Bの記録レベル=0.5±0.5 dB ATF-AおよびATF-Bの記録レベル=-0.5±0.5 dB RFレベルチェッカのレベルメータ表示



調整: 「1、 」 キーで、規格外の項目を選択し、 F6 および F7 キーで以下のように調整する。 記録レベルを上げるには F6 (UP) キーを押す。 記録レベルを下げるには F7 (DOWN)キーを押す

*1: オフセットダイヤルの設定


使用するテストテープ (TY-7111DX) に添付の校正値表に従って、1.57 MHz, 130 kHz の Ach/Bch の校正値を RF LEVEL CHECKER のオフセットダイヤルで設定する。

設定例

校正値表の表示

	130.7(kHz)	1.568(MHz)
Ach	-0.1	-0.3
Bch	+0.2	+0.2

オフセットダイヤルの設定(上記の校正値の場合)



16. REC CURRENT ADJUSTMENT (TRILING) (16. 記録レベル調整 (後行ヘッド))

使用機器、治工具

オシロスコープ RF レベルチェッカ PD-817 RF レベルチェッカ 用 I/F ボックス PF-534

使用テストテープ

テストテープ TY-30BX テストテープ TY-7111DX

接続


"15. REC CURRENT ADJUSTMENT (LEADING) " に同じ

手順	調整/確認/規格					
(1) [↑、↓ キーで、"16. REC CURRENT ADJUSTMENT (TRAILING)"を選択す	ELディスプレイ画面					
3.	RECORDER ADJUSTMENT	16. REC CURRENT ADJUSTMENT (TRAILING)				
(2) FI (TEST ON) キーを押す。	REC CURRENT PCM-A REC CURRENT PCM-B REC CURRENT ATF-A REC CURRENT ATF-B	XX XX XX XX				
(3) テストテープ (TY-7111DX) を挿入す	RECORDER: REC	TIME CODE: 00: 10: 58: 40				
る。	TEST OFF					
(4) テストテープ(TY-7111DX)に添付されて いる校正値表に従って、校正値をRFレベ ルチェッカ(PD-817)のオフセットダイヤ	F1 F2 F3	F4 F5 F6 F7				
ルで設定する。* (4-25 ページ参照)	•					
(5) PLAY キーを押す。 RF波形 (オンロスコープ) が安定することを確 認する。						
(6) RFレベルチェッカ (PD-817) の CAL キー を押す。						
(7) CAL終了後、RFレベルチェッカ (PD- 817) の CAL キーのLEDが点滅から点灯	`					
に変わったら、EJECTキーを押して、						

- (8) テストテープ (TY-30BX、ブランク部分) を挿入する。
- (9) RFレベルチェッカ (PD-817) の TRAILING (A/B) キーを押す。後行 ヘッドのPCM/ATF (Ach, Bch) 記録電流 レベルの自動測定 (自己記録・再生) が 行われる。
- (10) 自動測定終了後(TRILING)キーのインジケータが点滅から点灯に変わる)、記録レベルがRFレベルチェッカのレベルメータに表示される。記録レベルが規格を満足するように手順(8)、(9)、(10)を繰り返し行う。
- (11) FI (TEST OFF) キーを押す。自動的に テストテープ (TY-30BX) がイジェクト される。

規格;PCM-AおよびPCM-Bの記録レベル=0.5±0.5 dB ATF-AおよびATF-Bの記録レベル=-0.5±0.5 dB

RFレベルチェッカのレベルメータ表示



調整; ↑ 、 ↓ キーで規格外の項目を選択し、 F6 および F7 キーで以下のように調整する。 記録レベルを上げるには F6 (UP) キーを押す。 記録レベルを下げるには F7 (DOWN) キーを押す。

17. REC/PB ERROR RATE CHECK (17. 自己記録再生エラーレート確認))

使用機器、治工具;使用せず

使用テストテープ;テストテープ TY-30BX

注意: 1. REC/PB ERROR RATE 測定は、必ず PCM-E7700 に天板を取り付けて行う。 2. 確認を行う前に、クリーニングテープを使用して、クリーニングを行う。

手順					整/確認/#	-B+47		
(1) 1 *-で "17. REC/PB ERROR	F1 =	ディスプレイ菌	र स्था		132/1636/7	死 作		
RATE CHECK"を選択する。	EL7	1 \ / \ / \ /	TAT					
AATE CHECK E.EV. 7 %		RECORDER	ADJUSTM	ENT	17. REC/PB	ERROR RAT	ге снеск	
(2) FI (TEST ON) キーを押す。		REC S	PEED		X1			
(3) テストテープ (TY-30BX) を挿入する。		REC H	EAD		LEADING			
(A) T-T-0 "PROVIDED IN 1911 A 1911		ERROR (TRAIL			A-CH X. XE- B-CH X. XE-			
(4) 画面の "REC HEAD LEADING"を確認 する。		RECORDER			TIME CODE		: 58 : 40	
		TEST OFF		SPEED	HEAD			
		F1	F2	F3	F4	F 5	F 6	F7
(5) PLAYキーを押す。	規格	エラーレー	⊦ A-CH=	=5E-3 (画面	表示)			
(6) AUTO EDIT キーを押し、先行記録 (X1)				(5×10 ⁻³)	以下)			
中の後行再生エラーレートが規格を満			B-CH=	=5E-3 (画面	ī表示)			
足することを確認する。				(5×10 ⁻³ J	以下)			
(7) STOP キーを押す。	·							
(8) F4 (HEAD) キーを押す。画面の "REC				•				
HEAD TRAILING"を確認する。								
(9) PLAY キーを押す。								
(10) AUTO EDIT キーを押し、20秒間記録す る。								
(11)STOPキーを押す。				3				
(12)SHUTTLE(-2) ([4] キー)を押し				•				
て、記録開始部分まで巻き戻す。								
注意;巻き戻しは、ディスプレイ画面								
のTIME CODE を目安に行う。								
(13)PLAYキーを押して、後行記録部分を	規格	;エラーレー	ŀ A-CH=	-5E-3 (画面	ī表示)			
再生し、再生エラーレートが規格を満				(5×1	10-3以下)			
足することを確認する。			B-CH=	=5E-3 (画面	表示)			
				(5×1	10-3以下)			
(14) <mark>STOP</mark> キーを押す。								
(15)FI (TEST OFF) キーを押す。								
自動的にテストテープ (TY-30BX) がイ								
ジェクトされる。	<u> </u>							

18. SERVO DATA SAVE (18. サーボデータセーブ)

使用機器、治工具;使用せず 使用テストテープ;使用せず

手順	確認
(I) SV-147A基板 (PCM-7040メカデッキ ASSY) のS1-2 (BIT SW2) スイッチを "ON" にし、ディスプレイ画面 (調整 項目表示画面) の右上で確認する。	
(2) 「↑、「↓キーで"18. SERVO DATA SAVE"を選択する。	ELディスプレイ画面 RECORDER ADJUSTMENT 18. SERVO DATA SAVE
 (3) [FI] (TEST ON) キーを押す。 ディスプレイ画面のMESSAGE; "SAVING IS COMPLETED!" を確認する。 (4) 確認後、[FI] (TEST OFF) キーを押す。 (5) SV-147A基板 (PCM-7040メカデッキASSY) のS1スイッチを以下のように設定する。 	SWP POSITION = 117 (75H)
SI-1 to S1-4:すべてOFF	SAVING IS COMPLETED! RECORDER: NO TAPE TEST OFF
	F1 F2 F3 F4 F5 F6 F7

19. SERVO DATA DISPLAY (19. サーボデータディスプレイ)

使用機器、治工具;使用せず 使用テストテープ;使用せず

注意: サーボデータディスプレイは、サーボデータの確認などに使うモードである。 調整中にサーボデータディスプレイを実行することによりその調整値を確認することができる。

手順		確認	
(i) †、↓キーで"19. SERVO DATA DISPLAY"を選択する。	ELディスプレイ画面 RECORDER ADJUSTMENT	19. SERVO DISPLAY	
(2) F1 (TEST ON) キーを押す。(3) ディスプレイ画面上のサーボデータを確認する。	FWD TORQ T = 14 (0EH) FWD TORQ S = 128 (80H) REV TORQ T = 65 (41H) REV TORQ S = 138 (84H) BACK TENTION = 56 (38H)	EQ-P-X1 = 44 (2CH) REC-L-ATFB1 = 16 (10H) EQ-L-X2 = 21 (15H) REC-T-PCMA1 = 217 (D9H) EQ-H-X2 = 44 (2CH) REC-T-PCMB1 = 217 (D9H)	
(4) F2 (EXIT) キーを押す		EQ-Q-X2 = 37 (25H) REC-T-ATFA1 = 16 (10H) EQ-P-X2 = 21 (15H) REC-T-ATFB1 = 16 (10H)	
	F1 F2 F3	F4 F5 F6 F7	

4-2-3、SV-147A 基板交換時の確認

メカデッキASSYのSV-147A基板を交換した際、交換後、メカデッキASSYの調整および確認を行う前にサーボマイコン動作確認を必ず行う。

使用機器、治工具

使用せず

使用テストテープ

空カセット (「4-2-1. 準備」参照)

サーボマイコン動作確認

- SV-147A 基板 (PCM-7040 メカデッキ ASSY) の BIT スイッチ (S1-3) を ON にする。
- (2) PCM-E7700の電源 (POWER) を ON にする。
- (3) SV-147A基板のLED (D1) が、1秒周期で点滅している ことを確認する。
- (4) 空カセットを挿入し、SV-147A基板のBITスイッチ (S1-1) をONにする。
- (5) 空カセットがイジェクトされることを確認し、BIT スイッチ (S1-1) を OFF にする。

以上の確認終了後、「42. 調整および確認」に従って調整、確認を行う。

第5章電気調整

本章では修理および保守を行った際に必要な SSP-11 基板の 下記電気調整について述べます。

SSP-11 基板調整項目

5-2. 信号処理系調整

5-2-1. マスタークロック調整

5-2-2. タイマークロック調整

5-2-3. RF PLL調整

53. AD/DA 系調整

5-3-1. AD 変換レベル調整

5-3-2. DA 変換レベル調整

5-3-3. C.M.R.R 調整

5-3-4. 出力バランス調整

54. タイムコード出力レベル調整

5-1. 準備

5-1-1. 使用機器

名 称	主な仕様	機器名
オシロスコープ	周波数:DC to 150 MHz 2現象以上(ADD モード)	TEKTRONIX 2445A または相当品
オーディオアナライザ	・AFオシレータ レンジ:10 to 100 kHz レベル:-70 to +24 dBm ・レベルメータ	TEKTRONIX SG505 (0P2), AA501 または相当品
周波数カウンタ	有効桁数:8 桁以上	ADVAN TEST TR5822, HEWLETT PACKARD 5315A または相当品

5-1-2. スイッチ,コントロール初期設定

フロントパネル

スイッチ

REMOTE (9P) /LOCAL ; LOCAL SYNC EXT/INT/VIDEO ; INT AUDIO INPUT ANALOG/DIGITAL ; ANALOG

SAMPLING FREQ 44.1 kHz/48 kHz

: 48 kHz

コントロール

ANALOG CH-1 入力レベル; センタークリック位置 ANALOG CH-2 入力レベル; センタークリック位置

SSP-11 基板

AD/DA ブロック

S51 スイッチ; NORMAL

S101 スイッチ; +4 S201 スイッチ; +4 S102 スイッチ; +4 S202 スイッチ; +4

CPU-268 基板

5-2. 信号処理系調整

調整は、天板を外して行う。

5-2-1. マスタークロック調整


ここでは、マスタークロックブロックの Fs 系システムクロックを発生する水晶振動子の発振周波数の確認および調整を行う。

調整は、SSP-11基板およびマスタークロックブロックの部品 (X401, 402, CT401, 402 およびその周辺回路) を交換した際 に行う。

使用機器

周波数カウンタ

接続




スイッチ、コントロール設定

下記設定以外は「5-1-2. スイッチ, コントロール初期設定」に同じ

フロントパネル

REMOTE (9P) /LOCAL スイッチ ; LOCAL SYNC EXT/INT/VIDEO スイッチ ; INT SAMPLING FREQ 44.1 kHz/48 kHz スイッチ ; 48 kHz

調整箇所



調整手順

調整時の状態	規 格	調整箇所 (SSP-11 基板)	
ステップ1 ・リアパネルの各コネクタ接続を無接続にする ・周波数カウンタを TP50 (C5) /SSP-11 基板に 接続する ・SAMPLING FREQ スイッチ (フロントパネル):48 kHz	・TP50 (C5) の周波数が下記規格 (47999.76~48000.24 Hz) を満足していることを確認する。満足していない場合 ©CT401 (C4) を調整して規格を満足させる。 規格 (TP50の周波数) Fs (48 kHz) = 48000.00±0.24 Hz	⊘ CT401 (C4)	
ステップ2 ・SAMPLING FREQ スイッチ (フロントパネル): 44.1 kHz ・他はステップ 1 に同じ	・TP50 (C5) の周波数が下記規格 (44099.78~44100.22 Hz) を満足していることを確認する。 満足していない場合 ©CT402 (D4) を調整して規格を満足させる。 規格 (TP50の周波数) Fs (44.1 kHz) = 44100.00±0.22 Hz	⊘ CT402 (D4)	

5-2-2. タイマクロック調整

この調整は、SSP-11基板およびタイマクロックブロックの部品 (X304, CT301およびその周辺回路) を交換した際に行う。


使用機器

周波数カウンタ

スイッチ、コントロール設定

スイッチ、コントロール設定は必要なし

接続/調整箇所



調整手順

調整時の状態	規 格	調整箇所 (SSP-11 基板)	
- 周波数カウンタをTP36 (C2) /SSP-11基板に接続する。	・TP36 (C2) の周波数が下記規格 (2047.99~ 2048.01 Hz) を満足していることを確認する。 満足していない場合、⊘CT301 (C2) を調整して、 規格を満足させる。	⊘ CT301 (C2)	
	規格 TP36の周波数= 2048.00±0.01 Hz	·	

5-2-3. RF PLL調整

RF PLL ブロックでは、HEAD からの再生データを抜き取る 為のCLOCK を生成している。HEAD/RF アンプの特性に応 じて、最良のエラーレートが得られる様調整する。この調整 は、SSP-11基板およびRF PLLブロックの部品を交換した際、 また、メカデッキ ASSY、DRUM ASSY および RF ASSY を交 換した際に行う。


準備

SSP-11 基板上のコネクタピン COR401 (D6)、COR402 (D6) よりコネクションプラグ COP401、COP402 を抜く。 (調整箇所の項参照) (RF PLL調整後は、COP401、COP402 を挿入すること)

使用機器

オシロスコープ 音楽記録済カセットテープ(Fs = 48 kHz)

接続




スイッチ、コントロールの設定

下記設定以外は「5-1-2. スイッチ, コントロール初期設定」に同じ

フロントパネル

REMOTE (9P) / LOCAL スイッチ ; LOCAL SYNC EXT/INT/VIDEO スイッチ ; INT SAMPLING FREQ 44.1 kHz/48 kHz スイッチ ; 48 kHz

調整箇所



1. 先行ヘッド RF PLL調整

調整時の状態	規 格	調整箇所(SSP-11 基板)
ステップ1 ・オシロスコープを SSP-11 基板の下記箇所に接続する オシロスコープ SSP-11 基板	TP53(D6) 出力波形 OK	●RV402(D6) NG 波形の場合は ●RV401を 少 し回 して か ら 、 再度 ●RV402を調整する。
ステップ2 ステップ1に同じ	TP53(D6) 出力波形 平らにする TRIG: TP512(A3)	ØRV401(C6)
ステップ3 ステップ1に同じ	TP53(D6) 出力波形 -2.6±0.5 V RF の有る部分の振幅のセンター電圧 TRIG: TP512(A3)	②LV402(C6) 注意: ②LV402 は 時 計 方 向 いっぱいより 1 回転分 ゆるめんる範囲 がでく とっぱい しいっざるとコアが破損し、ゆるめするとコア部が外れることがあります。
ステップ4 ・音楽記録済カセットテープ (Fs=48 kHz) を装着して、CUE FWD (16 倍速モード) にする。 ・接続はステップ 1 に同じ	TP53(D6) 出力波形 平たんになるようにする。 TRIG: TP512(A3)	⊘ RV402(D6)
ステップ5 ・音楽記録済カセットテープ (Fs=48 kHz) を装 着して、CUE REV(16 倍速モード)にする。 ・接続はステップ 1 に同じ	TP53(D6) 出力波形 平たんになるようにする。 TRIG: TP512(A3)	⊘ RV402(D6)
ステップ6 ・音楽記録済カセットテープ (Fs=48 kHz) を装着して、CUE FWD および CUE REV (3 倍速モード) を 2〜3 回繰り返す。 ・接続はステップ 1 に同じ	TP53(D6) 出力波形 テープ走行中平らなこと。 TRIG: TP512(A3)	

2. 後行ヘッド RF PLL 調整

調整時の状態	規 格	調整箇所(SSP-11 基板)
ステップ 1 ・ オシロスコープを SSP-11 基板の下記箇所に接続する オシロスコープ SSP-11 基板	TP55(D6) 出力液形 OK NG NG TRIG: TP512(A3)	●RV404(D6) NG 波形の場合は ●RV403 を 少 し回 して か ら 、 再 度 ●RV404 を調整する。
ステップ2 ステップ1に同じ	TP55(D6) 出力波形 平らにする TRIG: TP512(A3)	⊘RV403(C6)
ステップ3 ステップ1に同じ	TP55(D6) 出力波形 -3.0±0.5 V RF の有る部分の振幅のセンター電圧	②LV403(C6) 注意:②LV403 は 時 計 方 向 いっぱいより 1 回転分 ゆるめられる範囲内で 調整を行ってくださ い。しめすぎるとコア が破損し、ゆるめすぎ るとコア部が外れるこ
ステップ4 ・音楽記録済カセットテープ (Fs = 48 kHz) を装着して、CUE FWD(16 倍速モード)にする。 ・接続はステップ 1 に同じ	TRIG: TP512(A3) TP55(D6) 出力波形 平たんになるようにする。 TRIG: TP512(A3)	とがあります。 ●RV404(D6)
ステップ5 ・ 音楽記録済カセットテープ (Fs=48 kHz) を装着して、CUE REV (16 倍速モード) にする。 ・ 接続はステップ1に同じ	TP55(D6) 出力波形 平たんになるようにする。 TRIG: TP512(A3)	⊘ RV404(D6)
ステップ6 ・ 音楽記録済カセットテープ (Fs = 48 kHz) を装着して、CUE FWD および CUE REV (3 倍速モード) を 2-3 回繰り返す。 ・ 接続はステップ 1 に同じ	TP55(D6) 出力波形 テープ走行中平らなこと。 TRIG: TP512(A3)	

3. RF PLL 微調整および確認


準備: この調整に入る前に電源 (POWER) スイッチを OFFにして、先に外したコネクションプラグ COP401、COP402 をコネクタピン COR401、COR402 に差し込む。挿入後、電源 (POWER) スイッチを ON にして調整を行う。

調整時の状態	規 格	調整箇所(SSP-11 基板)
ステップ 1 ・オシロスコープを SSP-11 基板の下記箇所に接 続する	TP55(D6) 出力波形	●LV401(D5) ●LV401は無信号部のセン
オシロスコープ SSP-11 基板 CH1 → TP55(D6) CH2 → TP512(A3)		ターがほぼ平らになる様に調整する。センターが平らにならない場合は、「2.後行 RF PLL調整」のステップ3から6
(TRIGGER) ・音楽記録済カセットテープ (Fs=48kHz) を装着して、再生する。(PLAY モード)	無信号部 RF部	までの調整をやり直す。再調整 整開始時に「2.後行RFPLL制整」のステップ3の調整規格 値の範囲でセンター電圧値を ずらしてから再調整する。
	TRIG : TP512(A3)	注意: OLV401 は 時 計 方 方 的 いっぱいより 1 回転で
ステップ2	TP53(D6) 出力波形	⊘ LV402(C6)
・オシロスコープを SSP-11 基板の下記箇所に接 統する。 オシロスコープ SSP-11 基板	無信号部 RF部	○LV402 は無信号部のセンターがほぼ平らになる様に調整する。センターが平らになる
CH1 → TP53(D6) CH2 → TP512(A3) (TRIGGER) 音楽記録済カセットテープ (Fs=48 kHz) を装着して再生する。(PLAY モード)		らない場合は、「1.先行 RI PLL調整」のステップ3から までの調整をやり直す。再調 整開始時に「1.先行 RF PLL 整」のステップ3の調整規格 値の範囲でセンター電圧値を ずらしてから再調整する。
		注意: ②LV402 は 時 計 方向 いっぱいより 1 回転が ゆるめられる範囲で言 整を行って下さい。し めすぎるとコアが破れ し、ゆるめすぎると ア部が外れることがあ
	TRIG : TP512(A3)	ります。
ステップ3 ・オシロスコープを SSP-11 基板の下記箇所に接 統する。 オシロスコープ SSP-11 基板 CH1 → TP53(D6), TP55(D6) CH2 → TP512(A3)	TP53(D6) , TP55(D6) 出力液形	
(TRIGGER) ・音楽記録済カセットテープ (Fs=48kHz) を装着して FF および REW モードにする。(PLAY		
	電圧が大きく(+)へ揺れる。 TRIG: TP512(A3)	

5-3. A/D, D/A 系調整

この調整は天板を外して行う。 調整は、下記調整手順に従って行う。


A/D, D/A 系調整手順



使用機器

オーディオアナライザ オシロスコープ

接続



スイッチ、コントロールの設定

下記設定以外は [5-1-2. スイッチ, コントロール初期設定] に同じ

フロントパネル

SAMPLING FREQ 44.1kHz/48kHz スイッチ ; 48 kHz AUDIO INPUT ANALOG/DIGITAL スイッチ ; ANALOG ANALOG CH-1 入力レベルコントロール

;クリックセンター位置

ANALOG CH-2 入力レベルコントロール

; クリックセンター位置

INPUT MONITOR +-

; ON (LED 点灯)

SSP-11 基板 (A/D, D/A ブロック)

S101, S102, S201, S202 スイッチ

; +4 側

S151 スイッチ


; NORMAL

CP-268 基板

S11, S21 スイッチ

; ON (600Ω) 側

調整箇所



5-3-1. A/D 変換レベル調整

SSP-11基板のA/Dブロックの電気調整を行う。

準備

調整を行う前に前面パネルのFL管ディスプレイ表示を下記 のように設定する。設定方法は、OPERATION MANUALを 参照。

FL管ディスプレイ表示 (フロントパネル) Au-rEF (入力信号レベルのデジタル値表示モード)

EMPH OFF (エンファシス OFF モード)

調整時の状態	規 格	調整箇所(SSP-11 基板)	
ステップ1	FL管ディスプレイの Au-rEF CH1 (左側) の数値	●RV102(F5)	
・ANALOG IN CH-1 コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の信号をオーディオア ナライザ(AF オシレータ)より入力する。	20.0 dB		
ステップ2	FL 管ディスプレイの Au-rEF CH2 (右側) の数値	⊘RV202(E6)	
 ANALOG IN CH-2 コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の信号をオーディオアナライザ (AF オシレータ) より入力する。 	-20.0 dB		

5-3-2. D/A 変換レベル調整

SSP-11基板のD/Aブロックの電気調整を行う。この調整は、「5-3-1. AD変換レベル調整」の後、引き続き行う。

調整時の状態	規 格	調整箇所(SSP-11 基板)
ステップ1 ・ANALOGIN CH-1 コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の信号をオーディオアナラ	ANALOG OUTPUT CH-1 出力レベル: + 4.0 dBs ± 0.1 dB	◆RV103(F4)
イザ (AFオシレータ) より入力する。	↑ 4.0 dbs ± 0.1 db	
・ANALOG OUTPUT CH-1 コネクタにオーディ オアナライザ(レベルメータ)を接続する。		
ステップ2	ANALOG OUTPUT CH-2 出力レベル:	⊘RV203(E4)
 ANALOG IN CH-2コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の信号をオーディオアナライザ (AF オシレータ) より入力する。 	$+ 4.0 \text{ dBs} \pm 0.1 \text{ dB}$	
・ANALOG OUTPUT CH-2 コネクタにオーディ オアナライザ(レベルメータ)を接続する。	3	

5-3-3. C.M.R.R 調整


FL管ディスプレイ表示(フロントパネル)の設定 Au-rEF(入力信号レベルのデジタル値表示モード)

調整手順

調整時の状態	規 格	調整箇所(SSP-11 基板)	
ステップ 1 ・ANALOG IN CH-1 コネクタに 1 kHz、+4 dBs	ANALOG OUTPUT CH-1 出力レベル:	⊘RV101(F6)	
(0 dBs = 0.775 Vrms) の同相信号をオーディオ アナライザ(AF オシレータ)より入力する。	-56 dBs 以下		
信号はCH-1コネクタのHOT, COLD (2ピンと 3ピンにパラレル入力)とGND (1ピン)間に 入力する。	・この時、FL管ディスプレイのAu-rEF(左側)の数値が「5-3-1.AD変換レベル調整」の規格値を満足していることを確認する。		
・ANALOG OUTPUT CH-1 コネクタにオーディ オアナライザ(レベルメータ)を接続する。	満足していない場合は、再度「5-3-1. AD 変換レベル調整」のステップ 1 を行い、規格を満足させる。		
ステップ2	ANALOG OUTPUT CH-2出力レベル:	●RV201(E6)	
・ANALOG IN CH-2 コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の同相信号をオーディオ	-56 dBs以下		
アナライザ(AFオシレータ)より入力する。 信号は CH-2コネクタの HOT, COLD (2 ピンと 3 ピンにパラレル入力) と GND (1 ピン) 間に 入力する。	- この時、FL管ディスプレイのAu-rEF (右側) の数値が「5-3-1.AD変換レベル調整」の規格値を満足していることを確認する。		
・ANALOG OUTPUT CH-2 コネクタにオーディ オアナライザ(レベルメータ)を接続する。	満足していない場合は、再度 [5-3-1.AD 変換レベル 調整] のステップ 2 を行い、規格を満足させる。		

5-3-4. 出力バランス調整

接続



調整手順

調整時の状態	規 格	調整箇所(SSP-11 基板)
ステップ1 ・ANALOG INPUT CH-1 コネクタに 1 kHz、 +4 dBs (0 dBs = 0.775 Vrms) の信号を入力する。 ・ANALOG OUTPUT CH-1 コネクタにオシロスコープを下記のように接続する。 オシロスコープ ANALOG OUTPUT CH-1 コネクタ CH1 → 2 ピン、1 ピン(GND) CH2 → 3 ピン、1 ピン(GND)	ANALOG OUTPUT CH-1の ⊕ (2 ピン)、 ⊝ (3 ピン) 間の出力パランス: 1%以内* 調整方法 オシロスコープ CH1 オシロスコープ CH2 ADD モード ON 加算波形のレベルが 34.6 mVp-p 以下になるように ②RV105 を調整する。	●RV105(F3)
ステップ2 ・ANALOG INPUT CH-2 コネクタに 1 kHz、+4 dBs (0 dBs = 0.775 Vrms) の信号を入力する。 ・ANALOG OUTPUT CH-2 コネクタにオシロスコープを下記のように接続する。 オシロスコープ ANALOG OUTPUT CH-2 コネクタ CH-2 コネクタ CH-2 コネクタ CH-2 コネクタ CH-2 コスクタ	ANALOG OUTPUT CH-2の ⊕ (2ピン)、 ⊕ (3ピン) 同の出力パランス: 1%以内* 調整方法 オシロスコープ CH1 オシロスコープ CH2 ADD モード ON 加算液形のレベルが 34.6 mVp-p以下になるように ②RV205 を調整する。	⊘ RV205(E3)

*: ANALOG OUTPUT⊕, ○ 間出力バランス 1 %とは、加算前のレベルが 3.46 Vp-p (+4 dBs) の時、加算後のレベルが 34.6 mVp-p 以下のことです。

5-4. タイムコード出力レベル調整

この調整は天板を外して行う。


調整は、SSP-11基板およびTCブロックの部品を交換した際に行う。また、タイムコード出力レベルを変更したい時に、行う。

使用機器、治工具

オシロスコープ タイムコード出力に接続される機器


タイムコード記録済カセットテープ XLR 3PIN (メス) コネクタ 10 kΩ 1/4W 抵抗

調整箇所



スイッチ, コントロール設定 [5-1-2. スイッチ, コントロール初期設定] に同じ

接続



調整手順

調整時の状態	規∴格	調整箇所(SSP-11 基板)	
・TIME CODE OUTPUT(リアパネル)に 10 kΩ ダミー負荷(接続図参照)または、タイムコー ド出力を使用する機器を接続する。	オシロスコープCH-1 オシロスコープCH-2; INVERT ADDモード	●RV701(F3)	
・ オシロスコープを下記箇所に接続する。 オシロスコープ 接続先 CH1 → TC OUT コネクタ、2番ピン (CPU-268 基板) E3(A2) , GND(SSP-11 基板) CH2 → TC OUT コネクタ、3番ピン (CPU-268 基板) E3(A2) , GND(SSP-11 基板) ・ タイムコード記録済カセットテープを装着して、再生する。(PLAYモード)	A=2.4 Vp-p ・タイムコード出力レベルを変更する場合は、上記Aの電圧が所望の電圧になるように ●RV701 を調整する。		

Section 1 Installation

1-1. Installation Environment

Operating temperature : 10°C to 35°C (performance guaranteed)

5°C to 40°C (operation guaranteed)

Storage temperature

: -20°C to 55°C (without condensation)

Mass

: Approx. 10 kg

Installation precautions: • Locations subject to many hours of direct sun light or strong light

· Locations subject to many dusty and severe vibrations

· Locations subject to strong electric or magnetic

· Locations close to heat sources

· Locations subject to electric noise

· Locations subject to electrostatic noise

1-2. Power Requirements

1-2-1. AC Power Supply

· Power supply voltage:

The power supply voltage has already been set to the voltage setting suited for each destination before shipment from the

The power supply voltage setting is performed by inserting the shorting plug to CN1, CN2 or CN3 connector on the PS-451 board in the primary circuit of the power transformer.

The power fuse (F1 on the SSP-11 board) of the appropriate type is installed corresponding to the above described setting.

Power supply voltage	Insert the shorting plug into	Rating of Fuse (F1 on the SSP-11 board)	Destination
100 V AC	CN1	2 A, 125 V	J
120 V AC	CN2	2 A, 125 V	UC
230 (220 to 240) V AC	CN3	1 A, 250 V	CE

Power line frequency

: 50/60 Hz (For J, CE)


50 Hz (For UC)

• Power/current consumption : 37 W at AC 100 V (For J)


38 W at AC 120 V (For UC) 0.3 A at AC 230 V (For CE)

1-2-2. Power cord


· For J




• For UC



• For CE



1-3. Dimensions



1-4. Rack Mounting

PCM-7040 can be mounted in a standard 19 inch rack. Be sure to use the optional rack mount rail RMM-30 and rack mount adaptor RMM-31.


Requied parts

- Rack mount rail RMM-30 (optional) : 1
 (Rail with bracket; 2, Screw B5 × 8; 8, Plate nut M4; 2, Screw PWH4 × 10; 2)
- Rack mount adaptor RMM-31 (optional): 1 (Handle; 2, Screw B4 × 14; 4, Washer; 4, Screw RK5 × 10; 4)
- Screw (B4 × 10) * : 4 (for inner member attaching)
- *: PCM-7040 comes with the four screws.

Cautions


When mounting the PCM-7040 into the rack, it is suggested to have a minimum 2 persons to install the unit.

- (1) If the PCM-7040 or a peripheral equipment is mounted in a 19 inch standard rack, it is recommended to install a ventilation fan to prevent a temperature bring-up in the rack. Make sure that all the units in the rack can be operated within the temperature range of 10°C to 35°C.
- (2) Be sure to use the recommended rail when rack mounting. The unit cannot be installed completely to a rack by rack mount adaptor alone.
- (3) It is recommended to fix the rack to the floor with bolts. When the unit is pulled out from the rack, this will prevent its fall.



How to install

(1) Remove four feet from the bottom of the unit.




(2) Install the rack mounting rail and rack mount adaptor. For details, refer to INSTALLATION MANUAL packed with the rack mounting rail RMM-30 and rack mount adaptor RMM-31.

Note

Attach the inner members to the PCM-7040 using four screws ($B4 \times 10$).

 Maximum movable length of the PCM-7040 is as follows.




1-5. Connection Connectors/Cables

For the connectors/cables to be connected to the connectors of rear panel, use the following or their equivalent.

PCM-7040 rear panel		Suitable connector/cable	
Used for	Name	Name	Sony Part mumber
ANALOG INPUT CH1/CH2	XLR 3P, FEMALE (UC,CE)	XLR 3P, MALE (UC, CE)	1-508-084-11 (CANNON XLR-3-12C or equivalent)
	XLR 3P, MALÉ (J)	XLR 3P, FEMALE (J)	1-508-083-11 (CANNON XLR-3-11C or equivalent)
ANALOG OUTPUT CN1/CH2	XLR 3P, MALE (UC,CE)	XLR 3P, FEMALE (UC, CE)	1-508-083-11 (CANNON XLR-3-11C or equivalent)
	XLR 3P, FEMALE (J)	XLR 3P, MALE (J)	1-508-084-11 (CANNON XLR-3-12C or equivalent)
DIGITAL INPUT	XLR 3P, FEMALE	ECD-3C/10C/30C (3m, 10m, 30m)	Optional accessory
DIGITAL OUTPUT	XLR 3P, MALE	ECD-3C/10C/30C (3m, 10m, 30m)	Optional accessory
TIME CODE INPUT	XLR 3P, FEMALE (UC,CE)	XLR 3P, MALE (UC,CE)	1-508-084-11 (CANNON XLR-3-12C or equivalent)
	XLR 3P, MALE (J)	XLR 3P, FEMALE (J)	1-508-083-11 (CANNON XLR-3-11C or equivalent)
TIME CODE OUTPUT	XLR 3P, MALE (UC, CE)	XLR 3P, FEMALE (UC, CE)	1-508-083-11 (CANNON XLR-3-11C or equivalent)
	XLR 3P, FEMALE (J)	XLR 3P, MALE (J)	1-508-084-11 (CANNON XLR-3-12C or equivalent)
REF VIDEO INPUT	BNC	BNC, PLUG	_
WORD SYNC INPUT/OUTPUT	BNC	BNC, PLUG	_
MONITOR CH-1/CH-2	PIN, JACK	PIN, PLUG	_
REMOTE (37PIN)	D-SUB 37P, FEMALE	D-SUB 37P, MALE	1-566-357-11 (connector) 1-563-378-11 (shell)
REMOTE (9PIN)	D-SUB 9P, FEMALE	· D-SUB 9P, MALE	1-560-651-00 (connector) 1-561-749-00 (shell)
		• RCC-5G/10G/15G (5m, 10m, 15m)	Optional accessory
RS-232C (25PIN)	D-SUB 25P, FEMALE	· D-SUB 25P, MALE	1-560-904-11 (connector) 1-563-377-11 (shell)
		RS-232C cross cable	
REMOTE (8PIN)	DIN 8P, SOCKET (FEMALE)	DIN 8P, PLUG (MALE)	_

1-6. Switch setting and LED function

SSP-11 board (A side)



LED indicators

D301 (C2) (red)

: CPU initialization indicator Turns on when reset, and turns off

when initialization process is

completed.

D302 (B2) (yellow): EEPROM access indicator

Turns on during data read/write of

EEPROM (IC308).

D303 (A1) (red)

: Backup memory data initialization

indicator

Turns on when backup memory (IC309, IC310) is initilized (cleared).

D304 (A1) (green) : Normal operation indicator

Turns on when when the main CPU

(IC304) operates normally.

D305 (A1) (yellow): Mute indicator

Turns on when the playback audio

signal is muted (in such mode as

STOP).

D306 (A1) (yellow) : DSP output indicator

Turns on when the monitor sound is (any of the following) DSP (IC604)

outputs.

PCM-7040

· The SYNC REC lamp on the front panel turns on. (sync record mode)

 Memory jog, memory rehearsal and memory start play

D307 (A1) (yellow): RMW mode indicator

Turns on when the leading head is playing back and the trailing head is recording (any of the followings).

 The SYNC REC lamp on the front panel turns on. (sync record mode)

· When playing back the wide rack pitch tape.

 When the leading head playback mode is selected by the error rate selection (service menu "rAtE SEL").

D308 (A1) (green): 9-pin CPU interface normal operation

indicator

Turns on when communication between the 9-pin CPU (IC318) and the main CPU (IC304) is establis hed.

1-5(E)

D309 (A1) (red)	: 9-pin data reception (9-pin CPU → main CPU) indicator
	Turns on while the main CPU is
D310 (A1) (green)	receiving data from the 9-pin CPU. : 9-pin data send (9-pin CPU ← main
Do to (A1) (giccii)	CPU) indicator
	Turns on while the main CPU is
D216 (A1) (md)	sending data to the 9-pin CPU.
D316 (A1) (red)	: 9-pin data reception (SCU → 9-pin CPU) indicator
	Turns on while the 9-pin CPU is
	receiving data from the SCU (Serial Control Unit, IC306).
D317 (A1) (green)	: 9-pin data send (SCU ← 9-pin CPU) indicator
	Turns on while the 9-pin CPU is
	sending data to the SCU.
D601 (A3) (red)	: Recorder (playback sound) sound
	memory write indicator
	Turns on while writing data into the
	recorder sound memory.
D602 (A3) (yellow)	: Recorder (playback sound) sound
	memory read indicator
	Turns on while reading data from
D603 (A3) (man)	the recorder sound memory.
D603 (A3) (green)	: Recorder (playback sound) sound
	memory IN-point trigger indicator Turns on when cross-fade is applied
	to the recorder sound memory data
	at IN-point.
D604 (A3) (green)	: Recorder (playback sound) sound
	memory OUT-point trigger indica-
	tor
	Turns on when cross-fade is applied
	to the recorder sound memory data
Door (AD) (B)	at OUT-point.
D605 (A3) (red)	: Player (input sound) sound memory
	write indicator
	Turns on while writing data into the
D606 (A3) (vellow)	player sound memory. : Player (input sound) sound memory
Dood (As) (Jenow)	read indicator
	Turns on while reading data from
	the player sound memory.
D607 (A3) (green)	: Player (input sound) sound memory
- '	IN-point trigger indicator
	Turns on when cross-fade is applied
	to the player sound memory data at
	IN-point.
D608 (A3) (green)	: Player (input sound) sound memory
1-6(E)	OUT-point trigger indicator

Switches

S301 (C2): RESET switch

CPU (IC304) reset switch

S302 (A2): Mode setting

S302-1, 2: Destination setting

S302-1	S302-2	Destination setting	
OFF	OFF	For UC	
ON	OFF	For J	
OFF	ON	For CE	
ON	ON	For UC	

S302-3, 4: Device type setting for 9 PIN

S302-3	3302-3 \$302-4 Device t for 9PIN		
OFF	OFF	PCM-7030 (Factory setting)	
ON	OFF	PCM-7050	
OFF	ON	PCM-7040	
ON	ON	PCM-7040	

S302-5 to -7: Reserved

S302-8 : Backup n

: Backup memory initialization

setting

\$302-8: Backup memory initialization setting	
OFF	Not initialized when the main power is turned on.(Factory setting)
ON	Initialized when the main power is turned on. "-ALL cLEAr-" appears on the display. in the cases as described below, set the destination using S302-1 and -2, then perform initialization. 1. When the SSP-11 board is replaced. 2. When IC309 or IC310 (RAM) on the

When any switch of S302-5 to -7 is set to on, the ALARM indicator on the front panel flashes, and "cAution 1-50" is triggered.

Factory setting

S302-1, -2; Items 1 and 2 are set in accordance with destination.

S302-3 to -8; off

S51 (E5): AD/DA signal path switch

Switch for AD/DA digital audio signal chang-

ing over

S51	Signal path setting
NORMAL	Normal signal path(Factory setting)
TEST	AD converter output is input to the DA converter

PCM-7040


S101 (F6): Input reference signal level (CH-1) switch
S201 (E6): Input reference signal level (CH-2) switch
S102 (F4): Output reference signal level (CH-1) switch
S202 (E4): Output reference signal level (CH-2) switch
Reference signal level (+4 dBs/-20 dBs)
changing switches

S101, S102, S201, S202	Reference signal level setting	
+4 dBs	The +4 dBs input/output signal will be displayed as -20 dB on the level meter (FL display).	
-20 dBs	The -20 dBs input/output signal will be displayed as -20 dB on the level meter (FL display).	
	(0 dBs = 0.775 Vrms)	

When reference level has been changed, adjust the following volumes.

RV102 (F6): Adjustment for input level (CH1) RV202 (E6): Adjustment for input level (CH2) RV103 (F4): Adjustment for output level (CH1) RV203 (E4): Adjustment for output level (CH2)

CP-268 board (A-side)



Switches

S11 (A1): Analog audio (CH-1) input impedance setting switch


Set the CH-1 input impedance.

S21 (A1): Analog audio (CH-2) input impedance setting switch

Set the CH-2 input impedance.

S11, 21	Input impedance setting
OFF	10 kΩ
ON	600 Ω (Factory setting)

SV-147A board (B-side)



Switch

S1 (S1-1 to S1-4); Adjustment Mode Setting Switch
(For details, refer to "Section 4.
Replacement and Adjustment of
Mechanism Deck")

Factory setting

S1-1 to S1-4 ; All OFF (Setting for normal operations)

LED indicators

Lit or off

D1; CPU Operation Indicator
Blinking (Approx.every 1 sec.)

: When operating normally.

Blinking quickly (Approx.every 0.5 sec.)

: When an error is detected.

: When not operating

D2; Adjusting Mode Indicator

Lit : When adjustment mode is ON.

Off : When adjustment mode is OFF.

D3; Servo Lock Indicator

Lit : Locked
Off : Unlocked

1-7. ISR (Interactive Status Reporting)

The PCM-7040 corresponds to a ISR (Interactive Status Reporting) function.

Using this function, the status of the PCM-7040 or the contents of a generated error can be intensively monitored and managed on the monitor screen of a personal computer. The data displayed on the monitor screen can be stored or printed as a file.

The major functions of the PCM-7040 are as follows.

Management functions

· Identification information

Manufacture : SONY

Model

Device ID

: Identification number or identification name within 50 alphanumeric characters.

Serial number: Serial number which is set from the PCM-7040 (service menu).

VM type

: 02 (VTR)

Destination

: Destination UC, J, CE

ROM

: ROM information for main CPU, servo CPU and display CPU (Board name, ROM name, version, board

· Hour meter information

Integrating meter for Operation, Drum Running, Tape Running, Threading Counter

· Upload and download of setup menu data (global setting)

Monitor function

Error/caution message

Indication of the error or caution (warning) number and its meaning. Or indication of error history.

· Signal processing error (Channel Condition) message

Indication of signal processing error. Or indication of error history.

Level:

0: Good

- 1: Correction of certain amount of error or more
- 2: Interpolation
- 4: Mute
- Operation statas

Indication for tape path mode

TAPE UNTHREAD, STOP, STANDBY OFF, PLAY, PLAY LOCK, REC, REC LOCK, EDIT, EDIT LOCK, F.FWD, REW, SHUTTLE STILL, SHUTTLE FWD, SHUTTLE REV, JOG STILL, JOG FWD, JOG REV, VAR STILL, VAR FWD, VAR REV, PREROLL, PREVIEW, AUTO EDIT, CHASE

· Test

Main CPU test, sound memory test

Control function

· Remote control

EJECT, STANDBY ON/OFF, STOP, PLAY, REC, F.FWD, REW, CUEUP(TC LOCATE)

1-8(E)

1-7-1. Connection

1. Set the setup menu "rS-232" (RS-232 MODE) and "bAud rAtE" (BAUD RATE) as follows;

rs-232 : iSr (ISR)

bAud rAtE: Any of 1200, 2400, 4800 or 9600 baud. (9600 baud is recommendation.) Select the same setting as that

of personal computer.

When the RS-232 MODE is set to ISR, parity and data length are fixed to "ODD" and "7" regardless of the settings "PArity" (parity) and "dAtA" (data bits).

2. Connect a personal computer to the RS-232C connector (D-sub 25pin) of the PCM-7040 using a RS-232C cross cable.

1-7-2. Commands

PCM-7040 supports the following commands.

Common Command List


Command from Controller	Response from Device	Remarks
*RST; (Reset)	*ATN: OPC;	
∗IDN?; (Identify Query)	*ATN: QRESP; id-data	
*TST ######; (Test)	*ATN: OPC;	
###### = TEST NUMBER		
*TST?; (Test Query)	*ATN: QRESP; test-result	
	When no test-result *ATN: QRESP; 00Test: 0	
*FLAGS?; (Flag Query)	*ATN: QRESP; flag-data	Power cycled on only
*STATUS?; (Status Query)	*ATN: QRESP; status-data	
*CMDERR?;	*ATN: QRESP; command in error	
(Command Error Query)	->error-code: error-description	
	When no error	
	*ATN: QRESP; 00*CMDERR->No errors in queue	
*MSG? #####; (Message Register Query)	*ATN: QRESP; message-data	
	When no designated number	
##### = REGISTER NUMBER	*ATN: QRESP; 00Not Active	
*UPLOAD? TYPE; (Upload)	*ATN: QRESP; setup-data	TYPE: SETFILE
TYPE = upload data name	·	
*UPLOAD? TYPE, size; (Upload)	*ATN: QRESP; size-data	TYPE: SETFILE
size = option +parameter		

Sony Private Command List

Command from Controller	Response from Device	Remarkes
HRS?; (Hours Meter Query)	*ATN: QRESP; item: value:unit	
HELP: TST?; (Help: Test-menu Query)	*ATN: QRESP; #####: test-description	
RDLOG? TYPE,D; (Read Log Query)	*ATN: QRESP; log-data	TYPE: ERR
TYPE = Log abbreviation D = Direction {F,L}	When no log-data *ATN: QRESP; 00Empty	
CLRLOG TYPE; (Clear Log)	*ATN: OPC;	TYPE: ERR
TYPE = Log abbreviation		
HELP: LOG? (Help: Log-menu Query)	*ATN: QRESP; TYPE: descreption	
DEVID; device-id (Device ID Set)	*ATN: OPC;	Device-id is within 50 alphanumeric characters
DOWNLOAD TYPE; data (Download)	*ATN: OPC;	TYPE: SETFILE
TYPE = download data name		
DOWNLOAD TYPE,place; (Download)	*ATN: OPC;	TYPE: SETFILE
place = Data is input area in device (option)		place: MEM
CHCOND?; (Channel Condition Query)	*ATN: QRESP; channel-condition	
CHCOND:ALRDY?; (Channel Condition: Already Query)	*ATN: QRESP; time-code: channel-condition	
	When no log-data *ATN: QRESP; 00Empty	
RMCTL TYPE; (Remote Control) TYPE = control type	*ATN: OPC;	

Section 2 Service Overview

2-1. Boards Location



① CP-269 : Connector ② CP-268 : Connector

SSP-11 : System Control, Signal Processor
 CN-1487 : Power Relay (secondary side)
 PS-451 : Power Supply (primary side)
 PS-452 : Power Supply (secondary side)


VR-109 : REC Volume
SW-420 : Menu Switch
KY-192 : Display, Key Switch

(1) LED-104 : LED Indicator
(1) HP-48 : Headphones
(2) RF-53 : RF Amplifier
(3) SV-147A : Servo

2-2. Cabinet Removal

Note: Turn OFF the Power switch before removal of cabinet.


Removing Top Plate



Removing Front Panel Assy

Note:

 When removing or attaching the front panel assy, the cassette compartment has finished ejecting or the cassette holder has finished lowering.



2-3. Main Part Replacement


2-3-1. Lythium Battery Replacement

Lythium battery is mounted on the SSP-11 board of the PCM-7040. Replace the battery with the following as shown in the parts list of "Section 6 Spare Parts".

SSP-11 board (Ref. No. BT301): Lythium battery CR2450

Note

The battery is guaranteed for the life of three years under normal condition of usage. Replace the battery as necessary.



Procedure

- (1) Turn ON the power of PCM-7040, and for more than 10 minutes.
- (2) Turn OFF the power of PCM-7040.
- (3) Unsolder the solder bridge from the slit land (SL301) on the SSP-11 board.
- (4) Push the lithium battery (* marked), and remove it in the arrow direction ①.
- (5) Insert a new lithium battery to the battery holder in the arrow direction ②.

Note

Check that the voltage of new lithium battery is more than +2.6 V before the replacement.

(6) Solder (Make a solder bridge) the slit land (SL301).

When performing the solder, be careful not to short-circuit the pins of IC318.

- (7) Turn ON the power of PCM-7040.
- (8) Check that no error message is displayed when started up.


2-3-2. Fuse Replacement

A fuse is mounted on the SSP-11 board.

When replacing the fuse, turn OFF the POWER switch and disconnect the power cord.

Replace the fuse with following as shown in the parts list of "Section 6 Spare Parts".

SSP-11 board (Ref. No. F1): Fuse 2A, 125V (For J, UC) Fuse 1A, 250V (For CE)



2-3-3. SSP-11 Board Replacement

Replace the SSP-11 board as follows:

Procedure

Step 1: Check before replacement

- (1) Record the hours meter information

 Make a note of the following hours meter information:

 "oPE-t", "Hour-t", "run-t", tHrd-no", "A-Hour-t", "A-run-t", "A-run-t" and "A-t Hrd". (Refer to "2-6-4.

 Display menu items" for details.)

 Or alternatively, execute "Print" of the service menu to print out the service information. (Refer to "2-6-3.

 Print menu items" for details.)
- (2) Make a note of the S302 switch setting on the SSP-11 board.

Step 2: SSP-11 board removal

Remove the SSP-11 board from the PCM-7040 referring to "6-2. EXPLODED VIEW".

Step 3: New SSP-11 board attachment

Before attaching the new SSP-11 board, perform the following steps (1) to (3).

- (1) Measure the lithium battery (BT301) voltage. If it is 2.6 V or less, exchange the battery. (Refer to "2-3-1. Lithium battery replacement" for details.)
- (2) Connect the slit land (SL301) by making solder bridge after checking the lithium battery voltage. (Refer to "2-3-1. Lithium battery replacement" for details.)
- (3) Set switch S302 on the SSP-11 board as shown below: S302-1 to -7: Set the switches to the values which were recorded in step 1.

S302-8 : ON (This initializes the backup memory.)

Step 4: Processing after attaching the SSP-11 board

(1) Turn on the main power of the PCM-7000.

Checking:

- 1 The message "-ALLcLEAr-" appears on the display, and that D303 (red) on the SSP-11 board turns on.
- ② The error/caution codes do not appear on the display.
- (2) Set switch S302-8 to "OFF".
- (3) Turn off the main power of the PCM-7040, then turn it back on.

Checking:

- ① D303 (red) is off (does not light).
- ② The error/caution codes do not appear on the display.
- (4) Set the serial number of your PCM-7040. (Refer to the "SEriAL" sub menu in "2-6-6. Preset menu items" for details.)
- (5) Set the hours meter information which was recorded in(1) of step 1.
- (6) Set the date and time. (Execute the setup menu "dAtESEt". Refer to the Operation Manual formuore details:)
- (7) Perform the following items of section "5. ELEC'TRI-CAL ALIGNMENT".
 - 5-2. Signal processing block adjustment
 - 5-3. AD/DA block adjustment
 - 5-4. Timecode output level adjustment

2-4. Removing the Cassette in Emergency

When the power is turned off due to malfunctioning of the mechanism deck assembly or malfunctioning of ejecting operation, remove the cassette inside the mechanism deck in the procedure below.


CAUTION

To protect the tape completely from damage, do not remove the tape from the mechanism deck at this stage of tape removal work.

Instead, remove the tape together with the cassette compartment from the mechanism deck assembly, referring to "6-2. Exploded Views".

How to Remove the Cassette

- (1) Remove the top plate of the main unit. (Refer to "2-2. Cabinet Removal".)
- (2) Disconnect the harnesses (4 parts) from the SSP-11 board.
- (3) Remove the four screws (PWH3 × 6) and remove the mechanism deck assembly from the main unit.



(4) Turn the drive motor rotation gear in the clockwise direction (displayed with "UP" on the SV-147A board) with a small screwdriver through a hole on the bottom side of the MD plate until the threading mechanism is reset. (The cassette moves in the direction to be ejected.)

Note

If the cassette holder is stopped in the middle of descending, turn the drive motor rotation gear in the counterclockwise direction with a small screwdriver until the cassette holder is descended completely. After that turn the drive motor rotation gear in the clockwise direction, and then eject the cassette.


(5) Since the tape has slack when the threading mechanism is reset to the initial position, be sure to take up the slack in tape by repeatedly pressing the ratchet mechanism (see the figure below). (Be sure to perform this operation to prevent the tape damage.)

Note

Be sure to press the ratchet mechanism with confirming the condition of the tape slack.

- (6) Repeat steps (4) and (5) until the cassette comes out enough to remove.

 (Perform until the cassette holder is ascended come.)
 - (Perform until the cassette holder is ascended completely.)



2-5. Errors/Caution Codes

This section described the possible location of defects for the errors/caution codes appearing on the display.

Errors (Error)

Number	Description	Level	Assumed Malfunctioning Parts
1-01	CPU (IC306) address bus error	5	IC306
1-02	CPU (IC306) data bus error	5	IC306
1-03	ROM (IC307) error	5	IC307
1-04	RAM (IC309, IC310) error	5	IC309, 310
1-05	Data in the backup memory (IC309, IC310) is destroyed. If this trouble occurs frequently, exchange of the lithium battery (BT301) is necessary.	5*	
1-06	EEPROM (IC308) data is destroyed.	5*	•
1-07	Backup memory data and EEPROM data are destroyed.	5*	
1-08	EEPROM (IC308) error.	4	IC308
1-09	4.9152 MHz clock is not oscillated.	4	X301, iC301
1-10	interrupt signal error.	5	IC306
1-20	9-pin remote CPU communication error.	4	IC306, IC318
1-21	37-/8-pin remote error.	4	IC306
1-30	Watch IC error.	4	IC314
2-00	Servo CPU communication error.	5	IC306, SV-147A IC9
2-01	Dew condensation. Leave the PCM-7040 until the message disappears with the main power turned on.	5	
2-02	+12 V power supply error.	5	
2-03	Servo CPU (IC9) data bus error.	5	SV-147A IC9
2-10	Servo RAM (IC9) error.	5	SV-147A IC9
2-11	Servo EEPROM (IC12) error.	5	SV-147A IC12
2-20	Couldn't complete the threading motion.	5	
2-21	Reel does not rotate during unthreading motion.	5	
2-22	Couldn't complete the unthreading motion.	5	
2-23	Cassette compartment does not operate.	5	
2-24	Tape guide position is faulty.	5	
2-25	Pinch roller is not pressed.	5	
2-30	Drum does not rotate.	5	
2-31	Drum rotation is too fast.	5	
2-40	Capstan does not rotate.	5	
2-41	Capstan rotation is too fast.	5	
2-50	Takeup reel does not rotate.	5	
2-51	Takeup reel rotation is too fast.	5	
2-52	Supply reel does not rotate.	5	
2-53	Supply reel rotation is too fast.	5	
2-54	Reel brake driving voltage is abnormal.	5	
3-02	SP block data bus error.	5	IC406
3-10	Leading SBSY signal error	5	IC306, 406, 418
			,

 $[\]star :$ The error indication is turned off by pressing the STOP key.

Number	Description	Level	Assumed Malfunctioning Parts
3-11	Trailing SBSY signal error	5	IC306, 406, 432
3-12	DATA frame signal error	5	IC306, 406
3-13	Leading SWP signal	5	IC306, 406
3-14	Leading EXSY signal error		IC306, 406, 418
3-15	Trailing SWP signal error	5	IC306, 406
3-16	Trailing EXSY signal error	5	IC306, 406, 432
3-20	Leading DMA CH-0 error	5	IC306, 418, 418
3-21	Leading DMA CH-1 error	5	IC306, 406, 418
3-22	Trailing DMA CH-2 error	5	IC306, 406, 432
3-23	Trailing DMA CH-3 error	5	IC306, 406, 432
5-02	TC block data bus error	4	IC406
6-01	Memory block for recorder, address bus error	4	IC406
6-02	Memory block for recorder, data bus error	4	IC406
6-04	Sound memory for recorder (IC601) error	4	IC601
7-01	Memory block for player, address bus error	4	IC406
7-02	Memory block for player, data bus error	4	IC406
7-04	Sound memory for player (IC601) error	4	IC601

Cautions (cAution)

Number	Description	Level	Assumed Malfunctioning Parts
1-01	Playback main ID is invalid. Data having the sampling frequency 32 kHz (e. g. LP mode of consumer DAT machine) and the data storage tape cannot be played back.	1	
1-02	Playback sub ID is invalid.	1.	
1-10	Servo unlock occurs during recording and the machine is stopped.	2	4
1-11	An error occurs in the input digital audio signal during recording.	2	
1-12	The non-recorded segment is detected during the INSERT recording and the machine is stopped.	2	
1-20	The machine reaches either tape top or tape end during locating.	2	
1-21	Locating is stopped due to discontinuity of program number.	2	
1-22	Locating is stopped due to discontinuity of time code or that the time code cannot be found.	2	
1-30	Editing is stopped due to discontinuity of time code or that the edit point cannot be found.	2	
1-40	Oscillation of watch clock is stopped. Set the date and time again. When this trouble occurs frequently, the lithium battery (BT301) needs to be exchanged.	2*	
1-50	Abnormal setting of DIP switch on the SSP board. Check setting of S302.	3	S302
2-02	The hours meter (indicating drum rotation time) reaches the periodic inspection timing. Periodic inspection is necessary.	2*	
2-50	Abnormal setting of DIP switch on the SV board. Check setting of S1 on the SV-147A board.	3	SV-147A S1

^{*:} The error indication is turned off by pressing the STOP key.

Level: 2 (caution): Caution code automatic indication
3 (caution): Adjustment mode. ALARM indicator on the front panel flashes.
4 (error): Operation can be continued. ALARM indicator on the front panel turns on.
5 (error): Operation cannot be continued. Error code automatic indication.
ALARM indicator on the front panel turns on.

2-6. Service Menu

The service menu consists of the following sub menus, and is located behind the setup menu.

• Print menu : Outputs the various information from the RS-232C connector.

· Display menu: Indicates the various information.

• Test menu : Executes the various test (self diagnostics).

• Preset menu : Performs settings such as serial number, etc.

1. Service Menu List

(1) Print Menu

Print : PRINT Print data output

(2) Display Menu

[DSPLy] open/close Display menu open/close setting

SoFt : SOFTWARE VERSION Software version

oPE-t : OPERATION TIME Hour meter for operating time

Hour-t : DRUM RUNNING TIME Hour meter for drum running time (reset enable)
run-t : TAPE RUNNING TIME Hour meter for tape running time (reset enable)

tHrd-no : THREAD/UNTHREAD COUNTER Tape threading/unthreading operation meter (reset enable)

A_Hour-t : DRUM RUNNING TIME Hour meter for drum running time
A_run-t : TAPE RUNNING TIME Hour meter for tape running time

A_tHrd : THREAD/UNTHREAD COUNTER Tape threading/unthreading operation meter

----: Separator

Err : ERROR/CAUTION LOG Error/cautio code history
Pb Aud id : PB MAIN ID Playback MAIN ID
Pb Sub id : PB SUB ID Playback SUB ID
Pb Pro-t : PB PRO R-TIME Playback pro R-TIME

Pb Pro-t : PB PRO R-TIME Playback pro R-TIME
tc Sno : TIME CODE MARKER Playback/recording time code marker

Pb Abs-t : PB A-TIME Playback A-TIME
Pb yEAr : PB DATE Playback date
Pb Hour : PB TIME Playback time

tc rdr : TIME CODE READER Time code reader status

dSno : dSNo Time code difference (in units of word)
FS cntr : Fs COUNTER External sync signal frequency counter

FS cntr : Fs COUNTER External sync signal frequency counter

9_6 cntr : 9.6k COUNTER 9.6 kHz signal frequency counter

Pb SPEED: PB SPEED Actual vari speed

rAtE SEL: ERROR RATE SELECT Error rate display selection

Err rAte : ERROR RATE Error rate

FS id : Fs ID Sampling frequency (Fs) ID

EP id : EMPHASIS ID Emphasis ID CoPy id : COPY ID Copy ID

din Err : DIN ERROR Digital input status

Sy diP-S : SYS DIP SWITCH Dip switch S302, SSP-11

Sr diP-S : SV DIP SWITCH Dip switch S1, SV-147A

inPut Au : INPUT AUDIO LEVEL Input audio signal level rEPro Au : REPRO AUDIO LEVEL Playback audio signal level

232 StAt : RS-232C STATUS RS-232C status

----: Separator

(3) Test menu

[tESt] open/close Test menu open/close setting

SyS cPu : SYS CPU TEST Address bus/data bus, RAM, ROM test

diSPLAy : DISPLAY TEST Display/lamp test of front panel

PAnEL-S : PANNEL KEY TEST Key test of front panel

toGGLE-S : TOGGLE SWITCH TEST Toggle switch/dial test of front panel

diAL : DIAL TEST Dial test

37Pin-1 : 37/8pin REMOTE TEST-1 37/8pin remote test
37Pin-2 : 37/8pin REMOTE TEST-2 37/8pin remote automatic test
rS-232 : RS-232C TEST RS-232C remote automatic test

9 Pin : 9pin REMOTE TEST 9pin remote test
Au PAth : AUDIO PATH TEST Audio signal path test

Sound : SOUND MEMORY TEST Sound memory test

----: separator

trnSP-1 : MECHANIZUM DECK TEST-1 Mechanism deck test-1
trnSP-2 : MECHANIZUM DECK TEST-2 Mechanism deck test-2
PAtH AdJ : TAPE PATH ADJUSTMENT Tape path adjustment
torq AdJ : FWD/REV TORQ CHECK FWD/REV torque checking

rEcoG-S : RECOGNITION SWITCH Recognition switch d-SEnSor : DEW SENSOR Dew sensor

tAPE LEn: TAPE LENGTH

Sr EEP: SV EEPROM DATA

Tape length

Servo EEPROM data

- : separator

(4) Preset menu

ProtEct : PROTECT Permission/prohibition setting for setup menu registration

tyPEcodE: 9pin DEVICE TYPE 9pin device type setting SEriAL: SERIAL No. Serial number setting

2. How to enter the service menu.

Press the STOP key +DISPLAY key +SET key at the same time.

"Print" appears on display and the machine enters the service menu.

3. How to exit the service menu.

Press the STOP key +DISPLAY key +RESET key at the same time. Or turn off the power switch.

4. Operations

• Changing the menu item : MENU key +search dial

• Moving to the other digit of the setup data : MENU key

• Changing the setup data : DATA key +search dial

• Setting data or starting a test : SET key

• Resetting the setup data or stopping the test : DATA key +RESET key

2-6-1. Print Menu

Menu Item	Description	
Print : PRINT	Outputs the various information (text data) from the RS-232C connector panel.	on the rea
	Use a cross-cable (sex-inverted cable) to connect a personal computer	or printer.
	Condition : STOP mode or cassette is not inserted.	
	 Output method : Select a data to be output by turning the dial while the DATA key, and press the SET key. 	pressing
	inFo : Service information (version number, destination, serial number, hours servo data)	meter and
	Err LoG : Error/caution history	
	Corr LoG : Signal processing error (mute/interpolation/correct exceeding a certain numbers) history	on
	Communication format	
	Flow control : Hardware (RTS/CTS)	
	Stop bit : 1bit	
	Data bit : In accordance with setup menu "dAtA" (DATA BIT	S)
	Parity : In accordance with setup menu "PArity" (PARITY)	
	Baud rate : In accordance with setup menu "bAud rAtE" (BAU	
	Abort method : DATA key +RESET key	

2-6-2. Display Menu

	n	Description		
[DSPLy] open/close		Selects whether or not to display the display menu. OPEN: display		
SoFt	: SOFTWARE VERSION	Software version		
		*_** *_**		
		Main CPU (SSP-11 board IC304)		
		Exsample) 1_00: Version 1.00 Servo CPU (SV-147A board IC9)		
		Servo CPO (SV-147A board 105)		
		Press the MENU key, and then the date when the version of the main CPU is changed, is displayed.		
oPE-t	: OPERATION TIME	Hour meter for operation time 0 to 99,999 (hour)		
Hour-t	: DRUM RUNNING TIME (Reset enable)	Hour meter for drum running time (reset enable) 0 to 99,999 (hour)		
run-t	: TAPE RUNNING	Hour meter for tape running time (reset enable) 0 to 99,999 (hour)		
	TIME (Reset enable)			
tHrd-no	: THREAD/UNTHREAD COUNTER (Reset enable)	Meter for tape threading/unthreading operation (reset enable) 0 to 99,999 (time)		
A_Hour-	: DRUM RUNNING TIME	Hour meter for drum running time (reset disable) 0 to 99,999 (hour)		
A_run-t	: TAPE RUNNING TIME	Hour meter for tape running time (reset disable) 0 to 99,999 (hour)		
A_tiHrd	: THREAD/UNTHREAD COUNTER	Meter for tape threading/unthreading operation (reset disable) 0 to 99,999 (time)		
Err	: ERROR/CAUTION LOG	History of error/caution code (a maximum of 100). The error code, time, date, tape running mode and tape counter value when an error or caution occurred, are displayed.		
		DATA key +dial : Incrementing and decrementing address		
		MENU key : Address +10		
		 MENU key : Address +10 DATA key +RESET key : Clearing the history DATA key +SET key : RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) 		
		 DATA key +RESET key : Clearing the history DATA key +SET key : RS-232C output (Same result is obtained as the "Err 		
		DATA key +RESET key: Clearing the history BATA key +SET key: RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication: Err *** Address (1 to 100)		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** ***		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err: Error		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err : Error CAu: Caution		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err : Error CAu: Caution 2) Date (year-month-day)		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err: Error cAu: Caution		
		DATA key +RESET key: Clearing the history: RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication: Err: *** Address (1 to 100) Right indication: 1) Code: *** *** Code: Err: Error: CAu: Caution Date (year*month*day) Time (hour*minute*second) Tape counter, tapetape path mode **** *** *** *** DATA key +RESET key: Clearing the history: RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Date (year*month*day) Time (hour*minute*second)		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err : Error CAu: Caution 2) Date (year-month-day) Time (hour-minute-second) Tape counter, tapetape path mode		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code ***		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code *** Code Err : Error CAu: Caution 2) Date (year*month*day) 3) Time (hour*minute*second) 4) Tape counter, tapetape path mode *** *** *** *** *** *** ** **		
		DATA key +RESET key: Clearing the history RS-232C output (Same result is obtained as the "Err LoG" is executed from "Print" of the service menu.) Left indication Err *** Address (1 to 100) Right indication 1) Code ***		

Pb Aud id : PB MAIN ID

The MAIN ID data which is reproduced from tape.

* * * * * * * * * 8 7 6 5 4 3 2 1

No. on b	T		X: Not defined
Number	ID Name	Indication	Content
①	Format ID	0 1 2 3	AUDIO USE X X
@	ID1: Emphasis	0 1 2 3	OFF 50/15 μs ×
3	ID2: Sampling frequency	0 1 2 3	48 kHz 44.1 kHz 32 kHz ×
•	ID3: Channel number	0 1 2 3	2 channel 4 channel X
⑤	ID4: Quantization	0 1 2 3	16 bit linear 12 bit non-linear X
6	ID5: Track pitch	0 1 2 3	Normal Wide ×
⑦	ID6: Copy	0 1 2 3	Permission X Inhibit Pre-recorded
8	ID7: Pack	-	

Description Menu Item Playbacked SUB ID data from tape. Pb Sub id : PB SUB ID * * - * * * 4 3 2 1 X: Not defined Indication Content **IDName** Number AUDIO USE 0 1 Data ID 1 ×× 2 3 bit0: TOC 4 bit (2) Control ID bit2: SHORTENING (SKIP) HEX bit3: START indication bit4: PRIORITY Number of recorded packs 0 to 7 Pack ID 3 No program Number 000 4 Program number Program Number 001 to 799 Invalid 0AA Lead in area 0BB Lead out area (END ID) OEE Playbacked pro R-TIME data from tape. hour-minute-second-frame (0 to 33) Pb Pro-t : PB PRO R-TIME Time code marker value of pro R-TIME. : TIME CODE MARKER P * * * (HEX) playback recording Playbacked A-TIME data from tape. hour-minute-second-frame (0 to 33) Pb Abs-t : PB A-TIME Playbacked date data from tape. Day of the week-year-month-day Pb yEAr : PB DATE day year Day of the week

Day of the week

Playbacked time data from tape. hour-minute-second

1: Sunday, 2: Monday 7: Saturaday

- minute - hour

Pb Hour : PB TIME

Menu item Description tc rdr : TIME CODE READER Time code reader and input time code status. Reader status (HEX) bito: DECODE 1: BAD. 0: GOOD 1: ERROR, 1: BIT ERROR 0: NO ERROR 2: VALUE ERROR 1: ERROR. 0: NO ERROR 3: DIRECTION 1: REV. 0: FWD Speed 6: 1/8 to 1/4 1: < 1/32, 0: 1/32 to 1/16, E: 1/4 < 2: 1/16 to 1/8 Freeze 1: Freeze Input 1: Time code input dSno : dSNo Difference between the target time code and the playback time code (in units of code 000**** (HEX) FS cntr : Fs COUNTER A frequency counter data of the input sync signal (D-I, WORD, VIDEO). The frequency can be calculated from this data. **** (HEX) Input signal frequency (Hz) = Count clock frequency (Hz) × 256/Fs COUNTER Count clock frequency (128Fs) 48 kHz : 6.1440 MHz 44.1 kHz : 5.6448 MHz 9_6 cntr : 9.6k COUNTER A frequency counter data of the 9.6 kHz input signal coming from 37-pin parallel remote connector. The frequency can be calculated from this data. *** (HEX) Average of counter data counter data Input signal frequency (Hz) = Count clock frequency (Hz) × 256/9.6 k COUNTER Count clock frequency (32Fs) 48 kHz :1.536 MHz 44.1 kHz : 1.4112 MHz

rate) is calculated. ALARM indicator o	e (%) Example) and channel of the playt Effective only in STOF in the front panel flashe : Setting data changin : Setting	
Selects the head a rate) is calculated. ALARM indicator of DATA key +Dial • SET key Indication Auto A-Ab A-A A-b	nd channel of the playt Effective only in STOF In the front panel flashe : Setting data changir : Setting Head RMW: Leading, RAW: Trailing Leading Leading	back data of which the Err rAtE (error P. When others than Auto is set, the es. Channel Average of A-ch and B-ch A-ch A-ch
rate) is calculated. ALARM indicator of the control	Effective only in STOF In the front panel flasher : Setting data changin : Setting Head RMW: Leading, RAW: Trailing Leading Leading	P. When others than Auto is set, the es. Channel Average of A-ch and B-ch Average of A-ch and B-ch A-ch
Auto A-Ab A-A A-b	RMW: Leading, RAW: Trailing Leading Leading	Average of A-ch and B-ch Average of A-ch and B-ch A-ch
A-Ab A-A A-b	RAW : Trailing Leading Leading	Average of A-ch and B-ch A-ch
A-A A-b	Leading	A-ch
A-b		
	Leading	B-ch
d-Ab		
	Trailing	Average of A-ch and B-ch
d-A	Trailing	A-ch
d-b	Trailing	B-ch
that are selected is started.	Example) 1_0-4: 1.0	pears in about six seconds after playb
8	SW TAKE TAKE TAKE TAKE TAKE TAKE TAKE TAKE	PE: Playback MAIN ID (ID2) from tal : Digital audio input
	that are selected to is started. *_*-* Fs (sampling frequency to the selected to is started. *_*-* Fs (sampling frequency to the selected to is started.	*_*-* Example) 1_0-4: 1.0 Fs (sampling frequency) ID E * d * t * S *

Menu Ite	m	Description
EP id	: EMPHASIS ID	Find the second
coPy id	: COPY ID	Copy ID r* d* t* S* SW :Copy ID setting of setup menu TAPE :Playback MAIN ID (ID6) from tape DIN :Digital audio input REC :Recording MAIN ID (ID6) to tape 0: Permission 2: Inhibit 3: Pre-recorded
din Err	: DIN ERROR	Indicates type (professional or consumer type) of input digital audio signal, and reason why the "D-1" of the display flashes. Pro * * * DIN PLL unlock Word slip (When digital connecting without sync signal) IDs do not match. 0: Miss-match does not occur. 1: Miss-match occurs. Pro: For professional use, con: For consummer use
Sy diP-S	: SYS DIP SWITCH	DIP SW (S302) on the SSP-11 board setting * * * * * * * * * 0: OFF No.8 7 6 5 4 3 2 1 1: ON
Sr diP-S	: SV DIP SWITCH	DIP SW (S1) on the SV-147A board setting * * * * * 0: OFF No.4 3 2 1 1: ON

Description
16-bit input audio signal data after converted to absolute value, and the bit map meter. Bit map meter: Each bit of the audio data is made to correspond to each segment of meter. A segment turns on when the bit is 1.
**** **** (HEX) 0000 to 7FFF, 8000: OVER CH-1 CH-2
bit0 (End of right) bit14 OVER
16-bit playback audio signal data after converted to absolute value, and the bit map meter. They are not displayed during memory jog and rehearsal.
**** **** (HEX) 0000 to 7FFF, 8000: OVER CH-1 CH-2
bit0 (End of right) bit14 OVER
RS-232C status indication
Transmitting data (HEX) Receiving data (HEX) DSR (0: OFF, 1: ON) DCD (0: OFF, 1: ON) Peceving error (HEX) bit0: Parity error bit1: Overrun error bit2: Framing error

2-6-3. Test Menu

Menu Item	Description Selects whether or not to display the test menu. OPEN: Indication	
[tESt] open/close		
SyS cPu : SYS CPU TEST	Test for address bus and data bus of system control CPU (IC304, SSP-11 board), and ROM (IC307), RAM (IC309, 310). Condition: STOP mode or cassette is not inserted. Test method: Press the SET key.	
	Result Display indication	
	No error **** **** (HEX) 16bit scheck sum 8bit scheck sum	
	Error 0 0 0 0 0 * * * * * Address bus — Data bus — ROM (IC307) — RAM (IC309, 310)	
display : Display Test	Test for FL display and LED lamp of front panel	
	Condition : STOP mode or cassette is not inserted. Test method : Press the SET key. The following cycle is repeated: All displays turn on → LED lamps turn on sequentially → Segments of the FL display turn on sequentially. (One cycle: about 30 accords)	
	(One cycle: about 30 seconds) • Abort method : DATA key +RESET key	

Description

PANEL-S : PANEL KEY TEST

Key test of front panel.

- · Condition : STOP mode or cassette is not inserted.
- Test method: Press the SET key, then press all of the 27 keys on the front panel. Test result appears on the display.

• Test result

Result	Display indication		
No error	no Error		
Error	- * * * * * * * (HEX) 7 6 5 4 3 2 1		
	The data in hexadecimal number is converted to binary data. The key which corresponds to bit 0, is error.		
	Example) - FFFFFdF (HEX)		
	② "d": 1101 (binary number)		
	Bit 1 of ② is "0". The CUE key is known to be error when referred to the correspondence table.		

· Correspondence table

Digit	bit	Key	Digit	bit	Key
0	0 1 2 3	EJECT STOP STANDBY FF	(5)	0 1 2 3	MARK DISPLAY MENU DATA
2	0 1 2 3	REW CUE PLAY REC	6	0 1 2 3	SET RESET MEMORY START INSERT SUB
3	0 1 2 3	WRITE ERASE NEXT PREVIOUS	0	0 1 2	INSERT AUDIO ASSEMBLE SYNC REC
4	0 1 2 3	LOCATE VARI CHASE INPUT MONITOR			

Abort method: DATA key +RESET key

Description

toGGLE-S

: TOGGLE SWITCH TEST

Toggle switches and search dial test of front panel.

- Condition
 - : STOP mode or cassette is not inserted.
- Test method: Press the SET key, then operate the four toggle switches on the
 - front panel, and turn the search dial in the CW/CCW directions.
 - Test result appears on the display.
- · Test result

Result	Display indication					
No error	no Error					
Error	0 * * * (HEX) 3 ② ① The data in hexadecimal number is converted to binary data.					
	The key which corresponds to bit 0, is error.					

·Correspondence table

Digit	bit	Key
0	0 1 2 3	REMOTE LOCAL EXT INT
@	0 1 2 3	VIDEO ANALOG DIGITAL 44.1 kHz
3	0 1 2	48 kHz Turn the DIAL clockwise Turn the DIAL counterclockwise

· Abort method:DATA key +RESET key

diAL

: DIAL TEST

Display for search dial position

 Test method: Turn the search dial confirm that the display on the right side becomes almost "0" when the search dial is rotated one full turn.



- · Reset method : RESET key
- · Assumed malfunctioning parts
 - : Rotary encoder on KY-192 board, IC306 (CXD8970) on SSP-11 board, CN303 on SSP-11 board

Menu item

Description

37Pin-1 : 37pin REMOTE TEST-1

37/8pin remote test

- : STOP mode or cassette is not inserted. Condition
- · Test method : Press the SET key.
 - 1) Turn on the status output in the following order.
 - (One cycle: about 12 seconds)
 - 5: REW \rightarrow 3: FF \rightarrow 4: PLAY \rightarrow 2: STOP \rightarrow 6: STANDBY \rightarrow 8: REC \rightarrow 9: LOCATE \rightarrow 7: INPUT MONITOR
 - ightarrow 14: ALARM ightarrow 18: SERVO LOCK ightarrow 11: START ID
 - \rightarrow 12: SKIP ID \rightarrow 13: END ID \rightarrow 10: Reserved
 - → 8pin 4: PLAY → 8pin 5: STOP
 - 2) Press the connected key of 37pin/8pin remote. Then test result will be displayed.

Test result

Result	Display indication								
No error	no Error								
Error	* * * * * * (HEX) 6 5 4 3 2 1								
	The data in hexadecimal number is converted to binary data. The key which corresponds to bit 0, is error.								

· Correspondence table

Digit	bit	Command	Digit	bit	Command
1	0 1 2 3	21: STOP 22: FF 23: PLAY 24: REW	4	0 1 2 3	33: CHASE 34: EJECT 35: Reserved 36: EXT SOURCE
2	0 1 2 3	25: STANDBY 26: INPUT MONITOR 27: REC 28: ID NEXT	⑤	0 1 2 3	16: SPEED A "0" 16: SPPED A "1" 17: SPPED B "0" 17: SPEED B "1"
3	0 1 2 3	29: ID PREVIOUS 30: START ID WRITE 31: SKIP ID WRITE 32: END ID WRITE	6	0 1 2 3	15: REVERSE "0" 15: REVERSE "1" 8pin 2: STOP 8pin 1: PLAY

· Abort method: DATA key +RESET key

Description

37Pin-2 : 37pin REMOTE TEST-2

37/8 pin remote automatic test. The following connectors (for tool) are required.

- : STOP mode or cassette is not inserted.
- Test method :
 - (1) Prepare a D-sub 37pin(male) and DIN 8pin(male) connectors of which pins are connected as follows;
 - · D-sub 37pin (male) connector

2 pin (STOP) ←→ 21 pin (STOP) and 35 pin (Reserved)

3 pin (FF) \longleftrightarrow 22 pin (FF) and 36 pin (EXT SOURCE SELECT)

4 pin (PLAY) \longleftrightarrow 23 pin (PLAY) and 15 pin (REVERSE) 5 pin (REW) \longleftrightarrow 24 pin (REW) and 16 pin (SPEED A)

6 pin (STANDBY) ←→ 25 pin (STANDBY) and 17 pin (SPEED B)

7 pin (INPUT MONITOR) \longleftrightarrow 26 pin (INPUT MONITOR)

8 pin (REC) ← 27 pin (REC)

9 pin (LOCATE) ←→ 28 pin (ID NEXT)

10 pin (Reserved) \longleftrightarrow 29 pin (ID PREVIOUS) 11 pin (START ID) \longleftrightarrow 30 pin (START ID WRITE)

12 pin (SKIP ID) \longleftrightarrow 31 pin (SKIP ID WRITE)

13 pin (END ID) \longleftrightarrow 32 pin (END ID WRITE) 14 pin (ALARM) \longleftrightarrow 33 pin (CHASE)

18 pin (SERVO LOCK) ←→ 34 pin (EJECT)

DIN 8 pin (male) connector

2 pin (STOP) \longleftrightarrow 5 pin (STOP)

1 pin (PLAY) ←→ 4 pin (PLAY)

Then connect they to the REMOTE (37P) and REMOTE (8P) connectors of rear panel (PCM-7040).

(2) Press the SET key.

· Test result

Result	Display indication
No error	no Error
Error	* * * * (HEX) ④ ③ ② ①
	The data in hexadecimal number is converted to binary data. The connection line which corresponds to be bit 0, is error.

· Correspondence table

Digit	bit	Connection	Digit	bit	Connection
1	0 1 2 3	(1) STOP (2) FF (3) PLAY (4) REW	3	0 1 2 3	(9) Reserved (10) START ID (11) SKIP ID (12) END ID
2	0 1 2 3	(5) STANDBY (6) INPUT MONITOR (7) REC (8) LOCATE	4	0 1 2 3	(13) ALARM (14) SERVO LOCK (15) 8pin STOP (16) 8pin PLAY

Assumed malfunctioning parts: IC306(CXD8970), IC320 to 321(TD62381),

IC322 to 324(HC245)

Abort method

: DATA key +RESET key

Description

rS-232

: RS-232C TEST

RS-232C automatic test. The following connector (for tool) is required.

- : STOP mode or cassette is not inserted.
- · Test method :
 - (1) Prepare a D-sub 25pin (male) connector of which pins are connected as follows:
 - · D-sub 25pin (male) connector
 - 2 pin (TXD) ←→ 3 pin (RXD)
 - 4 pin (RTS) ←→ 5 pin (CTS)
 - 6 pin (DSR) ←→ 20 pin (DTR)

Then connect it to the RS-232C connector of rear panel (PCM-7040).

(2) Press the SET key.

· Test result

Result	Display indication
No error	по Епог
Error	0 0 0 0 0 0 * * * (HEX) (3) DSR/DTR (2) RTS/CTS (1) TXD/RXD

Assumed malfunctioning parts : IC306 (CXD8970), IC317 (LT1134)

Abort method

: DATA key +RESET key

9 Pin : 9pin REMOTE TEST 9pin automatic test. The following connector (for tool) is required.

- : STOP mode or cassette is not inserted. Condition
- Test method:
 - (1) Prepare a D-sub 9pin (male) connector of which pins are connected as follows;
 - D-sub 9pin (male) connector

 - 2 pin (Transmit A) \longleftrightarrow 8 pin (Receive A) 7 pin (Transmit B) \longleftrightarrow 3 pin (Receive B)
 - 6 pin (Transmit Common) \longleftrightarrow 4 pin (Receive Common) Then connect it to the REMOTE (9P) connector of rear panel
 - (PCM-7040). (2) Press the SET key.

· Test result

Result	Display indication
No error	no Error
Error	0 0 0 0 0 0 * * Communication error between 9pin CPU and MAIN CPU Transmit/Receive Data

· Assumed malfunctioning parts : IC306 (CXD8970), IC318 (uPD78C11),

IC319 (MC34051)

· Abort method

: DATA key +RESET key

Description

Au PAth : AUDIO PATH TEST

Audio signal path test for SSP-11 board

: Cassette is not inserted.

· Test method: Input the different audio signals to the ANALOG and DIGITAL INPUT connectors respectively. Confirm that the input signal to the ANALOG and DIGITAL INPUT connectors, are output respectively by selecting their signal path number. When the output signal cannot be obtained, locate the defective IC using the

following block diagrams and table.


When S51 on the SSP-11 board is set to "TEST", the AD converter output is input to the DA converter as it is.

· DATA key + Dial : Signal path No. changing

· SET key

: Setting

Audio signal path block diagram (SSP-11 board)



Audio signal path No. and ICs (SSP-11 board)

Path	Out-	IC 51	IC 801	CXD	406 8971	ICI	501	IC 603	IC 602	IC 604	CXD	406 8971	IC 417	IC 431		406 8971	IC 806	IC57, 58
No.	put	AD	DI RECV	DEC	Di SC	P MEM	R MEM	DSP #1	DSP #2	DSP #3	REC SC	PB SC	SP-	SP-	DO SC	DO ENC	DO DRV	DA
1	Α	0						0							0	0	0	0
2	D		0	0	0			0							0	0	0	0
3	D		0	0	0			0		0					0	0	0	0
4	D		0	0	0	0		0		0					0	0	0	0
5	D		0	0	0				0	0					0	0	0	0
6	D		0	0	0		0		0	0					0	0	0	0
7	D		0	0	0			0		0	0	0	0		0	0	0	0
8	D		0	0	0				0	0	0	0	0		0	0	0	0
9	D		0	0	0			0		0	0	0		0	0	0	0	0

Output A

: Analog, D: Digital

SC SP-L

: Slot Converter (16 - 32bits) : Signal Processor (Leading)

SP-T

: Signal Processor (Trailing)


Description

Sound

: SOUND MEMORY TEST

Address bus and data bus of memory control block, and sound memory tests for IC406 (CXD8971) on SSP-11 board. (About 70 seconds)


- · Condition : STOP mode or cassette is not inserted.
- · Test method : Press the SET key.
- · Test result



tmSP-1 : MECHANIZUM DECK TEST-1

Mechanical device test for mechanism deck assembly

- Condition : Blank cassette (no tape).
- Test method: Press the SET key, and insert the blank cassette. After the test
 has completed, the blank cassette will automatically be ejected.
- · Test result



Menu Item Description tmSP-2 : MECHANIZUM DECK TEST-2 Plunger solenoid test for mechanism deck assembly : Cassette is not inserted. Test method: Press the SET key. Check the sound produced when plungenr solenoid operating. Test result Result Display indication No error no Error Error 000000* Plunger solenoid kick Plunger solenoid release 1: Error PAtH AdJ: TAPE PATH ADJUSTMENT Tape path adjusting Test tape : test tape TY-7251 Adjustment method : While pressing the DATA key, set the ATF OFFSET (oFF: off, 0: 0%, 50: 50%, 100: 100%) by turning the search dial. Then press the SET key. For detail of adjustment, refer to "11. TAPE PATH ADJUSTMENT of 4-2-2. Adjustments and checkings in the service menu". torq AdJ : FWD/REV TORQ CHECK FWD/REV reel torque checking. Test tape : Torque cassette TW-7131 Checking : While pressing the DATA key, set the "on" display by turning the Insert the torque cassette. Confirm the torque values at each mode when tape runs in the FWD direction by pressing the PLAY key, or alternately tape runs in the REV direction by pressing the CUE key and turning the search dial in the CCW direction. For torque specifications, refer to "9. FWD/REV TORQUE ADJUSTMENT of 4-2-2. Adjustments and checkings in the

service menu.

Description

rEcoG-S: RECOGNITION SWITCH

Indicates cassette hole switch ON/OFF.

* * * * * * * 5 4 3 2 1

Digit	Hole name	Indication	OPEN/CLOSE
1	HOLE-1(RESERVED)	0	OPEN (RESERVED) CLOSE
2	HOLE-2(THIN)	0	OPEN (THIN) CLOSE
3	HOLE-3(WIDE)	0	OPEN (WIDE) CLOSE
④	HOLE-RECINH	0	OPEN (REC INHIBIT) CLOSE
(\$)	HOLE-4(SOFT TAPE)	0	OPEN (SOFT TAPE) CLOSE

d-SEnSor : DEW SENSOR

Indicates dew sensor data and voltage.

- Dew sensor data (00H to FFH) - Voltage *.** V

tAPE LEn: TAPE LENGTH

Indicates the length of a tape. The time required to indicate data is about 10 seconds in PLAY, and immediately in FF and REW modes after a cassette is inserted.

* * * (minute)

Sr EEP : SV EEPROM DATA

Indicates EEPROM data of IC12 on the SV-147A board.


· DATA key +Dial: Address increase/decrease

- Data (HEX) - Address (00 to 35)

Address	Data	Address	Data	Address	Data
00	SWP POSITION	12	EQ-L-X2	24	
01	٠.	13	EQ-H-X2	25	
02		14	EQ-Q-X2	26	
03	FWD TORQ S	15	EQ-P-X2	27	·
04	FWD TORQ T	16	REC-L-PCMA1	28	
05	REV TORQ S	17	REC-L-PCMB1	29	
06	REV TORQ T	18	REC-L-ATFA1	30	
07	OFFSET TORQ	19	REC-L-ATFB1	31	
08	EQ-L-X1	20	REC-T-PCMA1	32	END S LOW
09	EQ-H-X1	21	REC-T-PCMB1	33	END S HIGH
10	EQ-Q-X1	22	REC-T-ATFA1	34	END T LOW
11	EQ-P-X1	23	REC-T-ATFB1	35	END T HIGH

2-6-4. Preset menu

Menu Item	Description Setting permission or inhibit of the setup menu registration "-sto-". The setup is backed up. When menu is going to be registered with the inhibit setting, "-ProtEct-" appears on display.						
ProtEct : PROTECT							
	oFF : Permission (Factory default setting) on : Inhibit						
tyPEcodE: 9pin DEVICE TYPE	Sets the device type of 9-pin remote connector. The setting is backed up.						
	 Note: The VTR constants such as EDIT DELAY remains unchanged even other setting than "00 00" is performed. 						
	** ** (HEX) DATA1 DATA2						
	 Device type of PCM-7030/7050 or PCM-7040 (Factory default setting Setting of PCM-7030/7040/7050 is performed using the switch S302 No. 3 and 4 on the SSP-11 board. 						
	Others: The set data is returned as it is. Example) 20 25: DVW-75						
SEriAL : SERIAL No.	Sets the serial number. The setting is backed up. This is used as the replay to the identification information request command (*IDN?;) of the ISR.						
	* * * *						



Section 3 Periodical Inspection and Maintenance

3-1. Cleaning

After cleaning, thoroughly wipe the drum surface using a dry cloth before inserting a cassette. If you do not wipe the drum surface completely with a dry cloth, the tape may be damaged due to an effect similar to moisture condensation.

- Normal cleaning
 Clean the drum and tape running system once a week using the following cleaning cassette.
 Cleaning cassette: DT-10CL (Optional accessory)
- When dirt is not removed completely with the cleaning cassette. (Be especially careful not to apply excessive force to the drum head.)

Note: Run the cleaning cassette for no more than 30 seconds.

Cleaning the drum

- (1) Wipe the lower section of the drum along the lead using a cleaning piece moistened with alcohol. Never touch the side surface of a drum with your bare hands.)
- (2) Use a dry cleaning piece and wipe the section you just wiped in the previous step.
 Be sure to perform step (2) immediately after (1). After the alcohol dries up, removing the remaining dirt just by wiping with a dry cloth will be difficult.
- (3) Clean the upper section of the drum using a cleaning piece moistened with alcohol.

 Never touch the side surface of upper drum with your hands. Rotate the drum in the direction of the arrow (⇒) to wipe the side surfaces of the upper drum and head. Repeat this procedure for approximately three rotations of the upper drum.


- (4) Wipe the upper section of the drum using a dry cleaning piece along the lead and rotate the upper drum approximately twice to wipe with a dry cleaning piece. Be sure to perform step (4) immediatery after (3). After the alcohol dries up, removing the remaining dirt just by wiping with a dry cloth will be difficult.
- (5) Inspect the entire circumference of upper drum by sight to make sure no fingerprints and no stains remain when the alcohol dries up. Cleaning piece: Part No. 2-034-697-00

Notes:

- 1. Never clean the drum while it is being driven.
- Do not wipe with the cleaning piece in a vertical motion with respect to the head clip.
 Doing so will most likely damage the head clip.
- When cleaning the drum, never touch the LED with your hand.
- 4. If there are dusts, etc. on the cleaning roller, remove with a pair of tweezers.

Cleaning the tape running system

- Remove the dirt on capstan axis, pinch roller, tension arm pin, and inclination guide pins using a cleaning piece moistened with alcohol. Wipe these parts then with a dry cleaning piece.
- (2) Peel off the dirt on the rotation rollers (T1, T2, T3, S1, S2 Tension arm roller) using a stick made of pliant piece such as bamboo before too much dirt accumulates. Then, wipe these areas with a dry cleaning piece.



3-2. Periodic check (maintenance) schedule

The following table shows the schedule for periodically checking the main parts of the unit to ensure its full functions and performance.

It is recommended to use the hour meter in the SERVICE menu as a reference for periodic inspections.

(See "2-6. Service menu".)

The methods of replacing and adjusting the following parts are described in "Section 4 Replacement and Adjustment of Mechanism deck".

Periodic Checks and Maintenance Schedule

Note The time shown in the table dose not signify the guaranteed time.

3-3. Maintenance after repaires

Perform the following maintenance after repairs regardless of the unit operating hours.

- 1. Clean the drum head.
- 2. Clean the tape transport surfaces.

Part name (Part No.)		Remarks						
	Part No.) 1 week 1000H 2000H 3000H 4000H 5000H 6000H						6000H	
Mechanism deck assy MT-PCM -7040-103 (A-8311-799-)							☆	Replace every 6000H.
Drum assy, DOU-21B/J-N (8-848-696-)				☆			(☆)	Clean every week and replace every 3000H.
Capstan motor, U-21A (8-835-329-)	0			☆			(☆)	Clean every week and replace every 3000H.
Reel motor (1-698-227-)		☆	☆	☆	☆	☆	(☆)	Replace every 1000H.
Pinch rollor assy (X-3363-976-)	0			☆			(☆)	Clean every week and replace every 3000H.
Drive motor assy (A-8267-759-)							(☆)	Replace every 6000H.
HC roller (3-375-727-)				☆			(☆)	Replace every 3000H.
Rotary encoder (1-466-670-)				☆			(☆)	Replace every 3000H.
Cassette compartment assy (A-8267-998-)				☆			(☆)	Replace every 3000H.

O: Cleaning, ☆: Replace, (☆): These are component parts of the MT-PCM-7040-103 by replaceing the mechanical deck assy, these parts are also replaced.

Section 4 Replacement and Adjustment of Mechanism Deck

4-1. Replacement of Mechanism Deck Assy and Parts

Replace the parts to replace periodically (refer to item "Section 3") following the table below.


- The parts required to remove when replacing the parts to replace periodically are signified with "O".
- The figures in the circles signify the removing order or the parts required to remove.
- · Assemble the parts in the reverse order of the removal. After replacement, proceed to "4-2. Adjustments and checks".

Note: Be sure to turn the POWER switch OFF during the operation.


		Parts required to remove										
Parts to replace periodically	RF shield case (top)	cassette window assy	MD side (L)	MD side (R)	RF-53 assy	Flexible shield plate	SV-147A board	MD shield plate	Cassette compart- ment assy	Reel motor		
Mechanism deck assy	_		_	_	_		_	_	_	_		
Drum assy DOU-21B/J-N	0	@	3	•	(5)	6	7	8	_	_		
Capstan maotor U-21A	_	1	2	3	_	_	4	(5)	_	_		
Reel motor	_	0	2	3	_	_	4	(5)	_			
Pinch roller assy	_	0	@	3	_	_	4	(5)	6	Ī		
Drive motor assy	1)	2	3	4	5	_	6	Ī	_	_		
HC roller	_	_	_	_	_	_	_	_	_	_		
Rotary encoder	_	0	2	3	_	_	4	(5)	_	_		
Cassette compartment assy	_	0	@	3	_	, -	4	(5)	_	_		


Procedure

HC roller, Mechanism deck assy




RF Shield Case (top), Cassette Window assy, MD side Plate (L)/(R), MD Plate







Cassette compartment assy



Drive motor assy, Rotary encoder, Capstan motor, Pinch roller assy.





4-2. Adjustments and Checks

When the PCM-7040 mechanism deck assy or mechanism deck parts (periodic replacement parts) are replaced, perform checks and adjustments in accordance with Table A.

Perform the checks and adjustments after the PCM-7040 mechanism deck assy is attached to the PCM-E7700 and using the built-in service menu of the PCM-E7700. It requires a PCM-E7700 machine (which is know to be a good machine) separately as an adjustment tool.


Attachment procedure

Attach the PCM-7040 mechanism deck assy to be adjusted, to the PCM-E7700 mechanism deck (recorder) assy, following the procedure below.


Procedure

Note: Before attaching the PCM-7040 mechanism deck assy, turn off the main power of the PCM-E7700.


(1) Remove the three screws (PWH 3 × 6) and remove the top panel.




(2) Open the display assy in the direction shown by the arrow.



(3) Remove the two (PWH 3 × 6) screws and move the key assy slightly in the direction shown by the arrow.



- (4) Remove the three harnesses and three screws (PWH 3 × 5) from the mechanism deck (recorder) of the PCM-E7700. Then remove the mechanism deck (recorder) from the PCM-E7700.
- (5) Attach the PCM-7040 mechanism deck assy to be adjusted, to the PCM-E7700 using the three screws (PWH 3 × 5).



(6) Connect the three harnesses coming from the following connectors, to the PCM-7040 mechanism deck assy which is attached to the PCM-E7700 for adjustment.

PCM-F700 PCM-7040 mechanism de: k assy
CN501, SSP-8 board → CN7, SV-147 board
CN708, SSP-8 board → CN11, SV-147 board
CN711, SSP-8 board → CN2, RF-53 board

Note: The harness coming from the RF-53 assyis not necessary to be connected.

- (7) Move back the key assy which is moved in step (3), by attaching the two screws (PWH 3 × 6).
- (8) Perform section "4-2-2. Adjustments and checksi n the Service Menu".

Table A : List of adjustments

When the mechanism deck assembly and its parts (parts to be replaced periodically) have been replaced, the adjustments with O must be performed.

Parts replaced	Mech- anism	Drum assy	Cassette compart-	Drive motor	Capstan motor	Reel	Pinch roller	Rotary	HC roller		hers
	deck assy		ment assy	assy			assy			SV-147A assy (RP)	RF-53 assy (RP)
Adjustments (Service mode)										, ,	,
1. SERVO DATA PRESET						0					
2. PLUNGER CHECK		0	0	0	0	0	0	0	0	0	
3. MECHANICAL DEVICE TEST							0	0			
4. RECOGNITION SWITCH CHECK											
5. END SENSOR LEVEL CHECK (HIGH)			0							0	
6. END SENSOR LEVEL CHECK (LOW)			0							0	
7. DEW SENSOR CHECK											
8. REEL TORQUE CHECK						0				1	
9. FWD/REV TORQUE ADJUSTMENT						0				0	
10. DRUM/CAPSTAN SPEED & WOW CHECK		0		-							
11. TAPE PATH ADJUSTMENT		0			0	0	0			1	
12. SWP POSITION ADJUSTMENT		0	·							0	
13. PATH & FF/REV TIME CHECK		0			0	0	0				
14. PB ERROR RATE CHECK	0	0			0	0	. 0			0	0
15. REC CURRENT ADJUSTMENT (LEADING)		0								0	0
16. REC CURRENT ADJUSTMENT (TRAILING)		0								0	0
17. REC/PB ERROR RATE CHECK	0	0								0	0
18. SERVO DATA SAVE		0			'	0				0	0
19. SERVO DATA DISPLAY											
4-2-3. Checking after SV-147A board replacement										0	
5-2-3. RF PLL adjustment	0	0									0

4-2-1. Preparations

Equipment

Name	Specification	Equipment
Oscilloscope	4CH INPUT DC to 150 MHz	TEKTRONIX 2445A or equivalent
Digital multimeter	_	ADVANTEST R6341A or equivalent

Tools

Name	Parts No.	Remarks
SONY PCM-E7700	Products	
Adjusting Screwdriver	J-6225-100-A	For fine tape path adjustments
RF LEVEL CHECKER PD-817	J-6228-170-A	For adjustments of recording and playback systems
I/F box PF-534 for the RF LEVEL CHECKER	J-6405-340-A	For PCM-E7700

Test Tapes and Torque Cassettes

Name	Parts No.	Remarks
Test tape TY-711DX	8-909-825-00	For playback level check
Test tape TY-7251	8-909-813-00	For tracking adjustments
Test tape TY-30BX	8-892-332-38	For recording level adjustments (Blank tape)
Test tape TY-7212	8-960-081-01	For error rate check
Torque cassette TW-7131	8-909-708-71	For FWD/REV torque adjustment
Torque cassette TW-7231	8-909-708-72	For FF/REW torque check

Use the following test tapes which are available on the market according to the table.

Name	Method of Use					
Blank cassette	No tape (remodel available DAT tapes)					
Test tape (01010)	Cassette tapes whose identification hole is as shown below (Remodel available DAT tapes) O 1 0					
Test tape (10101)	Cassette tapes whose identification hole is as shown below (Remodel the DAT tape available on the market) 101 01 123 REC INH O: OPEN •: CLOSE					
Test tape (end sensor LOW)	Any 120 min. tape on the market (Use from around the middle of the tape)					
Test tape (TOP)	Any 120 min. tape on the market (Use from around the top of the tape)					
Test tape (END)	Any 120 min. tape on the market (Use from around the end of the tape)					
Test tape (FF/REW TIME)	Any 30 min. tape on the market (Use after recording the whole tape)					

4-2-2. Adjustments and checks in the service menu

Setting the service menu

(1) After attaching the PCM-7040 mechanism deck assy to the PCM-E7700, set the BIT switch S1 on the SV-147A board (PCM-7040 mechanism deck assy) as follows:

S1/SV-147A board setting S1-3; ON S1-1, -2, -4; OFF

- (2) Turn on the power switch of the PCM-E7700.
- (3) Press the SHIFT key + MODE key simultaneously. (Service menu setting)

EL display

SEI	RVICE M	ENU				
1	PLAYER	MECHAN	ICAL DECK	ADJUSTMENT	ı	
				CK ADJUSTMI		
3	TEST					
4	INFORM	ATION				
			TEST	INFORM		
P-M	D	R-MD	1531	INFORM		

Note: F1 to F7; Function keys

(4) Press the F2 (R-MD) key.

EL display

RE	CORDER ADJUSTMENT	
		SERVO BOARD BIT SW
D	SERVO DECK PRESET	
2	PLUNGER CHECK	BIT! OFF MAN EJECT
3	MECHA DEVICE TEST	BIT2 OFF EEPROM EN
4	RECOGNITION SWITCH CHECK	BIT3 ON ERROR CUT
5	END SENSOR LEVEL CHECK (HIGH)	BIT4 OFF
6	END SENSOR LEVEL CHECK (LOW)	
7	DEW SENSOR CHECK	
8	REEL TORQUE ADJUSTMENT	i
9	FWD/RVS TORQUE ADJUSTMENT	* !
10	DRAM/CAPSTAN SPEED & WOW CHECK	i
	MESSAGE	
REC	DRDER: STOP	
TEST	ON EXIT	
1231	VII GAII	

*: Mode setting keys for SERVICE MENU.

Key	<u>Mode</u>
[SHUTTLE]:	STILL
[PREVIOUS]:	SHUTTLE -16
[NEXT]:	SHUTTLE +16
[PCM SEARCH]:	SHUTTLE -1
[LOCATE]:	SHUTTLE +1
[1]:	SHUTTLE -8
[2]:	SHUTTLE +8
[4]:	SHUTTLE -2
[5]:	SHUTTLE +2
[7]:	SHUTTLE -0.2
[8]:	SHUTTLE +0.2

(5) Using the ↑ and ↓ keys, select the desired adjustments according to Table A (select with the cursor " ") on page 4-6, and perform the following adjustments and checks.

Exiting the Service menu (Returning to normal operations)

After the adjustment has completed, perform the following to return to the normal operation modes from the service menu.

- (1) Set the BIT switch S1 on the SV-147A board (PCM-7040 mechanism deck assy) as follows:
 - S1-1, -2, -3, -4; All off
- (2) Turn off the power switch of the PCM-E7700.
- (3) Turn on the power switch of the PCM-E7700.
- (4) After the normal operation modes, turn off the power switch of the PCM-E7700, and then remove the PCM-7040 mechanism deck assy from the PCM-E7700

1. SERVO DATA PRESET

Normally, this adjustment and check need not be performed when mechanical deck parts (parts to be replaced periodically) have been replaced.

Note: If servo data preset has been performed by mistake, turn off the power switch of the PCM-E7700 and then turn it on again.

Equipment and Tools: Not required
Test Tape: Not required

Procedure		Checks	
 Using the ↑ and ↓ keys, select SERVO DATA PRESET*. 	l .	on the display may differ according to t	the version of the
(2) Press the F1 (TEST ON) key.	ROM used. RECORDER ADJUSTMENT	1. SERVO DECK PRESET	
(3) MESSAGE: PRESETTING IS COMPLETED! will be displayed on the EL display. (4) Press F1 (TEST OFF) key. (Presetting ends) Note: Every time the F1 key is pressed once, the unit sets to the TEST OFF (on the display) from the TEST ON	SWP POSITION = 117 (75H) FWD TORQ T = 14 (0EH) FWD TORQ S = 128 (80H) REV TORQ T = 65 (41H) REV TORQ S = 138 (84H) OFFSET TORQ = 56 (38H) END T HIGH = 128 (80H) END S HIGH = 128 (80H) END T LOW = 00 (00H) EMD S LOW = 00 (00H)	EQ-L-X1 = 64 (40H) REC-L-PCMA1 = EQ-H-X1 = 66 (42H) REC-L-PCMB1 = EQ-Q-X1 = 59 (3BH) REC-L-ATFA1 = EQ-P-X1 = 44 (2CH) REC-L-ATFB1 = EQ-L-X2 = 21 (15H) REC-T-PCMA1 =	217 (D9H) 16 (10H) 16 (10H) 217 (D9H) 217 (D9H) 16 (10H)
state.	PRE	SETTING IS COMPLETED!	
	RECORDER: NO TAPE		
	TEST ON		
	F1 F2 F3	F4 F5 F6	F7

2. PLUNGER CHECK

Equipment and Tools: Not required
Test Tape: Not required

	Procedure			. :		Checks				
(1)	Using the ↑ and ↓ keys, select	EL D	isplay		·					
	"2. PLUNGER CHECK".	,								~1
			RECORDE	R ADJUSTME	TV	2. PLUNGER	CHECK			
(2)	Press the F1 (TEST ON) key.			GER KICK GER RELEAS	E	PASS PASS				
(2)	Check the equal produced when the		PEUN	OCK KELEAS	E	LV22				
(3)	Check the sound produced when the		RECORDE	R: NO TAPE						
	plunger starts operating.		TEST OFF							
	Check the results displayed on the EL	ا								_
	display.		F1	F2	F3	F4	F 5	F6	F 7	
(4)	Press F1 (TEST OFF) key.									
		Resu	its Displaye	d: PASS	.Normal					
L .				FAULT.	.Failure					

3. MECHANICAL DEVICE TEST

Equipment and Tools: Not required

Test Tape

: Blank cassette (Refer to "4-2-1. Preparations".)


	Procedure	Checks
(1)	Using the 1 and 1 keys, select "3. MECHANICAL DEVICE TEST".	EL Display
(2)	Press the F1 (TEST ON) key. Insert the blank cassette. The mechanical device test will be carried out and the results will be displayed on the display. After the display, the blank cassette will automatically be ejected.	RECORDER ADJUSTMENT 3. MECHANICAL DEVICE TEST CASSETTE UP SWITCH PASS CASSETTE DOWN SWITCH PASS ROTARY ENCORDER PASS DRUM MOTOR PASS CAPSTAN MOTOR PASS SUPPLY REEL MOTOR PASS TAKEUP REEL MOTOR PASS RECORDER: NO TAPE
(4)	After checking the display, press the	TEST OFF F1 F2 F3 F4 F5 F6 F7
	F1 (TEST OFF) key.	Results Displayed: PASSNormal FAULTFailure
		Note: When the mechanical device test mode has been set, until it has been executed, the next mode cannot be set.


4. RECOGNITION SWITCH CHECK

Equipment and Tools: Not required

Test Tape : Test tape

: Test tape (01010) (Refer to "4-2-1. Preparations".) Test tape (10101) (Refer to "4-2-1. Preparations".)





5. END SENSOR LEVEL CHECK (HIGH)

Equipment and Tools: Not required

Test Tape : Blank cassette (Refer to "4-2-1. Preparations")

	Procedure	Checks/Specifications
(1)	Using the 1 and 1 keys, select "5.	EL display
(2)	END SENSOR LEVEL CHECK (HIGH)*. Press the F1 (TEST ON) key.	RECORDER ADJUSTMENT 5. END SENSOR LEVEL CHECK (HIGH) T-END SENSOR LEVEL = X. XX V (XXH)
(3)	Insert the blank cassette. The sensor level will be displayed on the EL display. Check that the sensor level	S-END SENSOR LEVEL = X. XX V (XXH) RECORDER: SBOFF TEST OFF
	satisfies the specification.	F1 F2 F3 F4 F5 F6 F7
(4)	Press the F1 (TEST OFF) key. The cassette will be ejected automatically.	Specification: Sensor level: 1.0 V and higher

6. END SENSOR LEVEL CHECK (LOW)

Equipment and Tools: Not required

Test Tape : Test

! Test tape (end sensor (LOW)) (Refer to "4-2-1. Preparations".)

	Procedure	Checks/Specifications
(1)	Using the 1 and 1 keys, select "6. END SENSOR LEVEL CHECK (LOW)".	EL Display
(2)	Press the F1 (TEST ON) key.	RECORDER ADJUSTMENT 6. END SENSOR LEVEL CHECK (LOW) T-END SENSOR LEVEL = X. XX V (XXH) S-END SENSOR LEVEL = X. XX V (XXH)
(3)	Insert the test tape (end sensor (LOW)). Note: Use the test tape (end sensor (LOW)) around the center of the	RECORDER: SBOFF TEST OFF
	take up side. The sensor level will be displayed	F1 F2 F3 F4 F5 F6 F7
	on the EL display. Check that the sensor level satisfies the specification.	Specification: Sensor level = Less than or equal 0.2 V
(4)	Press F1 (TEST OFF) key. The tape will be ejected automatically.	

7. DEW SENSOR CHECK

Equipment and Tools: Not required **Test Tape**: Not required

Procedure	Checks/Specifications					
(1) Using the 1 and ↓ keys, select "7. DEW SENSOR CHECK".	EL Display					
	RECORDER ADJUSTMENT 7. DEW SENSOR LEVEL CHECK					
(2) Press the F1 (TEST ON) key. The sensor level will be displayed on the	DEW SENSOR LEVEL = X. XX V (XXH)					
EL display.	RECORDER: NO TAPE					
Check that the sensor level satisfies the	TEST OFF					
specification.	FI F2 F3 F4 F5 F6 F7					
(3) Press the F1 (TEST OFF) key.	Specification: Sensor level = 0.1 V < X.XX V < 0.4 V Displayed level					

8. REEL TORQUE CHECK

Equipment and Tools: Not required

Test Tape

: Torque cassette TW-7231

	Procedure	Checks/Specifications
(1) U:	sing the 1 and 4 keys, select	EL Display (TEST ON display)
1 ' '	REEL TORQUE CHECK".	
		RECORDER ADJUSTMENT 8. REEL TORQUE CHECK
(2) P	ress the F1 (TEST ON) key.	CHECK OFF □ REEL TORQUE CHECK FF L (1.5V)
(3) In	nsert the torque cassette (TW-7231).	CHECK OFF REEL TORQUE CHECK REW L (1.5V) CHECK OFF REEL TORQUE CHECK FF H (4.3V)
		CHECK OFF REEL TORQUE CHECK FF L (4.3V)
		CHECK OFF OFFSET TORQUE
		RECORDER: SBOFF
		TEST OFF
		FI F2 F3 F4 F5 F6 F7
		T. TAKE UP and side C. CUPPUV real side
1 ' '	Using the ① and ↓ keys, select "REEL TORQUE CHECK FF L". Check that the	Note: T = TAKE UP reel side, S = SUPPLY reel side
1 '		Specification: T-REEL torque = 0.0004 to 0.001 N·m (4 to 10 g·cm)
	orque value of the torque cassette T-side reel) satisfies the specification	Specification, PREEL torque = 0.0004 to 0.007 K III (4 to 10 g sin)
1	(shown on the right side).	
<u> </u>	Using the 1 and ↓ keys, select "REEL	Specification: S-REEL torque = 0.0004 to 0.001 N·m (4 to 10 g·cm)
1 ' '	TORQUE CHECK REW L".	opositionion of them to specific to see the second of the
	Check that the torque value of the torque	
1	cassette (S-side reel) satisfies the	
	specification (shown on the right side).	
<u> </u>	Using the ↑ and ↓ keys, select "REEL	Specification: T-REEL torque = 0.0026 N·m and higher (26 g·cm and higher)
•	TORQUE CHECK FF H*.	
(Check that the torque value of the torque	
•	cassette (T-side reel) satisfies the	3
L	specification (shown on the right side).	
(7)	Using the 1 and ↓ keys, select "REEL	Specification: S-REEL torque = 0.0026 N·m and higher (26 g·cm and higher)
	TORQUE CHECK REW H".	·
	Check that the torque value of the torque	
	cassette (S-side reel) satisfies the	
	specification (shown on the right side).	
(8)	Press the F1 (TEST OFF) key.	
	The torque cassette will be ejected	
	automatically.	

9. FWD/REV TORQUE ADJUSTMENT

Equipment and Tools: Not required

Test Tape : Torque cassette TW-7131

	Procedure	Checks/Specifications	
(1)	Using the ↑ and ↓ keys, select "9. FWD/REV TORQUE	EL Display (TEST ON display)	
	ADJUSTMENT".	RECORDER ADJUSTMENT 9. FWD/RVS TORQUE ADJUSTMENT	
(2)	Press the F1 (TEST ON) key.	FWD T-REEL TORQUE = XXX (XXH) FWD S-REEL TORQUE = XXX (XXH) REV T-REEL TORQUE = XXX (XXH) REV T-REEL TORQUE = XXX (XXH)	
(3)	Insert the torque cassette (TW-7131).	OFFSET TORQUE = XXX (XXH) RECORDER: PLAY	
		TEST OFF ↑ ↓	
		F1 F2 F3 F4 F5 F6 F7	
(4)	Using the 1 and 1 keys, select "FWD T-REEL TORQUE".	Specification: T-REEL torque = 0.00050 ±0.00005 N·m (5.0 ±0.5 g·cm) Adjustment: Use the F6 (UP) and F7 (DOWN) keys.	
(5)	Press the PLAY key.		
(6)	Using the $\widehat{\ \ }$ and $\widehat{\ \ }$ keys, select	Specification: S-REEL torque = 0.00065 ±0.00005 N·m (6.5 ±0.5 g·cm)	
	"FWD S-REEL TORQUE".	Adjustment: Use the F6 (UP) and F7 (DOWN) keys.	
(7)	Using the and keys, select	Specification: T-REEL torque = 0.0013 ±0.0001 N·m (13 ±1 g·cm)	
	"REV T-REEL TORQUE".	Adjustment: Use the F6 (UP) and F7 (DOWN) keys.	
(8)	Press SHUTTLE (-1)		
	(PGM SEARCH key).		
(9)	Using the 1 and ↓ keys, select	Specification: S-REEL torque = 0.0008 ±0.0001 N·m (8 ±1 g·cm)	
	"REV S-REEL TORQUE".	Adjustment: Use the F6 (UP) and F7 (DOWN) keys.	
(10	Press the F1 (TEST OFF) key.		
	The torque cassette (TW-7131)		
	will be ejected automatically.		

10. DRUM/CAPSTAN SPEED & WOW CHECK (10. Correct Rotation Check)

Equipment and Tools: Not required

Test Tape

: Blank cassette (Refer to "4-2-1. Preparations".)

Procedure	Checks/Specifications
(1) Using the ↑ and ↓ keys, select "10. DRUM/CAPSTAN SPEED & WOW CHECK."	RECORDER ADJUSTMENT 10. DRUM/CAPSTAN SPEED & WOW CHECK
(2) Press the F1 (TEST ON) key.	DRUM SPEED = 2000 rpm RECORDER: PLAY
(3) Insert the blank cassette.	TEST OFF SPEED
	F1 F2 F3 F4 F5 F6 F7
(4) Press the PLAY key.	Check: While rotating the drum in the clockwise direction slowly, check that the drum rotates correctly. (When the drum is stopped with your finger, it must rotate when you release your finger regardless of its position.)

11. TAPE PATH ADJUSTMENT

Equipment and Tools:


Oscilloscope

Adjusting screwdriver (J-6225-100-A)

Test Tape:

Test tape TY-7251

Connection



Procedure				Check	cs/Specific	ations		
(1) Connect the oscilloscope to the	EL Display	У						
following points of the RF-53 assembly.		RECORDER	R ADJUSTMEN	IT :	II. TAPE P	ATH ADJUST	MENT	
Oscilloscope RF-53 assembly CH1 → TP1 (RF-A)		ATF (OFFSET = 0 S					
CH2 → TP2 (RF-D)		RECORDER	R: PLAY					
CH3 \rightarrow TP3 (SWP-A, TRIG)		TEST OFF		0%	50%	100%		
Connect the GND to the metal plate, etc. of the mechanism deck.		FI	F 2	F3	F4	F5	F6	F7
(2) Using the ↑ and ↓ keys, select								
"11. TAPE PATH ADJUSTMENT".								
(3) Press the F1 (TEST ON) key.								
(4) Insert the test tape (TY-7251).								
(5) Press the PLAY key.	Specifica	tion: Adjust	the RF way	reform (TP1	1) so that it	becomes s	quare.	
				•				
				RF v	waveform (TP1)	_	
				4+ 24 U	i de la companya de l			
				50				
	Adjustme	ent: Adjust th	ne height of	the S1 and	T1 guides	finely with t	he adjustin	g screwdriver

	Press the F5 (100%) key. (ATF OFF)	Check: Check that the RF waveform (TP1) changes parallel.
	,	
		Adjustment: Adjust the height of the S1 and T1 guides so that the RF waveform changes parallel.
(7)	Press the F4 (50%) key. (ATF OFFSET)	Check: Check that the RF waveform (TP1) satisfies the following specification.
		Specification: The RF waveform becomes rectangular at its 50% height.
		Distortion including fluctuations should be within 10% against the flat part.
		A B RF waveform (TP1)
		Specification: B/A × 100 (%) ≥ 80%
(8)	Press the F3 (0%) key. (ATF ON)	Check (specification): The RF waveform (TP1) becomes stable within two seconds.
(9)	Press the SHUTTLE (-16) (PREVIOUS key).	
(10)	Check the rising time of the RF	
(,	waveform when press the	
	PLAY key.	
(11)	Press the EJECT key and eject the test tape.	Check (Specification): The RF waveform becomes stable within 2 seconds.
	Langet the Acat to 2 - 1994 man 11	
(12)	Insert the test tape (TY-7251), press the PLAY (PLAY mode)	
	key, and check the rising time of	
	the RF waveform (PLAY mode).	
(13)	Press the F1 (TEST OFF) key.	
	The test tape (TY-7251) will be	
	ejected automatically.	

12. SWP POSITION ADJUSTMENT

Equipment and Tools:

Oscilloscope

Test Tape:

Test tape TY-7251

Connection

Same as "11. TAPE PATH ADJUSTMENT".

Procedure	Adjustments/Checks/Specifications
(1) Connect the oscilloscope to the following points of the RF-53	EL Display
assembly.	RECORDER ADJUSTMENT 12. SWP POSITION ADJUSTMENT
Oscilloscope RF-53 ASSY	CAME POSITION AND VALUE
CH1 → TP1 (RF-A)	SWP POSITION = XXX (XXH)
CH2 → TP2 (RF-D)	RECORDER: PLAY
(Only the recorder)	TEST OFF
CH3 → TP3 (SWP-A, TRIG)	F1 F2 F3 F4 F5 F6 F7
(2) Press the F1 (TEST ON) key.	
(3) Insert the test tape (TY-7251).	
(4) Press the PLAY key.	Specification: Time (T) between the falling edge of the SWP and the falling edge of the marker
Adjust the SWP position with the	of the RF waveform
F6 (UP) key and F7 (DOWN)	$T = 650 \pm 15 \mu s$
key.	CH3(TRIG): TP3 (SWP-A) CH3(TRIG): TP3 (SWP-A) Adjustment: Press the SHIFT key + F6 (UP) key or the F7 (DOWN) key. (Adjustment consisting of ten steps at a time) Press the F6 (UP) key or F7 (DOWN) key.
	(Adjustment consisting of one step at a time)
(5) Press the F1 (TEST OFF) key.	
The test tape (TY-7251) will be	
ejected automatically.	

13. PATH & FF/REW TIME CHECK

Equipment and Tools:

Oscilloscope

Test Tape:

Test tape (TOP) (Refer to "4-2-1. Preparations".)
Test tape (END) (Refer to "4-2-1. Preparations".)

Test tape (FF/REW TIME) (Refer to "4-2-1. Preparations".)

Connection

Same as "11. TAPE PATH ADJUSTMENT".

	Procedure	Adjustments/Checks/Specifications
(1)	Connect the oscilloscope to the following points of the RF-53	EL Display
Osc	assembly. iilloscope RF-53 ASSY	RECORDER ADJUSTMENT 13. PATH & FF/REW TIME CHECK
	CH1 → TP1 (RF-A) CH3 → TP3 (SWP-A, TRIG)	FF TIME = 0 SEC REW TIME = 0 SEC
(2)	Using the ↑ and ↓ keys, select	RECORDER: NO TAPE
	"13. FF/REW TIME CHECK".	TEST OFF
(3)	Press the F1 (TEST ON) key.	F1 F2 F3 F4 F5 F6 F7
(4)	Insert the test tape (TOP).	
(5)	Repeat pressing SHUTTLE (+1) (LOCATE key) and SHUTTLE (-1)	Specification: The tape should not be curled and not come off the guides before and after the pinch roller.
	(PGM SEARCH key)	
	alternately.	
	Check that the tape running	
	satisfies the specification.	
(0)	Repeat pressing SHUTTLE (+16) (NEXT key)	Specification: The tape should not be curled and not come off the guides before and after the
	and SHUTTLE (-16)	pinch roller.
	(PREVIOUS key) alternately.	
	Check that the tape running	
	satisfies the specification.	``
(7)	Press the EJECT key and eject	
, ,	the test tape (TOP).	
(8)	Insert the test tape (END).	Specification: The tape should not be curled and not come off the guides before and after the pinch roller.
(9)	Repeat pressing SHUTTLE (+1)	prior ora.
	SHUTTLE (-1)	
	(PGM SEARCH key)	
	alternately.	
	Check that the tape running	

(10) Repeat pressing	Specification: The tape should not be curled and not come off the guides before and after the
SHUTTLE (+16)	pinch roller.
(NEXT) key) and	
SHUTTLE (-16)	
(PREVIOUS key) alternately.	
Check that the tape running	
satisfies the specification.	
(11) Press the EJECT key and	
eject the test tape (END).	
(12) Insert the test tape (FF/REW	
TIME).	
(13) Fast forward and rewind the	Specification: Take up time of tape fast forwarded = Less than 20 seconds.
tape with the REW key or	Take up time of tape rewound = Less than 20 seconds.
FF key and check that the	Check with the RF waveform of the oscilloscope that the tape contacts the head
tape rewind time satisfies the	correctly during FF and REW.
specification.	
(14) Press the F1 (TEST OFF) key.	
The test tape (FF/REW TIME)	
will be ejected automatically.	

14. PB ERROR RATE CHECK

Equipment and Tools: Oscilloscope

Test Tape : Test tape TY-7212

Note: 1. Be sure to mount the top plate when measuring the error rate.

2. Before performing checks, use the cleaning tape and clean for ten seconds.

	Procedure			Adj	ustmen	ts/Checks/Spec	ifications			
(1)	Using the ↑ and ↓ keys,	EL Displa	у						·	
	select "14. PB ERROR RATE	_								
	CHECK".		RECORDER	ADJUSTMENT	Γ	14. PB ERROR I	RATE CHECK	(
			DEQ-L-	X1-L = 64 ((40H)	PB SPEED	X 1			
(2)	Press the F1 (TEST ON) key.		•	XI-H = 66 (
				X1-Q = 59 (PB HEAD	LEADIN	G		
(3)	Insert the test tape (TY-7212).	}	EQ-r-2	K1-P = 44 (2CH)	ERROR RATE	A-CH X	YE.V		
(-)			EQ-L-	X2-L = 21 ((15H)	DRAVE RAID	B-CH X			
			-	X2-H = 44 (
				X2-Q = 37						
			EQ-P-1	K2-P = 21 ((15H)					
			RECORDER	: PLAY		TIME CODE: 0	0:10:5	8:40		
			TEST OFF			HEAD		1	1	
			F1	F2	F3	F4	F5	F6	F7	
(4)	Press the PLAY key and check	Specifica	tion: Playba	ck error rate	A-CH =	Less than or eq	ual 5 × 10	-3		
	that the specification is satisfied.					(Display: Less t				
			Playba	ick error rate	B-CH =	Less than or eq				
						(Display: Less t	han or equ	al 5E-3)		
(5)	Press the STOP key.									
(6)	Press the F4 (HEAD) key and	Specifica	tion: Playba	ick error rate	A-CH =	Less than or eq	ual 5 × 10	-3		
	check that "PB HEAD					(Display: Less t	han or equ	al 5E-3)		
	check that "PB HEAD TRAILING" is displayed.		Playba	ack error rate	B-CH =	·	•	,		
		-	Playba	ack error rate	B-CH =	(Display: Less t Less than or eq	ual 5 × 10	-3		
(7)	TRAILING" is displayed.		Playba	ack error rate	B-CH =	(Display: Less t	ual 5 × 10	-3		
(7)	TRAILING" is displayed.		Playba	ack error rate	B-CH =	(Display: Less t Less than or eq	ual 5 × 10	-3		
	TRAILING" is displayed. Press the PLAY key and check		Playba	ack error rate	B-CH =	(Display: Less t Less than or eq	ual 5 × 10	-3		- -
(8)	TRAILING" is displayed. Press the PLAY key and check that the specification is satisfied. Press the STOP key.		Playba	ack error rate	B-CH =	(Display: Less t Less than or eq	ual 5 × 10	-3		
	TRAILING" is displayed. Press the PLAY key and check that the specification is satisfied. Press the STOP key.		Playba	ack error rate	B-CH =	(Display: Less t Less than or eq	ual 5 × 10	-3		

15. REC CURRENT ADJUSTMENT (LEADING) (RECORDER deck only)

Equipment and Tools:

Oscilloscope RF level checker PD-817 I/F box PF-534 for the RF level checker

Test Tape:


Test tape TY-7111DX Test tape TY-30BX

Connection

Connect the parts with the power switch of PCM-E7700 off.

Remove the key panel assembly when connecting the RF-534 cable (15P) of the I/F box to CN302 on the SSP-8 board.

When performing adjustments, make sure that the cable (15P) is not caught and the key panel assembly is attached to the unit.



	Procedure				Adjustmer	nts/Checks/S	Specification	ns	
(1)	Using the ↑ and ↓ keys, select "15. REC CURRENT	EL Displa	ay						
	ADJUSTMENT (LEADING)".		RECORDE	R ADJUSTM	ENT	15. REC CI	JRRENT ADJ	USTMENT (LI	ADING)
(2)	Press the F1 (TEST ON) key.		REC REC	CURRENT CURRENT CURRENT CURRENT	PCM-A PCM-B ATF-A ATF-B	XXX (XXH XXX (XXH XXX (XXH)		
(3)	Insert the test tape				VIL-D	XXX (XXH			
	(TY-7111DX).		RECORDE			TIME CODE	E: 00 : 10	:58:40 	
(4)	According to the calibration		F1	F2	F3	F4	F5	F 6	F7
	values table attached to the test		• •		• • •				
	tape, set the calibration value								
	with the OFF SET dial of the RF					•			
	level checker (PD-817).*1								
5)	Press the PLAY key.								
	Check that the RF waveform								
	(oscilloscope) is stable.								
6)	Press the CAL key of the RF								
	level checker (PD-817).								

(7) After completing CAL, and the LED of the CAL key stops blinking and lights up, press the EJECT key and eject the test tape (TY-7111DX). (8) Insert the test tape (TY-30BX, Specification: PCM-A and PCM-B recording level = 0.5 ±0.5 dB blank area). ATF-A and ATF-B recording level = -0.5 ± 0.5 dB (9) Press the LEADING (A/B) key RF Level Checker Level Meter Display of the RF level checker (PD-817). PCM ATF The PCMATF (Ach, Bch) recording current level of the leading head will be measured automatically (Self recording and playback). (10) After measuring, the indicator of the LEADING key will stop blinking and light up and Adjustment: Using the 1 and 1 keys, select values that do not satisfy the specification, and the recording level will be adjust with the F6 and F7 keys as follows. displayed on the level meter of To raise the recording level: Press the F6 (UP) key the RF level checker. Repeat steps (8), (9), and (10) so that To lower the recording level: Press the F7 (DOWN) key the recording level satisfies the specification. (11) Press the F1 (TEST OFF) key. The test tape (TY-30BX) will be ejected automatically.

*1: Setting of the offset dial


According to the table of calibration values attached to the test tape (TY-7111DX), set the calibration values of the 1.57 MHz and 130 kHz Ach/Bch with the RF level checker offset dial.

Setting Example

Display of Calibration Values

	130.7 (kHz)	1.568 (MHz)
Ach	-0.1	-0.3
Bch	+0.2	+0.2

Setting the offset dial (For the above calibration values)



PCM-7040

16. REC CURRENT ADJUSTMENT (TRAILING) (RECORDER deck only)

Equipment and Tools:

Oscilloscope RF level checker PD-817 L/F box PF-534 for the RF LEVEL CHECKER

Test Tape:

Test tape TY-30BX Test tape TY-7111DX

Connection

Same as "15. REC CURRENT ADJUSTMENT (LEADING)".


	Procedure				Adjustme	nts/Checks/	Specification	ons	
(1)	Using the ↑ and ↓ keys,	EL Displa	ay						
	select "16. REC CURRENT	Г	~						
	ADJUSTMENT (TRAILING)".		RECORDE	R ADJUSTM	ENT	16. REC CU	RRENT ADJU	JSTMENT (TR	(AILING)
(2)	Press the F1 (TEST ON) key.		REC REC	CURRENT CURRENT CURRENT	PCM-A PCM-B ATF-A	XX XX XX			
(3)	Insert the test tape (TY-7111DX).		REC	CURRENT R: REC	ATF-B	XX TIME CODE	E: 00 : 10	58:40	
(4)	According to the table of		TEST OF	F				1	
	calibration values attached to the test tape, set the calibration		FI	F2	F3	F4	F5	F6	F7
	value with the OFF SET dial of								
	the RF level checker (PD-817).*1								
	(*1: See page 4-25.)								
5)	Press the PLAY key.								
	Check that the RF waveform								
	(oscilloscope) is stable.								
(6)	Press the CAL key of the RF								
	level checker (PD-817).				3				
(7)	After completing CAL, and the								
	LED of the CAL key stops								
	blinking and lights up, press the								
	EJECT key and eject the test								

- (8) Insert the test tape (TY-30BX, blank area).
- (9) Press the TRAILING (A/B) key of the RF level checker (PD-817). The PCM/ATF (Ach, Bch) recording current level of the trailing head will be measured automatically (Self recording and playback).
- (10) After measuring, the indicator of the TRAILING key will stop blinking and light up and the recording level will be displayed on the level meter of the RF level checker. Repeat steps (8), (9), and (10) so that the recording level satisfies the specification.
- (11) Press the F1 (TEST OFF) key.

 The test tape (TY-30BX) will be ejected automatically.

Specification: PCM-A and PCM-B recording level = 0.5 ± 0.5 dB ATF-A and ATF-B recording level = -0.5 ± 0.5 dB

RF Level Checker Level Meter Display



Adjustment: Using the 1 and 1 keys, select values that do not satisfy the specification, and adjust with the F6 and F7 keys as follows.

To raise the recording level: Press the F6 (UP) key

To lower the recording level: Press the F7 (DOWN) key

17. REC/PB ERROR RATE CHECK

Equipment and Tools:

Not required

Test Tape:

Test tape TY-30BX

Note: 1. Be sure to mount the top plate when measuring the REC/PB ERROR RATE.

2. Before performing checks, clean the head with a cleaning tape.

	Procedure			Ac	ijustmen	ts/Checks/S	pecificatio	ns		
(1)	Using the ↑ and ↓ keys, select "17. REC/PB ERROR	EL Displ	ay							
(2)	RATE CHECK". Press the F1 (TEST ON) key.		RECORDER	ADJUSTME!	NT	17. REC/PB	ERROR RAT	E CHECK		
(3)			REC SP	PEED		XI				
	Check that "REC HEAD		REC HI	EAD		LEADING				
·	LEADING" is displayed.		ERROR (TRAIL			A-CH X. XE B-CH X. XE				
			RECORDER	: REC		TIME CODE	: 00:10	: 58:40		
			TEST OFF		SPEED	HEAD				
			FI	F2	F3	F4	F5	F6	F 7	_
5)	Press the PLAY key.	Specific	ation: Error ra	ite A-CH =		 splay) an or equal 5	× 10-3\			
6)	Press the AUDIO EDIT key and check that the error rate of the trailing head playback during the leading head recording (X1) satisfies the specification.			B-CH =	5E-3 (Dis		,			
7)	Press the STOP key.									
8)	Press the $\boxed{\text{F4}}$ (HEAD) key and check that "REC HEAD TRAILING" is displayed.									
9)	Press the PLAY key.									
10	Press the AUDIO EDIT key									
	and record for twenty seconds.	Ì			· .					
11	and record for twenty seconds. Press the STOP key.				•					
					•					
12	Press the STOP key. Press SHUTTLE (-2) ([4] key) and rewind until the part where recording starts. Note: Rewind according to the	Specific	cation: Error ra		: 5E-3 (Dis (Less tha : 5E-3 (Dis	n or equal 5	,			
12	Press the STOP key. Press SHUTTLE (-2) ([4] key) and rewind until the part where recording starts. Note: Rewind according to the TIME CODE displayed. Press the PLAY key, playback the trailing head recording part, and check that the playback error rate satisfies the	Specific	eation: Error ra		: 5E-3 (Dis (Less tha : 5E-3 (Dis	n or equal 5 play)	,			

18. SERVO DATA SAVE

Equipment and Tools: Not required
Test Tape: Not required

	Procedure	Checks	
(1)	Turn on the S1-2 (BIT SW2) switch of		
	the SV-147A board and check that it is		
	on at the top right of the display (Menu		
	of adjustments).		
(2)	Using the $ \uparrow $ and $ \downarrow $ keys, select	EL Display	
	"18. SERVO DATA SAVE".		
		RECORDER ADJUSTMENT 18. SERVO DATA SAVE	
(3)	Press the F1 (TEST ON) key.	SWP POSITION = 117 (75H) EQ-L-X1 = 64 (40H) REC-L-PCMA1 = 217	(DOU)
	Check that "MESSAGE: SAVING IS	EQ-H-XI = 66 (42H) REC-L-PCMB1 = 217	
		, , , , , , , , , , , , , , , , , , , ,	(10H)
	COMPLETED!" is displayed.		(10H)
		REV TORQ T = $65 (41H)$	
(4)	After checking, press the F1 (TEST	REV TORQ S = 138 (84H) EQ-L-X2 = 21 (15H) REC-T-PCMA1 = 217	(D9H)
()		BACK TENTION = 56 (38H) EQ-H-X2 = 44 (2CH) REC-T-PCMB1 = 217	, ,
	OFF) key.		(10H)
		END T HIGH = 128 (80H) EQ-P-X2 = 21 (15H) REC-T-ATFB! = 16 END S HIGH = 128 (80H)	(10H)
(5)	Set the S1 switch of the SV-147A board	END T LOW = 00 (00H)	
(-)		EMD SLOW = 00 (00H)	
	as follows.		
	S1-1 to S1-4: All off	MESSAGE	
		SAVING IS COMPLETED!	
		RECORDER: NO TAPE	
		TEST OFF	
		F1 F2 F3 F4 F5 F6	F 7

19. SERVO DATA DISPLAY

Equipment and Tools: Not required
Test Tape: Not required

Note: The servo data display is used for checking the servo data.

By executing it during adjustments, adjustment values can be checked even without saving.

	Procedure	Check
(1)	5 <u> </u>	EL Display
	"19. SERVO DATA DISPLAY".	
		RECORDER ADJUSTMENT 19. SERVO DISPLAY
(2)	Press the F1 (TEST ON) key.	SWP POSITION = 117 (75H) EQ-L-XI = 64 (40H) REC-L-PCMAI = 217 (D9H)
		EQ-H-X1 = 66 (42H) REC-L-PCMB1 = 217 (D9H)
· ·		FWD TORQ T = 14 (0EH) EQ-Q-X1 = 59 (3BH) REC-L-ATFA1 = 16 (10H)
(3)	Check the servo data on the display.	FWD TORQ S = 128 (80H) EQ-P-XI = 44 (2CH) REC-L-ATFB1 = 16 (10H)
		REV TORQ T = $65 (41H)$
(A)	Press the F2 (EXIT) key.	REV TORQ S = 138 (84H) EQ-L-X2 = 21 (15H) REC-T-PCMAI = 217 (D9H)
(*)	Fless the [FZ] (EATT) key.	BACK TENTION = 56 (38H) EQ-H-X2 = 44 (2CH) REC-T-PCMB1 = 217 (D9H)
		EQ-Q-X2 = 37 (25H) REC-T-ATFA1 = 16 (10H)
		END T HIGH = 128 (80H) EQ-P-X2 = 21 (15H) REC-T-ATFB1 = 16 (10H)
		END S HIGH = 128 (80H)
		END T LOW = 00 (00H)
		EMD S LOW = 00 (00H)
		RECORDER: NO TAPE
		EXIT
		F1 F2 F3 F4 F5 F6 F7

4-30(E)

4-2-3. Checking after SV-147A board replacement

When replacing the SV-147A board of PCM-7040 mechanism deck assy, be sure to perform the following checks before adjusting the PCM-7040 mechanism deck assy.

Equipment and Tool:

Not required

Test Tape:

Blank cassette (Refer to "4-2-1. Preparations".)

Servo microprocessor operations check

- (1) Set the BIT switch S1-3 on the SV-147A board (PCM-7040 mechanism deck assy) to ON.
- (2) Turn ON the power of the PCM-E7700.
- (3) Check that LED (D1) on the SV-147A board blinks every second.
- (4) Insert the blank cassette, and set the BIT switch S1-1 on the SV-147A board to ON.
- (5) Check that the blank cassette is ejected, and set the BIT switch S1-1 to OFF.

After completing the above, adjust and check according to "4-2. Adjustments and checks".

5 1 .

Section 5 Electrical Alignment

This section describes the following electrical adjustment when SSP-11 board is repaired or maintained.

SSP-11 board adjustment items

- 5-2. Signal processing block adjustment
 - 5-2-1. Master clock adjustment
 - 5-2-2. Timer clock adjustment
 - 5-2-3. RF PLL adjustment
- 5-3. AD/DA block adjustment
 - 5-3-1. AD conversion level adjustment ·
 - 5-3-2. DA conversion level adjustment
 - 5-3-3. C.M.R.R adjustment
 - 5-3-4. Output balance adjustment
- 5-4. Time code output level adjustment

5-1. Preparation

5-1-1. Equipment

Equipment	Specification	Model name
Oscilloscope	Frequency:DC to 150 MHz Dual trace or more (Add mode)	TEKTRONIX 2445A or equivalent
Audio analyzer	• AF Oscillator Range:10 to 100 kHz Level:-70 to +24 dBm • Level meter	TEKTRONIX SG505 (OP2), AA501 or equivalent
Frequency counter	Effective digits:8 digits or more	ADVAN TEST TR5822, HEWLETT PACKARD 531 5A or equivalent

5-1-2. Switch and Control Initial Setting

Front panel

Switches

REMOTE (9P)/LOCAL

; LOCAL

SYNC EXT/INT/VIDEO

; INT

AUDIO INPUT ANALOG/DIGITAL

; ANALOG

SAMPLING FREQ 44.1 kHz/48 kHz

; 48 kHz

Controls

ANALOG CH-1 input level; Center click position ANALOG CH-2 input level; Center click position

SSP-11 board

AD/DA block

S51 switch: NORMAL

S101 switch; +4

S201 switch; +4

S102 switch; +4

S202 switch; +4

CPU-268 board

S11 switch;

ON (600Ω)

S21 switch;

ON (600Ω)

5-2. Signal Processing Block Adjustment

To perform the adjustments, first remove the top panel.

5-2-1. Master Clock Adjustment


This section describes the oscillation frequency adjustments of X'tal which generates the Fs system clock of master clock block.

Perform the adjustment/checking when SSP-11 board and master clock block components (X401, 402, CT401, 402 and peripheral components) are replaced.

Equipment required

Frequency counter

Connection



Switch and control setting

Same as "5-1-2. Switch and Control Initial Setting" except the followings:

Front panel

REMOTE (9P)/LOCAL switch


; LOCAL

SYNC EXT/INT/VIDEO switch

: INT

SAMPLING FREQ 44.1 kHz/48 kHz switch ; 48 kHz

Adjustment Location



Adjustment procedure

Adjustment condition	Specification	Adjustment (SSP-11 board)
Step 1 Disconnect the connecting cables of rear panel. Connect the frequency counter to the TP50 (C5)/SSP-11 board. SAMPLING FREQ. switch(Front panel): 48 kHz	Check that the frequency at TP50 (C5) satisfies the following specification (47999.76 to 48000.24 Hz). If the specification are not satisfied, adjust the CT401 (C4). Specification (frequency at TP50) Fs (48 kHz) = 48000.00 ±0.24 Hz	⊘ CT401 (C4)
Step 2 The settings remain in the same as step 1 except the following. • SAMPLING FREQ. switch(front panel) : 44.1 kHz	 Check that the frequency at TP50 (C5) satisfies the following specification (44099.78 to 44100.22 Hz). If the specifications are not satisfied, adjust the CT402 (D4). Specification (frequency at TP50) Fs (44.1 kHz) = 44100.00 ±0.22 Hz 	⊘ CT402 (D4)

5-2-2. Timer Clock Adjustment

Perform the adjustment/checking when SSP-11 board and time clock block components (X304, CT301 and peripheral components) are replaced.


Equipment required

Frequency counter

Switch and control setting

This has no switches and controls that need to be set during adjustment.

Connection/Adjustment Location



Adjustment procedure

Adjustment condition	Specification	Adjustment (SSP-1 board)
Connect the frequency counter to the TP36 (C2) SSP-11 board.	Check that the frequency at TP36 (C2) satisfies the following specification (2047.99 to 2048.01 Hz). If the specifications are not satisfied, adjust the CT301 (C2).	⊘ CT301 (C2)
	Specification Frequency at TP36 = 2048.00 ±0.01 Hz	

5-2-3. RF PLL Adjustment

The RF PLL block generates the clock for extracking the playback data from the head. In correspondence to the head/RF amplifier characteristics, adjust the RF PLL block to obtain the best error rate.

Perform this adjustment when replacing SSP-11 board and RFPLL block components, and replacing the mechanism assembly, drum assembly and RF assembly.

Preparation


Disconnect the connection plugs (COP401 and COP402) from the connection pins (COR401 and COR402) (D6) on the SSP-11 board. (See "Adjustment Location".)
 The connection plugs (COP401 and COP402) are to be reinserted after the RF PLL adjustment.

Equipment required

Oscilloscope

Pre-recorded music DAT tape (Fs = 48 kHz)

Connection




Switch and Control setting

Same as "5-1-2. Switch and Control Initial Setting" except the followings:

Front panel

REMOTE (9P)/LOCAL switch ; LOCAL SYNC EXT/INT/VIDEO switch ; INT SAMPLING FREQ 44.1 kHz/48 kHz switch ; 48 kHz

Adjustment Location



SSP-11 board (A-side)

1. Leading head RF PLL Adjustment

Adjustment Condition	Specification	Adjustment (SSP-11 board)
Step 1 Connect the oscilloscope as follows: Oscilloscope SSP-11 board CH1 → TP53 (D6) CH2 → TP512 (A3) (TRIGGER) Insert the pre-recorded music cassette tape (Fs = 48 kHz) and playback the tape. (PLAY mode)	TP53 (D6) output waveform OK NG NG NG TRIG: TP512 (A3)	⊘RV402 (D6) If the waveform is no good, turn ⊘RV401 slightly and their readjust ⊘RV402.
Step 2 Same as step 1.	TP53 (D6) output waveform This portion is to be flat. TRIG: TP512 (A3)	ØRV401 (C6)
Step 3 Same as step 1.	TP53 (D6) output waveform	9 LV402 (C6)
	Amplitude's center voltage where is RF.	Note: After being turned clockwise all the way, adjust @LV402 so that it can be loosened within one full turn. If it is too tight, the core may be damaged. And if it is too loose, the core may come off.
Step 4 • Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE FWD (X16 speed). • The connectings remain the same as step 1.	This portion is to be flat. TRIG: TP512 (A3)	ØRV402 (D6)
Step 5 • Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE REV (×16 speed). • The connectings remain the same as step 1.	This portion is to be flat. TRIG: TP512 (A3)	ØRV402 (D6)
Step 6 Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE FWD and CUE REV (X3 speed). Repeatedly two or three times. The connectings remain the same as step 1.	TP53 (D6) output waveform This portion is to be flat while the tape is running.	
	TRIG: TP512 (A3)	

2. Trailing head RF PLL Adjustment

Adjustment Condition	Specification	Adjustment (SSP-11 board)
Step 1 Connect the oscilloscope as follows: Oscilloscope SSP-11 board CH1 → TP55 (D6) CH2 → TP512 (A3) (TRIGGER) Insert the pre-recorded music cassette tape (Fs = 48 kHz) and playback the tape. (PLAY mode)	TP55 (D6) output waveform OK NG NG NG TRIG: TP512 (A3)	⊘RV404 (D6) If the waveform is no good, turn ⊘RV403 slightly and then readjust ⊘RV404.
Step 2 Same as step 1.	TP55 (D6) output waveform This portion is to be flat. TRIG: TP512 (A3)	⊘ RV403 (C6)
Step 3 Same as step 1.	TP55 (D6) output waveform - 3.0 ± 0.5V Amplitude's center voltage where is RF. TRIG: TP512 (A3)	Note: After being turned clockwise all the way, adjust OLV403 so that it can be loosened within one full turn. If it is too tight, the core may be damaged. And if it is too loose, the core may come off.
Step 4 • Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE FWD (×16 speed). • The connectings remain the same as step 1.	TP55 (D6) output waveform This portion is to be flat. TRIG: TP512 (A3)	ØRV404 (D6)
Step 5 • Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE REV (×16 speed). • The connectings remain the same as step 1.	TP55 (D6) output waveform This portion is to be flat. TRIG: TP512 (A3)	ØRV404 (D6)
Step 6 • Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set CUE FWD and CUE REV (X3 speed). Repeatedly two or three times. • The connectings remain the same as step 1.	TP55 (D6) output waveform This portion is to be flat while the tape is running. TRIG: TP512 (A3)	

3. RF PLL Fine Adjustment

Preparation:

Before performing the adjustment, turn off the POWER switch and reinsert the connection plugs (COP401 and COP402) into the connection pins (COR401 and COR402) on the SSP-11 board.


Then turn on the POWER switch and perform the adjustment.

Adjustment Condition	Specification	Adjustment (SSP-11 board)
Step 1 Connect the oscilloscope as follows: Oscilloscope SSP-11 board CH1 → TP55(D6) CH2 → TP512(A3) (TRIGGER) Insert the pre-recorded music cassette tape (Fs = 48 kHz) and playback the tape. (PLAY mode)	TP55 (D6) output waveform NO-signal portion RF portion	OLV401 (D5) Adjust OLV401 so that the center of the RF portion and no signal portion becomes flat. If the center cannot be flattened, redo the adjustments from steps 3 to 6 for "2. Trailing head RF PLL adjustment". Before making the re-adjustment, shift the center voltage within the adjustment standard range stated in step 3 of "2. Trailing head RF PLL adjustment".
	TRIG: TP512 (A3)	Note: After being turned clockwise all the way, adjust @LV401 so that it can be loosened within one full turn. If it is too tight, the core may be damaged. And if it too loose, the core may come off.
Step 2 Connect the oscilloscope as follows: Oscilloscope SSP-11 board CH1 → TP53(D6) CH2 → TP512(A3) (TRIGGER) Insert the pre-recorded music cassette tape (Fs = 48 kHz) and playback the tape. (PLAY mode)	TP53 (D6) output waveform NO-signal portion RF portion	Adjust OLV402 so that the center of the RF portion and no signal portion becomes flat. If the center cannot be flattened, redo the adjustments from steps 3 to 6 for "1. Leading head RF PLL adjustment". Before making the re-adjustment, shift the center voltage within the adjustment standard range stated in step 3 of "1. Leading head RF PLL adjustment". Note: After being turned clockwise all the way, adjust OLV402 so that it
	TRIG: TP512 (A3)	can be loosened within one full turn. If it is too tight, the core may be damaged. And if it too loose, the core may come off.
Step 3 Connect the oscilloscope as follows: Oscilloscope SSP-11 board CH1 → TP53(D6), TP55(D6) CH2 → TP512(A3) (TRIGGER) Insert the pre-recorded music cassette tape (Fs = 48 kHz) and set the FF and REW modes.	TP53 (D6) and TP55 (D6) output waveform OK	
	As the voltage is high, the waveform swings to plus. TRIG: TP512 (A3)	

5-3. AD/DA Block Adjustment

To perform the adjustments, first remove the top panel. Perform the adjustments according to the following adjustment procedure.


AD/DA Block adjustment procedure



Equipment required

Audio analyzer Oscilloscope

Connection



Switch and control setting

Same as "5-1-2. Switch and Control Initial Setting" except the followings:

Front panel

SAMPLING FREQ 44.1 kHz/48 kHz switch ; 48 kHz AUDIO INPUT ANALOG/DIGITAL switch ; ANALOG ANALOG CH-1 input level control

; click center position

ANALOG CH-2 input level control

; click center position

INPUT MONITOR key

; ON (LED lighting)

SSP-11 board (AD/DA block)

S101, S102, S201, S202 switches

; +4

S151 switch


; NORMAL

CP-268 board

S11, S21 switch

; ON (600Ω)

Adjustment Location



SSP-11 board (A-side)

5-3-1. AD Conversion Level Adjustment

Perform the AD block adjustments on the SSP-11 board, perform the adjustment first.

Preparation

Before performing the adjustment, set the FL tube display on the front panel as follows. For setting, refer to the operation manual.

FL tube display (front panel)

Au-rEF (input signal level's digital indication mode) EMPH OFF (emphasis OFF mode)

Adjustment condition	Specification	Adjustment (SSP-11 board)
Step 1	Value of the Au-rEF CH1 (left side) on the FL tube display	⊘ RV102 (F5)
 Input a 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG IN CH-1 connector from the audio analyzer (AF oscillator). 	~20.0 dB	
Step 2	Value of the Au-rEF CH2 (right side) on the FL tube display	⊘ RV202 (E6)
 Input a 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG IN CH-2 connector from the audio analyzer (AF oscillator). 	-20.0 dB	

5-3-2. DA Conversion Level Adjustment

Perform the DA block adjustments on the SSP-11 board, perform this adjustment after completing "5-3-1. AD conversion level adjustment".

Adjustment condition	Specification	Adjustment (SSP-11 board)
Step 1	ANALOG OUTPUT CH-1 output level:	⊘ RV103 (F4)
 Input a 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG IN CH-1 connector from the audio analyzer (AF oscillator). Connect the audio analyzer (level meter) to the ANALOG OUTPUT CH-1 connector. 	+4.0 dBs ±0.1 dB	
Step 2	ANALOG OUTPUT CH-2 output level:	⊘RV203 (E4)
 Input a 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG IN CH-2 connector from the audio analyzer (AF oscillator). Connect the audio analyzer (level meter) to the ANALOG OUTPUT CH-2 connector. 	+4.0 dBs ±0.1 dB	

5-3-3. C. M. R. R. Adjustment


FL tube display (front panel) setting
Au-rEF (Input signal level's digital indication)

Adjustment procedure

Adjustment condition	Specification	Adjustment (SSP-11 board)
Step 1	ANALOG OUTPUT CH-1 output level:	ØRV101 (F6)
 Input the in-phase signal of 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) to the ANALOG IN CH-1 connector, from an audio analyzer (AF oscillator). Connection of the input signal must be made between hot (pin-2) and GND (pin-1), and between cold (pin-3) and GND (pin-1) of the CH-1 connector, in parallel. Connect an audio analyzer (level meter) to the ANALOG OUTPUT CH-1 connector. 	-56 dBs or less Confirm at this time that the numeric value appearing on Au-rEF (left side) of the FL tube display satisfies the specification indicated in section "5-3-1. AD Conversion Level Adjustment". When the specification is not satisfied, perform step 1 of section "5-3-1. AD Conversion Level Adjustment" again until the specification is satisfied.	
Step 2	ANALOG OUTPUT CH-2 output level:	●RV201 (E6)
 Input the in-phase signal of 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) to the ANALOG IN CH-2 connector, from an audio analyzer (AF oscillator). Connection of the input signal must be made between hot (pin-2) and GND (pin-1), and between cold (pin-3) and GND (pin-1) of the CH-2 connector, in parallel. Connect an audio analyzer (level meter) to the ANALOG OUTPUT CH-2 connector. 	-56 dBs or less Confirm at this time that the numeric value appearing on Au-rEF (left side) of the FL tube display satisfies the specification indicated in section "5-3-1. AD Conversion Level Adjustment". When the specification is not satisfied, perform step 2 of section "5-3-1. AD Conversion Level Adjustment" again until the specification is satisfied.	

5-3-4. Output Balance Adjustment

Connection



Adjustment procedure

Adjustment condition	Specification	Adjustment (SSP-11 board)	
Step 1 • input the 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG INPUT CH-1 connector. • Connect an oscilloscope to the ANALOG OUTPUT CH-1 connector as follows: Oscilloscope ANALOG OUTPUT CH-1 connector CH-1 → Across pin-2 and pin-1 (GND) CH-2 → Across pin-3 and pin-1 (GND)	Output balance between (pin-2) and (pin-3) of the ANALOG OUTPUT CH-1: 1% or less * Adjustment procedure Oscilloscope CH-1 Oscilloscope CH-2 Adjust ORV105 until amplitude of the ADDed waveform is 34.6 mVp-p or less.	⊘ RV105 (F3)	
Step 2 Input the 1 kHz, +4 dBs (0 dBs = 0.775 Vrms) signal to the ANALOG INPUT CH-2 connector. Connect an oscilloscope to the ANALOG OUTPUT CH-2 connector as follows: Oscilloscope ANALOG OUTPUT CH-2 connector CH-1 → Across pin-2 and pin-1 (GND) CH-2 → Across pin-3 and pin-1 (GND)	Output balance between ① (pin-2) and ② (pin-3) of the ANALOG OUTPUT CH-2: 1% or less * Adjustment procedure Oscilloscope CH-1 ADD mode ON Oscilloscope CH-2 Adjust ②RV205 until amplitude of the ADDed waveform is 34.6 mVp-p or less.	⊘ RV205 (E3)	

^{*:} Output balance between \oplus (pin-2) and \bigcirc (pin-3) of the ANALOG OUTPUT must be 1%, means that the amplitude of the ADDed waveform must be 34.6 mVp-p or less when the amplitude before ADDition is 3.46 Vp-p (+4 dBs).


5-4. Time Code Output Level Adjustment

To perform the adjustment, first remove the top plate. Perform the adjustment when SSP-11 board and TC block components are replaced, or if time code output level is to be changed.

Equipment and Tools

Oscilloscope
Pre-recorded time code DAT tape
XLR 3PIN (female) connector
10 kΩ 1/4 W resistor


Adjustment Location



Switch and control setting

Same as "5-1-2. Switch and Control Initial Setting".

Connection



Adjustment Procedure

Adjustment Condition	Specification	Adjustment (SSP-11 board)	
• Connect a 10 k Ω dummy load (See "Connection".) or equipment (for using time code) to the TIME CODE OUTPUT (rear panel) connector.	Oscilloscope CH-1 Oscilloscope CH-2; INVERT Both channels: ADD mode	ØRV701 (F3)	
• Connect the oscilloscope as follows: Oscilloscope Connect to CH1 → 2pin, TC OUT connector (CPU-268 board)	X-X-X-X- 1 ^		
E3 (A2), GND	A = 2.4 Vp-p		
CH2 → 3pin, TC OUT connector (CPU-268 board) E3 (A2), GND Insert the pre-recorded time code DAT tape and playback tape (PLAY mode).	If the time code output level is to be changed, adjust ©RV701 so that voltage A above becomes the desired voltage.		

Section 6 Spare Parts

6-1. 補修部品注意事項

1. 安全重要部品

小警告

▲印のついた部品は安全性を維持するために重要な部品です。したがって、交換する時は必ず指定の部品を使ってください。

2. 部品の共通化

ソニーから供給する補修用部品は、セットに使われているものと異なることがあります。

これは部品の共通化,改良等によるものです。 部品表には現時点での共通化された補修用部品が記載されています。

3. 部品の在庫

部品表のSP (Supply code) 欄に "o" で示される部品は 在庫していないことがあり,納期が長くなることがあり ます。

4. 単位の表記

下記の単位については、表記を変更または省略しています。

単位		表記
静電容量	μF	uF
インダクタンス	μH	uH
抵抗値	Ω	省略
温度	°C	XXX-DEG-C

6-1. Notes on Repair Parts

1. Safety Related Components Warning

Components marked \triangle are critical to safe operation. Therefore, specified parts should be used in the case of replacement.

2. Standardization of Parts

Some repair parts supplied by Sony differ from those used for the unit. These are because of parts commonality and improvement.

Parts list has the present standardized repair parts.


3. Stock of Parts

Parts marked with "o" at SP (Supply Code) column of the spare parts list may be not stocked. Therefore, the delivery date will be delayed.


4. Units Representation

The following represented units are changed or omitted in writing.


Units		Representation	
Capacitance	μF	uF	
Inductance	μH	uН	
Resistance	Ω	Abbreviation	
Temperature	°C	XXX-DEG-C	



6-2 POJA-7040




No.	Part No. SP D	Description	No.	Part No.	SP Description
101 102 103 104 105	X-3165-315-3 s D X-3167-823-1 s K X-3167-892-2 s P	KY-192A MOUNTED CIRCUIT BOARD DIAL ASSY KNOB ASSY (P), VOL PANEL ASSY, FRONT RES, VAR, CARBON 10K/10K		1-956-645-11 3-166-928-02 3-166-929-11	l o HARNESS, SUB (REC VR2) l o HARNESS, SUB (HP) 2 o ESCUTCHEON, SW l o KEY TOP (LARGE) l o KEY TOP (SMALL)
106 107 108 109 110	1-466-955-11 s E 1-507-863-51 s J 1-570-117-41 s S	RES, VAR, CARBON 20K RNCODER, ROTARY JACK, LARGE TYPE WITCH, SEESAW (AC POWER) PRINTED CIRCUIT BOARD, LED-104	121 122 123 124 125	3-184-994-01 3-567-099-01 3-668-009-02	3 o TABLE, ENCORDER 1 o ISR STICKER (S) 1 o SPRING, COMPRESSION 2 o PIN, PUSH BUTTON 1 s CAP, SWITCH
111 112 113 114 115	1-637-283-14 o P 1-637-284-13 o P 1-946-966-11 o H	PRINTED CIRCUIT BOARD, SW-420 PRINTED CIRCUIT BOARD, HP-48 PRINTED CIRCUIT BOARD, VR-109 IARNESS (SW) IARNESS, SUB (REC VR1)	126	4-862-354-00	s SPRING, COMPRESSION




No.	Part No. SP	Description
201	A-8311-414-A o	SSP-11 MOUNTED CIRCUIT BOARD (FOR J. UC)
	A-8311-415-A o	SSP-11 MOUNTED CIRCUIT BOARD (FOR CE)
202	A-8311-417-A o	CP-268A MOUNTED CIRCUIT BOARD (FOR UC. CE)
	A-8311-800-A o	CP-268B MOUNTED CIRCUIT BOARD (FOR J)
203	X-2068-004-0 s	TERMINAL ASSY
204		INLET (WITH NOISE FILTER)
		BATTERY, LITHIUM
206		FUSE, GLASS TUBE (FOR J, UC)
	1-576-225-41 s	FUSE (H.B.C.) (FOR CE)

No.	Part No. SP Description
207	1-663-718-11 o PRINTED CIRCUIT BOARD, CP-269
208	1-664-284-11 o PRINTED CIRCUIT BOARD, CN-1487
209	1-956-636-11 o HARNESS, SUB (AC IN)
210	1-956-642-11 o HARNESS, SUB (ANALOG IN)
211	1-956-650-11 o HARNESS, SUB (SV CONT)
212	2-068-008-00 s WASHER
213	3-191-393-01 o PANEL, CONNECTOR
214	3-743-347-01 o COVER, FUSE

Case Section



No.	Part No. SP Description
301 302 303 304 305	A-8267-753-B o WINDOW ASSY, CASSETTE A-8310-132-A D RF-53 ASSY A-8312-269-A D SV-147A MOUNTED CIRCUIT BOARD 1-764-402-11 S WIRE, FLEXIBLE CARD(1.00MM)18P 3-671-150-01 D CLAMP
	3-703-502-21 s SCREW 7-621-772-18 s SCREW +B 2X4 7-627-850-27 s SCREW, PRECISION +P 1.4X3 7-627-850-47 s SCREW, PRECISION +P 1.4X1.6




No.	Part No. SP Description
402 403 404	A-8267-998-B s CASSETTE COMPARTMENT ASSY X-3363-985-5 s PLATE (LEFT) ASSY, SIDE X-3363-986-5 s GEAR (LEVER LEFT) ASSY X-3363-987-7 s HOLDER ASSY, CASSETTE X-3363-989-5 s SLIDER (CASSETTE) ASSY
407 408 409	X-3363-990-2 s LEVER ASSY, X X-3363-991-1 s LEVER ASSY, SLIDER LOCK X-3363-995-2 s GEAR (LEVER RIGHT) ASSY X-3363-996-1 s GEAR (JOINT) ASSY X-3366-603-1 s GEAR (C3) ASSY
412 413 414	X-3369-846-2 s PLATE (RIGHT) SUB ASSY, SIDE 3-140-263-99 s SPRING, TENSION 3-321-393-01 s WASHER, STOPPER 3-341-752-11 s WASHER, POLYETHYLENE 3-341-753-11 s WASHER, POLYETHYLENE
417 418 419	3-374-680-01 s GUIDE (CASSETTE LEFT) 3-374-681-01 s LEVER (SWITCH) 3-374-686-01 s GEAR 3-374-688-01 E GEAR (C2) 3-374-689-01 s PLATE, JOINT


N	0.	Part	No.	SP	Description
4	22 23 24	3-37- 3-37- 3-37-	4-720-01 4-721-04 4-722-01	s	LEVER (CASSETTE) SPRING (SLIDER LOCK), TORSION SPRING (SLIDER RETURN), TORSION SPRING (LID ARM), TORSION SPRING(CASSETTE LEVER), TORSION
444	27 28 29	3-37 3-38 3-56	4-739-03 8-228-03	ls s	GUIDE (CASSETTE RIGHT) GEAR (JOINT RIGHT) LEVER (LID UP) SPRING, TENSION SCREW
4	32 33 34	3-90 4-85 7-62	4-008-03 8-478-09 7-850-2	s s s	SCREW (M1.4X1.6), SPECIAL HEAD ROLLER SPRING, TENSION SCREW, PRECISION +P 1.4X3 SCREW, PRECISION +P 1.4X1.6

6-6

Mechanism Deck (1)




No.	Part No. SP Description	No. Part No. SP Description
501 502 503 504 505	A-8276-769-A 0 MOUNTED PCB, REEL FG X-3363-984-1 s ARM ASSY, LID 1-570-771-11 s SWITCH 1-572-950-11 s SWITCH, PUSH 1-572-951-11 s SWITCH, PUSH	512 3-374-672-01 s SPRING, TENSION 513 3-374-673-01 s BRACKET (SWITCH) 514 3-374-674-01 s HOLDER (ES) 515 7-621-772-08 s SCREW +B 2X3 516 7-627-553-67 s SCREW, PRECISION +P 2X5
506 507	1-642-056-12 s PRINTED CIRCUIT BOARD, RECOGNI END FLEXIBLE 1-648-978-11 s PRINTED CIRCUIT BOARD, REEL FG.DEW FLEXIBLE	517 7-627-850-08 s SCREW, PRECISION +P 1.4X2 518 7-627-850-27 s SCREW, PRECISION +P 1.4X3 519 8-729-907-25 s PHOTO TRANSISTOR PT4850F 520 8-759-057-48 s PHOTO REFLECTOR NJL5803K-F10
508 509 510 511	1-648-979-11 s PRINTED CIRCUIT BOARD, CAPSTAN FLEXIBLE 1-698-227-51 s MOTOR, REEL 1-809-544-12 s SENSOR, DEW CONDENSATION 3-374-654-01 s COVER (MOTOR)	521 18-835-329-12 s MOTOR, DC U-21A



No.	Part No. SP Description
602 603 604	A-8267-743-A s ROLLER ASSY, RG A-8267-744-A s ROLLER ASSY, LG A-8267-759-A s MOTOR ASSY, DRIVE A-8267-761-A s GUIDE ASSY, ROLLER X-3363-963-1 o CHASSIS ASSY
607 608 609	X-3363-965-3 s LEVER ASSY, CAM X-3363-966-1 s LEVER ASSY, LR X-3363-976-1 s PINCH ROLLER ASSY X-3363-983-1 s ARM ASSY, CR X-3366-602-1 s TENSION REGULATOR ASSY
611	1-648-976-12 s PRINTED CIRCUIT BOARD, TENREGI MOTOR ENCODER FLEXIBLE
613	1-648-982-11 o PRINTED CIRCUIT BOARD, TENREGI 3-320-354-21 s WASHER 3-321-393-01 s WASHER, STOPPER
616 617 618	3-341-752-11 s WASHER, POLYETHYLENE 3-341-753-11 s WASHER, POLYETHYLENE 3-360-866-01 s ROLLER (TENSION REGULATOR) 3-374-604-01 s SPRING, COMPRESSION 3-374-605-01 s SHAFT (CASSETTE)

```
SP Description
No.
             Part No.
            3-374-606-01 s SPRING (R), TORSION
3-374-608-01 s SPRING (LF), TORSION
3-374-609-05 s SPRING (L), TORSION
3-374-610-02 s SLIDER
620
621
622
623
             3-374-635-01 s SPRING (P), TORSION
624
625
626
             3-374-657-01 s SCREW (M2X2)
             3-374-662-01 s SPRING, TENSION
3-374-665-01 s SLIDER, CR
3-375-727-01 s ROLLER (HC)
 627
 628
             3-375-728-01 s SPRING, TENSION
 629
             3-379-832-01 s RETAINER, THRUST
3-570-776-01 s SPRING, TENSION
7-627-850-08 s SCREW, PRECISION +P 1.4X2
7-627-850-27 s SCREW, PRECISION +P 1.4X3
 631
 632
 633
              8-719-821-03 s ELEMENT, HALL THS117
              8-848-696-01 s DRUM ASSY DOU-21B/J-N
```



No.	Part No. SP	Description	No.	Part No.	SP Description
704	X-3363-972-1 s X-3363-974-1 s X-3363-975-1 s	ROLLER ASSY, SLANT GUIDE (T) ROLLER ASSY, SLANT GUIDE (S) ARM (T) ASSY, LOADING ARM (S) ASSY, LOADING GEAR (S) ASSY, LOADING	716 717 718 719 720	3-374-646-01 3-374-647-01 3-374-648-01	l o RETAINER, SPOOL PLATE L S SPRING (SPOOL PLATE), TORSION L S RETAINER (A), DRIVE SHAFT L S RETAINER (B), DRIVE SHAFT L S GEAR (M2)
709	X-3363-980-1 s X-3363-981-1 s 1-466-670-21 s	GEAR (T) ASSY, LOADING PLATE ASSY, SPOOL, REEL GEAR ASSY, DRIVE ENCODER, ROTARY PRINTED CIRCUIT BOARD, GOMA	721 722 723 724 725	3-374-655-01 4-866-397-00 7-627-850-27	Ls GEAR (MD WHEEL) Ls BRACKET (LED) O o CUSHION, LED 7 s SCREW, PRECISION +P 1.4X3 7 s SCREW, PRECISION +P 1.4X1.6
714	3-374-628-02 s 3-374-636-01 s 3-374-641-01 s	WASHER, POLYETHYLENE PLATE, LOAD, PRE GEAR, CAM SPRING (T), TORSION SPRING (S), TORSION	726	8-719-988-42	2 s DIODE GL453

6-3. Electrical Parts Lists

Replacement for capacitors and resistors not given in each board parts lists are shown below. If a capacitor with the desired working voltage is not found, choose one of higher working voltage.

CAPACITOR, CHIP CERAMIC

Part No. SP Description

RESISTOR, CHIP

Part No. SP Description

1-216-308-00 s RES, CHIP 4.7 5% 1/10W 1-216-001-00 s RES, CHIP 10 5% 1/10W 1-216-009-00 s RES, CHIP 22 5% 1/10W 1-216-021-00 s RES, CHIP 22 5% 1/10W 1-216-033-00 s RES, CHIP 220 5% 1/10W 1-216-033-00 s RES, CHIP 220 5% 1/10W 1-216-037-00 s RES, CHIP 330 5% 1/10W 1-216-051-00 s RES, CHIP 470 5% 1/10W 1-216-051-00 s RES, CHIP 1.2k 5% 1/10W 1-216-057-00 s RES, CHIP 2.2k 5% 1/10W 1-216-059-00 s RES, CHIP 2.7k 5% 1/10W 1-216-069-00 s RES, CHIP 2.7k 5% 1/10W 1-216-069-00 s RES, CHIP 5.6k 5% 1/10W 1-216-073-00 s RES, CHIP 6.8k 5% 1/10W 1-216-073-00 s RES, CHIP 10k 5% 1/10W 1-216-073-00 s RES, CHIP 10k 5% 1/10W 1-216-083-00 s RES, CHIP 12k 5% 1/10W 1-216-083-00 s RES, CHIP 22k 5% 1/10W 1-216-083-00 s RES, CHIP 22k 5% 1/10W 1-216-085-00 s RES, CHIP 10k 5% 1/10W 1-216-085-00 s RES, CHIP 12k 5% 1/10W 1-216-085-00 s RES, CHIP 120k 5% 1/10W 1-216-085-00 s RES, CHIP 120k 5% 1/10W 1-216-133-00 s RES, CHIP 120k 5% 1/10W 1-216-133-00 s RES, CHIP 120k 5% 1/10W 1-216-113-00 s RES, CHIP 120k 5% 1/10W 1-216-113-00 s RES, CHIP 10k 5% 1/10W 1-216-113-00 s RES, CHIP 10k 5% 1/10W 1-216-113-00 s RES, CHIP 3.3M 5% 1/10W 1-216-133-00 s RES, CHIP 3.3M 5% 1/10W 1-216-133-00 s RES, CHIP 3.3M 5% 1/10W

CAPACITOR, ELECTROLYTIC

Part No. SP Description

1-126-923-11 s CAP, ELECT 220uF 20% 10V
1-126-924-11 s CAP, ELECT 330uF 20% 10V
1-126-926-11 s CAP, ELECT 1000uF 20% 10V
1-126-933-11 s CAP, ELECT 100uF 20% 35V
1-126-948-11 s CAP, ELECT 470uF 20% 35V
1-126-952-11 s CAP, ELECT 470uF 20% 35V
1-126-955-11 s CAP, ELECT 4700uF 20% 35V
1-126-963-11 s CAP, ELECT 4700uF 20% 35V
1-126-964-11 s CAP, ELECT 4700uF 20% 50V
1-126-964-11 s CAP, ELECT 470uF 20% 50V
1-126-968-11 s CAP, ELECT 100uF 20% 50V
1-126-968-11 s CAP, ELECT 47uF 20% 10V
1-126-968-11 s CAP, ELECT 100uF 20% 50V

```
CN-1487 BOARD
                                                                                                  CP-268A/B BOARD
Ref. No.
                                                                                                  Ref. No.
or Q'ty Part No.
                               SP Description
                                                                                                  or Q'ty Part No.
                                                                                                                                 SP Description
1pc
             1-664-284-11 o PRINTED CIRCUIT BOARD, CN-1487
                                                                                                                A-8311-417-A o MOUNTED CIRCUIT BOARD, CP-268A
                                                                                                  1pc
                                                                                                                (for UC, CE)
A-8311-800-A m MOUNTED CIRCUIT BOARD, CP-268B
             1-564-905-11 o PIN, CONNECTOR 9P
1-506-599-11 o PIN, CONNECTOR (B10P-VH) 10P
CN1
CN2
                                                                                                                                       (for J)
                                                                                                   (This assembly includes the following parts.)
D1
             8-719-500-27 s DIODE $15VB60
                                                                                                  C1
                                                                                                                1-102-973-00 s CERAMIC 100PF 5% 50V
                                                                                                                1-102-973-00 s CERAMIC 100PF 5% 50V
                                                                                                                1-102-973-00 s CERAMIC 100PF 5% 50V
1-102-973-00 s CERAMIC 100PF 5% 50V
1-102-973-00 s CERAMIC 100PF 5% 50V
1-102-973-00 s CERAMIC 100PF 5% 50V
                                                                                                   C3
                                                                                                  C4
                                                                                                  C5
                                                                                                  C6
                                                                                                                1-102-973-00 s CERAMIC 100PF 5% 50V
                                                                                                  C7
                                                                                                  C8
                                                                                                  C9
                                                                                                  C10
                                                                                                  C11
                                                                                                  C12
                                                                                                  C13
                                                                                                  C14
                                                                                                  C15
                                                                                                  C16
                                                                                                  C17
```

1-102-973-00 s CERAMIC 100PF 5% 50V 1-101-004-00 s CERAMIC 0.01uF 50V0% C18 C19 C20 1-101-004-00 s CERAMIC 0.01uF 50V0% CN51 1-506-494-11 s PIN, CONNECTOR 15P 1-750-785-11 s CONNECTOR, XLR 3P, MALE (for J) 1-750-786-11 s CONNECTOR, XLR 3P, FEMALE CN52 (for UC, CE) CN53 1-750-785-11 s CONNECTOR, XLR 3P, MALE (for UC, CE) 1-750-786-11 s CONNECTOR, XLR 3P, FEMALE (for J) 1-750-788-11 s CONNECTOR, XLR 3P, FEMALE 1-750-787-11 s CONNECTOR, XLR 3P, MALE 1-750-788-11 s CONNECTOR, XLR 3P, FEMALE 1-750-787-11 s CONNECTOR, XLR 3P, MALE CN54 CN55 CN56 CN57 (for UC, CE) 1-750-788-11 s CONNECTOR, XLR 3P, FEMALE (for J) CN501 1-506-494-11 s PIN, CONNECTOR 15P FB1 1-412-694-11 s INDUCTOR, BEED FB2 1-412-694-11 s INDUCTOR, BEED 1-412-694-11 s INDUCTOR, BEED FB3 1-412-694-11 s INDUCTOR, BEED FB4 FB5 1-412-694-11 s INDUCTOR, BEED FB6 1-412-694-11 s INDUCTOR, BEED FI.1 1-236-163-41 s ENCAPSULATED COMPONENT FI.2 1-236-163-41 s ENCAPSULATED COMPONENT 1-236-163-41 s ENCAPSULATED COMPONENT FL3 FL4 1-236-163-41 s ENCAPSULATED COMPONENT FL5 1-236-163-41 s ENCAPSULATED COMPONENT FL6 1-236-163-41 s ENCAPSULATED COMPONENT FL7 1-236-163-41 s ENCAPSULATED COMPONENT FL8 1-236-163-41 s ENCAPSULATED COMPONENT FL9 1-236-163-41 s ENCAPSULATED COMPONENT FL10 1-236-163-41 s ENCAPSULATED COMPONENT FL11 1-236-163-41 s ENCAPSULATED COMPONENT

```
(CP-268A/B BOARD)
                                                                                           KY-192A BOARD
 Ref. No.
or Q'ty Part No.
                          SP Description
                                                                                           or Q'ty Part No. SP Description
FI.12
             1-236-163-41 s ENCAPSULATED COMPONENT
                                                                                                       A-8311-410-A o MOUNTED CIRCUIT BOARD, KY-192A
                                                                                           (This assembly includes the following parts.)
R11
             1-215-421-00 s METAL 1K 1% 1/4W
             1-215-427-00 s METAL 1.8K 1% 1/4W
1-215-421-00 s METAL 1K 1% 1/4W
 R12
                                                                                                       1-466-955-11 \le ENCODER, ROTARY 3-167-806-03 o TABLE, ENCORDER
                                                                                           1pc
 R21
                                                                                           1pc
R22
             1-215-427-00 s METAL 1.8K 1% 1/4W
                                                                                                       7-682-903-01 s SCREW +PWH 3X5
7-685-903-21 s SCREW +PTPWH 3X8 (TYPE2)
7-685-532-14 s SCREW +BTP 2.6X5 TYPE2 N-S
                                                                                           1pc
                                                                                           1pc
RY1
             1-515-614-11 s RELAY
             1-515-614-11 s RELAY
 RY2
                                                                                                       1-162-306-11 s CERAMIC 0.01uF 30% 16V
            1-570-856-11 s SWITCH, SLIDE
1-570-856-11 s SWITCH, SLIDE
                                                                                           C5
                                                                                                       1-124-584-00 s ELECT 100uF 20% 10V
                                                                                                       1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
                                                                                           C6
                                                                                           C7
                                                                                                       1-162-306-11 s CERAMIC 0.01uF 30% 16V
                                                                                           C9
                                                                                           C10
                                                                                           C11
CP-269 BOARD
                                                                                           C12
                                                                                           C13
Ref. No.
                                                                                                       1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-124-584-00 s ELECT 100uF 20% 10V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
or Q'ty Part No.
                          SP Description
                                                                                           C15
            1-663-718-11 p PRINTED CIRCUIT BOARD, CP-269
                                                                                           C16
                                                                                           C17
            1-573-582-11 s CONNECTOR, ENC (RECEPTACLE)
1-573-582-11 s CONNECTOR, ENC (RECEPTACLE)
CN1
                                                                                           C18
CN2
CN502
             1-506-487-11 s PIN, CONNECTOR 8P
                                                                                           CN1
                                                                                                       1-564-009-11 o PIN, CONNECTOR 10P
                                                                                                       1-506-473-11 s PIN, CONNECTOR 8P
                                                                                           CM2
FB1
            1-412-694-11 s INDUCTOR, BEED
1-412-694-11 s INDUCTOR, BEED
                                                                                                       1-506-473-11 s PIN, CONNECTOR 8P
                                                                                           CN3
FB2
                                                                                                       1-506-475-11 s PIN, CONNECTOR 10P
1-506-475-11 s PIN, CONNECTOR 10P
                                                                                           CN4
            1-412-694-11 s INDUCTOR, BEED
1-412-694-11 s INDUCTOR, BEED
1-412-694-11 s INDUCTOR, BEED
FB3
                                                                                           CN5
FB4
FB5
                                                                                           CN6
                                                                                                       1-566-982-11 o PIN HEADER, STRAIGHT 9P
                                                                                          CN7
                                                                                                       1-506-474-11 s PIN, CONNECTOR 9P
            1-412-694-11 s INDUCTOR, BEED
1-412-694-11 s INDUCTOR, BEED
FB7
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                           D2
            1-247-804-11 s CARBON 75 5% 1/4W 1-247-804-11 s CARBON 75 5% 1/4W
                                                                                           D3
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                           D4
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
SW1
            1-570-157-51 s SWITCH, SLIDE
            1-570-157-51 s SWITCH, SLIDE
                                                                                                       8-719-911-19 E DIODE 1SS119-25TD
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
8-719-911-19 s DIODE 1SS119-25TD
                                                                                           D7
                                                                                           D8
                                                                                           D9
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D10
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                           D11
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
HP-48 BOARD
                                                                                          D12
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D13
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
Ref. No.
                                                                                          D14
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
or Q'ty Part No.
                          SP Description
                                                                                          D15 : 8-719-911-19 s DIODE 1SS119-25TD
            1-506-847-11 o HOUSING, BOARD IN CONNECTOR 10P
1-563-184-11 o HOUSING, CONNECTOR 10P
1-637-283-14 o PRINTED CIRCUIT BOARD, HP-48
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
1pc
                                                                                          D17
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
1pc
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D19
            1-162-306-11 s CERAMIC 0.01uF 30% 16V
1-162-306-11 s CERAMIC 0.01uF 30% 16V
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D21
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
FB1
            1-412-694-11 s INDUCTOR, BEAD
1-412-694-11 s INDUCTOR, BEAD
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D22
FB2
                                                                                          D23
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
FRR
            1-412-694-11 s INDUCTOR, BEAD
                                                                                          D24
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D25
                                                                                                       8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D26
                                                                                                      8-719-911-19 s DIODE 1SS119-25TD
8-719-911-19 s DIODE 1SS119-25TD
                                                                                          D27
                                                                                          D28
                                                                                                      8-719-911-19 m DIODE 1SS119-25TD
                                                                                          D29
                                                                                                      8-719-060-07 s DIODE EBG5334S
```

(KY-192A	BOARD)	(KY-192A	BOARD)
Ref. No. or Q'ty	Part No. SP Description	Ref. No. or Q'ty	Part No. SP Description
D30 D31 D32 D33 D34	8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S	Q23 Q24 Q25 Q26 Q27	8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146
D35 D36 D37 D38 D39	8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-07 s DIODE EBG5334S 8-719-060-08 s DIODE PY5334S	Q28 Q29 Q30 Q31 Q32	8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146
D40 D41 D53 D54 D55	8-719-911-19 s DIODE 1SS119-25TD	Q33 Q34 Q35 Q36	8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146
D56	8-719-911-19 s DIODE 1SS119-25TD 1-535-178-00 s RES, FERRITE	R1 R2 R3	1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W
FB1	1-535-178-00 s RES, FERRITE	R4 R5	1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W
FL1 IC1 IC2 IC3 IC4 IC5	8-759-926-11 s IC SN74HC138ANS-E05 8-759-926-77 s IC SN74HC541ANS-E05 8-759-926-77 s IC SN74HC541ANS-E05 8-759-500-05 s IC MSM6338MS-K	R6 R7 R8 R9 R10	1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W 1-249-441-11 s CARBON 100K 5% 1/4W 1-249-429-11 s CARBON 10K 5% 1/4W
IC6 IC7 IC8 IC9 IC10	8-759-513-50 s IC MSC62408-018GS-V1K 8-759-926-82 s IC SN74HC574ANS-E05 8-759-926-82 s IC SN74HC574ANS-E05 8-759-926-82 s IC SN74HC574ANS-E05	R12 R13 R14 R15	1-249-429-11 s CARBON 10K 5% 1/4W 1-249-429-11 s CARBON 10K 5% 1/4W
JW5 JW12 JW117 JW118	8-759-926-82 s IC SN74HC574ANS-E05 1-217-666-11 s CONDUCTOR 0.01 1-217-666-11 s CONDUCTOR 0.01 1-217-666-11 s CONDUCTOR 0.01 1-217-666-11 s CONDUCTOR 0.01	R16 R17 R18 R19 R20	1-249-429-11 s CARBON 10K 5% 1/4W 1-249-429-11 s CARBON 10K 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-249-403-11 s CARBON 68 5% 1/4W 1-249-403-11 s CARBON 68 5% 1/4W
L1 L2	1-412-533-21 s INDUCTOR 47UH 1-412-533-21 s INDUCTOR 47UH 8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146	R21 R22	1-249-408-11 s CARBON 180 5% 1/4W 1-249-399-11 s CARBON 33 5% 1/4W 1-249-399-11 s CARBON 33 5% 1/4W
Q1 Q2 Q3 Q4	8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146	R24 R25 R26	1-247-815-91 s CARBON 220 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-247-815-91 s CARBON 220 5% 1/4W
Q5 Q6 Q7	8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146	R27 R28 R29 R30	1-247-815-91 s CARBON 220 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W
Q8 Q9 Q10	8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-56 s TRANSISTOR DTC143TKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146	R31 R32 R33	1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W
Q11 Q12 Q13 Q14	8-729-901-47 s TRANSISTOR DTA143EKA-T146 8-729-901-47 s TRANSISTOR DTA143EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-901-47 s TRANSISTOR DTA143EKA-T146	R34 R35	1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W
Q15 Q16	8-729-901-47 s TRANSISTOR DTA143EKA-T146 8-729-901-47 s TRANSISTOR DTA143EKA-T146	R37 R38 R39	1-249-408-11 S CARBON 180 5% 1/4W 1-249-408-11 S CARBON 180 5% 1/4W 1-249-408-11 S CARBON 180 5% 1/4W
Q17 Q18 Q19	8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146	R40 R41	1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W
Q20	8-729-027-23 s TRANSISTOR DTA114EKA-T146	R42 R43	1-249-408-11 s CARBON 180 5% 1/4W 1-249-408-11 s CARBON 180 5% 1/4W
Q21 Q22	8-729-027-23 s TRANSISTOR DTA114EKA-T146 8-729-027-23 s TRANSISTOR DTA114EKA-T146	R44 R45	1-249-408-11 s CARBON 180 5% 1/4W 1-247-807-31 s CARBON 100 5% 1/4W

PCM-7040

```
(KY-192A BOARD)
                                                                                 TED-104 BOARD
Ref. No.
                                                                                 Ref. No.
or Q'ty Part No.
                          SP Description
                                                                                 or Q'ty Part No.
                                                                                                            SP Description
           1-247-791-91 s CARBON 22 5% 1/4W
                                                                                             1-637-269-11 o PRINTED CIRCUIT BOARD, LED-104
R47
           1-247-791-91 s CARBON 22 5% 1/4W
                                                                                             7-685-132-19 s SCREW +P 2.6X5 TYPE2 NON-SLIT
                                                                                2pcs
R48
           1-247-791-91 s CARBON 22 5% 1/4W
           1-247-807-31 s CARBON 100 5% 1/4W
R49
                                                                                             8-719-060-10 s DIODE BR3338S
           1-247-807-31 s CARBON 100 5% 1/4W
R50
                                                                                 D45
                                                                                             8-719-060-10 s DIODE BR3338S
                                                                                             8-719-060-11 s DIODE MPY3338S
                                                                                 D46
R51
           1-247-807-31 s CARBON 100 5% 1/4W
                                                                                             8-719-060-09 s DIODE EMBG3338S
                                                                                 D47
           1-247-607-51 S CARBON 100 5% 1/4W
1-249-425-11 S CARBON 4.7K 5% 1/4W
1-249-425-11 S CARBON 4.7K 5% 1/4W
1-249-425-11 S CARBON 4.7K 5% 1/4W
R52
                                                                                 D48
                                                                                             8-719-060-11 s DIODE MPY3338S
R53
R54
           1-249-425-11 s CARBON 4.7K 5% 1/4W
R55
R56
           1-249-425-11 s CARBON 4.7K 5% 1/4W
R57
           1-249-425-11 s CARBON 4.7K 5% 1/4W
           1-249-437-11 s CARBON 47K 5% 1/4W
                                                                                 PS-451 BOARD
R58
R59
           1-249-437-11 s CARBON 47K 5% 1/4W
           1-249-437-11 s CARBON 47K 5% 1/4W
                                                                                 Ref. No.
R60
                                                                                 or Q'ty Part No. SP Description
           1-249-437-11 s CARBON 47K 5% 1/4W 1-249-437-11 s CARBON 47K 5% 1/4W
R61
R62
                                                                                             1-562-210-11 s CONTACT, CONNECTOR
R63
           1-249-437-11 s CARBON 47K 5% 1/4W 1-249-437-11 s CARBON 47K 5% 1/4W
                                                                                             1-663-710-11 o PRINTED CIRCUIT BOARD, PS-451
                                                                                  1pc
R64
                                                                                             1-956-640-11 o HARNESS, SUB (CN)
                                                                                  1pc
R65
            1-249-429-11 s CARBON 10K 5% 1/4W
                                                                                             1-564-321-00 s PIN, CONNECTOR 2P
1-564-321-00 s PIN, CONNECTOR 2P
1-564-321-00 s PIN, CONNECTOR 2P
                                                                                  CN1
R66
           1-249-429-11 s CARBON 10K 5% 1/4W
                                                                                 CN2
           1-249-429-11 s CARBON 10K 5% 1/4W
1-249-429-11 s CARBON 10K 5% 1/4W
1-249-429-11 s CARBON 10K 5% 1/4W
1-249-437-11 s CARBON 47K 5% 1/4W
R67
R68
R69
R70
R71
           1-249-437-11 s CARBON 47K 5% 1/4W
1-249-437-11 s CARBON 47K 5% 1/4W
1-249-437-11 s CARBON 47K 5% 1/4W
R72
R73
                                                                                 REEL FG BOARD
           1-249-437-11 s CARBON 47K 5% 1/4W
R74
                                                                                  Ref. No.
           1-692-892-11 s SWITCH, TACTILE
1-762-030-11 s SWITCH, TACTILE
S1
                                                                                  or Q'ty Part No.
                                                                                                           SP Description
52
           1-572-609-21 s SWITCH, PUSH (1 KEY)
1-572-607-21 s SWITCH, PUSH (1 KEY)
                                                                                             A-8276-769-A o MOUNTED CIRCUIT BOARD, REEL FG
S3
S4
                                                                                  (This assembly includes the following parts.)
S5
            1-572-607-11 s SWITCH, PUSH (1 KEY)
                                                                                  1pc
                                                                                             1-648-983-11 o PRINTED CIRCUIT BOARD, REEL FG
56
            1-554-937-11 s SWITCH, KEY BOARD
S7
            1-572-609-11 s SWITCH, PUSH (1 KEY)
                                                                                  C1
                                                                                             1-164-505-11 s CERAMIC 2.2uF 16V
S8
            1-572-608-11 s SWITCH, PUSH (1 KEY)
S9
            1-762-031-11 s SWITCH, TACTILE
            1-762-032-11 s SWITCH, TACTILE
            1-554-937-11 s SWITCH, KEY BOARD 1-554-937-11 s SWITCH, KEY BOARD
S11
S12
S13
            1-554-937-11 s SWITCH, KEY BOARD
            1-554-937-11 s SWITCH, KEY BOARD
S14
            1-554-937-11 s SWITCH, KEY BOARD
S15
S16
            1-554-937-11 s SWITCH, KEY BOARD
            1-554-937-11 s SWITCH, KEY BOARD
1-554-937-11 s SWITCH, KEY BOARD
S17
S18
            1-554-937-11 s SWITCH, KEY BOARD
S19
S20
            1-554-937-11 s SWITCH, KEY BOARD
$21
            1-554-937-11 s SWITCH, KEY BOARD
S22
            1-554-937-11 s SWITCH, KEY BOARD
            1-554-937-11 = SWITCH, KEY BOARD
1-571-156-11 o SWITCH, TOGGLE
S23
S24
S25
            1-571-157-11 o SWITCH, TOGGLE
            1-571-156-11 o SWITCH, TOGGLE
1-571-156-11 o SWITCH, TOGGLE
S26
```

RF-53 BOARD	(RF-53 BOARD)
Ref. No. or Q'ty Part No. SP Description	Ref. No. or Q'ty Part No. SP Description
1pc A-8310-132-A o RF-53 ASSY (This assembly includes the following parts.) C101 1-135-217-21 s TANTAL 15uF 20% 6.3 C102 1-164-845-21 s CEPANIC 5PR 0 25PR 16V	C238 1-164-882-11 s CERAMIC 220PF 5% 16V C239 1-162-964-11 s CERAMIC 0.001uF 10% 50V
C101 1-135-217-21 s TANTAL 15uF 20% 6.3	C302 1-135-217-21 s TANTAL 15uF 20% 6.3 C305 1-135-217-21 s TANTAL 15uF 20% 6.3 C306 1-135-217-21 s TANTAL 15uF 20% 6.3
C101 1-135-217-21 s TANTAL 15uF 20% 6.3 C102 1-164-845-11 s CERAMIC 5PF 0.25PF 16V C104 1-164-845-11 s CERAMIC 5PF 0.25PF 16V C106 1-135-073-00 s TANTALUM, CHIP 0.33uF 10% 35V C107 1-164-874-11 s CERAMIC 100PF 5% 16V C108 1-164-874-11 s CERAMIC 100PF 5% 16V C109 1-135-217-21 s TANTAL 15uF 20% 6.3 C110 1-135-073-00 s TANTALUM, CHIP 0.33uF 10% 35V C112 1-162-921-11 s CERAMIC 33PF 5% 50V C114 1-162-921-11 s CERAMIC 33PF 5% 50V C117 1-164-937-11 s CERAMIC 0.001uF 10% 16V C118 1-164-937-11 s CERAMIC 0.001uF 10% 16V C119 1-164-874-11 s CERAMIC 100PF 5% 16V	CN1 1-566-531-11 s CONNECTOR, FPC (ZIF) 15P CN2 1-565-882-11 o PIN, CONNECTOR (PC BOARD) 10P CN3 1-566-534-11 s CONNECTOR, FPC (ZIF) 18P
C109 1-135-217-21 s TANTAL 15uF 20% 6.3 C110 1-135-073-00 s TANTALUM, CHIP 0.33uF 10% 35V C112 1-162-921-11 s CERAMIC 33PF 5% 50V	IC101 8-752-039-01 s IC CXA1364R IC201 8-752-039-01 s IC CXA1364R IC301 8-759-064-36 s IC MB88346BPFV-EF
C114 1-162-921-11 s CERAMIC 33PF 5% 50V C117 1-164-937-11 s CERAMIC 0.001uF 10% 16V	L101 1-410-381-11 s INDUCTOR CHIP 10UH L201 1-410-381-11 s INDUCTOR CHIP 10UH L301 1-410-381-11 s INDUCTOR CHIP 10UH
C120 1-164-8/4-11 S CERAMIC 100PF 5% 16V	Q102 8-729-102-08 s TRANSISTOR 2SC2223-T1F14
C125	Q106 8-729-216-21 s TRANSISTOR 2SA1162Y-TE85L Q107 8-729-230-49 s TRANSISTOR 2SC2712Y-TE85L
C133 1-135-217-21 s TANTAL 15uF 20% 6.3 C134 1-162-968-11 s CERAMIC 0.0047uF 10% 50V C135 1-135-217-21 s TANTAL 15uF 20% 6.3	Q202 8-729-102-08 s TRANSISTOR 2SC2223-T1F14 Q203 8-729-901-00 s TRANSISTOR DTC124EK-T146 Q203 8-729-201-00 s TRANSISTOR DTC124EK-T146
C138 1-164-882-11 s CERAMIC 220PF 5% 16V C139 1-162-964-11 s CERAMIC 0.001uF 10% 50V C201 1-135-217-21 s TANTAL 15uF 20% 6.3 C202 1-164-845-11 s CERAMIC 5PF 0.25PF 16V	Q206 8-729-216-21 s TRANSISTOR 2SA1162Y-TE85L Q207 8-729-230-49 s TRANSISTOR 2SC2712Y-TE85L Q208 8-729-216-21 s TRANSISTOR 2SA1162Y-TE85L Q209 8-729-230-49 s TRANSISTOR 2SC2712Y-TE85L
C204 1-164-845-11 s CERAMIC 5PF 0.25PF 16V C206 1-135-073-00 s TANTALUM, CHIP 0.33uF 10% 35V C207 1-164-874-11 s CERAMIC 100PF 5% 16V C208 1-164-874-11 s CERAMIC 100PF 5% 16V C209 1-135-217-21 s TANTAL 15uF 20% 6.3	R101 1-216-837-11 s METAL 22K 5% 1/16W R102 1-216-797-11 s METAL 10 5% 1/16W R103 1-216-797-11 s METAL 10 5% 1/16W R104 1-216-837-11 s METAL 22K 5% 1/16W
C210 1-135-073-00 s TANTALUM, CHIP 0.33uf 10% 35V C212 1-162-921-11 s CERAMIC 33PF 5% 50V C214 1-162-921-11 s CERAMIC 33PF 5% 50V C217 1-164-937-11 s CERAMIC 0.001uf 10% 16V C218 1-164-937-11 s CERAMIC 0.001uf 10% 16V	D106 1 016 010 11 - 100 10 10 10 10 10 10
C219 1-164-874-11 s CERAMIC 100PF 5% 16V C220 1-164-874-11 s CERAMIC 100PF 5% 16V C221 1-135-259-11 s TANTAL 10uF 20% 6.3 C223 1-164-882-11 s CERAMIC 220PF 5% 16V C224 1-164-940-11 s CERAMIC 0.0033uF 10% 16V	R111 1-218-967-11 s METAL 15K 5% 1/16W R112 1-218-967-11 s METAL 15K 5% 1/16W R113 1-218-990-11 s CONDUCTOR 1005 R114 1-218-973-11 s METAL 47K 5% 1/16W
C225 1-164-882-11 s CERAMIC 220PF 5% 16V C227 1-135-217-21 s TANTAL 15uF 20% 6.3 C228 1-164-937-11 s CERAMIC 0.001uF 10% 16V C229 1-164-935-11 s CERAMIC 470PF 10% 16V C230 1-164-882-11 s CERAMIC 220PF 5% 16V	R115 1-218-990-11 s CONDUCTOR 1005 R116 1-218-967-11 s METAL 15K 5% 1/16W R117 1-218-967-11 s METAL 15K 5% 1/16W R118 1-218-952-11 s METAL 820 5% 1/16W R119 1-218-961-11 s METAL 4.7K 5% 1/16W R120 1-220-184-11 s METAL 1.3K 5% 16W
C231 1-164-874-11 s CERAMIC 100PF 5% 16V C233 1-135-217-21 s TANTAL 15uF 20% 6.3	R120 1-220-184-11 S METAL 1.3K 5% 16W R121 1-218-961-11 S METAL 4.7K 5% 1/16W R122 1-218-968-11 S METAL 18K 5% 1/16W R123 1-218-968-11 S METAL 18K 5% 1/16W R124 1-220-193-81 S METAL 7.5K 5% 16W

(RF-53 B	DARD)	SSP-11 BOARD
Ref. No. or Q'ty	Part No. SP Description	Ref. No. or Q'ty Part No. SP Description
R125 R126 R127 R128 R129	1-220-193-81 5 METAL 7.5K 5% 16W 1-218-968-11 S METAL 18K 5% 1/16W 1-220-193-81 S METAL 7.5K 5% 16W 1-216-835-11 S METAL 15K 5% 1/16W 1-216-833-11 S METAL 10K 5% 1/16W	lpc A-8311-414-A & MOUNTED CIRCUIT BOARD, SSP-11 (for J, UC) A-8311-415-A o MOUNTED CIRCUIT BOARD, SSP-11 (for CE) (This assembly includes the following parts.)
R130 R131 R132 R133 R134	1-216-809-11 s METAL 100 5% 1/16W 1-216-821-11 s METAL 1K 5% 1/16W 1-216-821-11 s METAL 1K 5% 1/16W 1-216-830-11 s METAL 5.6K 5% 1/16W 1-216-830-11 s METAL 5.6K 5% 1/16W	1pc 3-743-347-01 o COVER, FUSE 2pcs 1-533-223-11 s HOLDER, FUSE 2pcs 1-956-642-11 o HARNESS, SUB (ANALOG IN) 8pcs 7-682-903-21 s SCREW +FWH 3X8 2pcs 3-167-945-02 o CASE (INNER), SHIELD, SP
R135 R136 R137 R138 R139	1-216-791-11 s METAL 3.3 5% 1/16W 1-216-791-11 s METAL 3.3 5% 1/16W 1-216-827-11 s METAL 3.3K 5% 1/16W 1-216-827-11 s METAL 3.3K 5% 1/16W 1-216-827-11 s METAL 3.3K 5% 1/16W	1pc 1-956-947-11 o HARNESS, SUB (CN11) 1pc 7-682-952-01 s SCREW +PSW 3X16 1pc 1-759-081-11 o HOLDER, BATTERY BT301 1-528-229-41 s BATTERY, LITHIUM (CR-2450)
R140 R201 R202 R203 R204	1-216-821-11 s METAL 1K 5% 1/16W 1-216-837-11 s METAL 22K 5% 1/16W 1-216-797-11 s METAL 10 5% 1/16W 1-216-797-11 s METAL 10 5% 1/16W 1-216-837-11 s METAL 22K 5% 1/16W	
R205 R206 R207 R208 R209	1-216-833-11 s METAL 10K 5% 1/16W 1-216-812-11 s METAL 180 5% 1/16W 1-216-812-11 s METAL 180 5% 1/16W 1-216-833-11 s METAL 10K 5% 1/16W 1-216-834-11 s METAL 12K 5% 1/16W	
R210	1-218-973-11 s METAL 47K 5% 1/16W	C70 1-126-514-11 s ELECT 22uF 20% 16V
R211	1-218-967-11 s METAL 15K 5% 1/16W	C76 1-126-514-11 s ELECT 22uF 20% 16V
R212	1-218-967-11 s METAL 15K 5% 1/16W	C101 1-107-715-11 s ELECT 22uF 20% 25V
R213	1-218-990-11 s CONDUCTOR 1005	C102 1-107-715-11 s ELECT 22uF 20% 25V
R214	1-218-973-11 s METAL 47K 5% 1/16W	C103 1-126-791-11 s ELECT 10uF 20% 16V
R215	1-218-990-11 s CONDUCTOR 1005	C106 1-104-547-11 s FILM 0.0047uF 5% 16V
R216	1-218-967-11 s METAL 15K 5% 1/16W	C108 1-104-551-11 s FILM 0.01uF 5% 16V
R217	1-218-967-11 s METAL 15K 5% 1/16W	C109 1-115-871-11 s ELECT 1uF 20% 50V
R218	1-218-952-11 s METAL 820 5% 1/16W	C110 1-115-871-11 s ELECT 1uF 20% 50V
R219	1-218-961-11 s METAL 4.7K 5% 1/16W	C112 1-126-791-11 s ELECT 10uF 20% 16V
R220	1-220-184-11 s METAL 1.3K 5% 16W	C113 1-126-791-11 s ELECT 10uF 20% 16V
R221	1-218-961-11 s METAL 4.7K 5% 1/16W	C117 1-104-535-11 s FILM 470PF 5% 50V
R222	1-218-968-11 s METAL 18K 5% 1/16W	C152 1-104-532-91 s FILM 270PF 5% 50V
R223	1-218-968-11 s METAL 18K 5% 1/16W	C153 1-104-545-11 s FILM 0.0033uF 5% 16V
R224	1-220-193-81 s METAL 7.5K 5% 16W	C154 1-104-545-11 s FILM 0.0033uF 5% 16V
R225	1-220-193-81 s METAL 7.5K 5% 16W	C155 1-104-545-11 s FILM 0.0033uF 5% 16V
R226	1-218-968-11 s METAL 18K 5% 1/16W	C157 1-126-514-11 s ELECT 22uF 20% 16V
R227	1-220-193-81 s METAL 7.5K 5% 16W	C158 1-126-514-11 s ELECT 22uF 20% 16V
R228	1-216-835-11 s METAL 15K 5% 1/16W	C161 1-126-514-11 s ELECT 22uF 20% 16V
R229	1-216-833-11 s METAL 10K 5% 1/16W	C164 1-126-514-11 s ELECT 22uF 20% 16V
R230	1-216-809-11 s METAL 100 5% 1/16W	C166 1-104-666-11 s ELECT 220uF 20% 25V
R231	1-216-821-11 s METAL 1K 5% 1/16W	C167 1-104-666-11 s ELECT 220uF 20% 25V
R232	1-216-821-11 s METAL 1K 5% 1/16W	C171 1-126-791-11 s ELECT 10uF 20% 16V
R233	1-216-830-11 s METAL 5.6K 5% 1/16W	C201 1-107-715-11 s ELECT 22uF 20% 25V
R234	1-216-830-11 s METAL 5.6K 5% 1/16W	C202 1-107-715-11 s ELECT 22uF 20% 25V
R235	1-216-791-11 s METAL 3.3 5% 1/16W	C203 1-126-791-11 s ELECT 10uF 20% 16V
R236	1-216-791-11 s METAL 3.3 5% 1/16W	C206 1-104-547-11 s FILM 0.0047uF 5% 16V
R237	1-216-827-11 s METAL 3.3K 5% 1/16W	C208 1-104-551-11 s FILM 0.01uF 5% 16V
R238	1-216-827-11 s METAL 3.3K 5% 1/16W	C209 1-115-871-11 s ELECT 1uF 20% 50V
R239	1-216-827-11 s METAL 3.3K 5% 1/16W	C210 1-115-871-11 s ELECT 1uF 20% 50V
R240	1-216-821-11 s METAL 1K 5% 1/16W	C212 1-126-791-11 s ELECT 10uF 20% 16V
R301	1-216-841-11 s METAL 47K 5% 1/16W	C213 1-126-791-11 s ELECT 10uF 20% 16V
R302	1-216-841-11 s METAL 47K 5% 1/16W	C217 1-104-535-11 s FILM 470PF 5% 50V
R303	1-216-841-11 s METAL 47K 5% 1/16W	C252 1-104-532-91 s FILM 270PF 5% 50V

(SSP-11	BOARD)	(SSP-11	BOARD)
Ref. No. or Q'ty	Part No. SP Description		Part No. SP Description
IC107 IC201	8-759-900-72 s IC NE5532P 8-759-710-32 s IC NE5532S 8-759-900-72 s IC NE5532P 8-759-900-72 s IC NE5532P 8-759-900-72 s IC NE5532P	IC426 IC427 IC428 IC429 IC430	8-759-011-64 s IC MC74HC4052FEL 8-759-239-23 s IC SN74HC86ANS-E05 8-759-011-63 s IC MC74HC4051FEL 8-759-327-60 s IC TC7W125FU-TE12R 8-759-327-60 s IC TC7W125FU-TE12R
IC204 IC205 IC206 IC207 IC301	8-759-900-72 s IC NE5532P 8-759-900-72 s IC NE5532P 8-759-710-32 s IC NJM5532S 8-759-082-55 s IC TC7W00FU(TE12R)	IC432 IC433 IC434 IC435	8-759-933-85 s IC CXD10090 8-752-364-91 s IC CXK58257BM-10LL 8-759-926-77 s IC SN74HC541ANS-E05 8-759-970-59 s IC TLC272CPS-E05
IC304 IC305 IC306	8-759-082-55 s IC TC7W00FU(TE12R) 8-759-973-71 s IC TL7705CPS-B-E05 8-759-151-34 s IC UPD70216L-10 8-759-058-58 s IC TC7S04FU(TE85R) 8-759-390-65 s IC CXD8970R	IC436 IC437 IC438 IC439 IC440	8-759-970-59 s IC TLC272CPS-E05 8-759-011-64 s IC MC74HC4052FEL 8-759-239-23 s IC SN74HC86ANS-E05 8-759-327-60 s IC TC7W125FU-TE12R 8-759-058-58 s IC TC7S04FU(TE85R)
IC307 IC308 IC309 IC310 IC311	8-759-448-59 o IC 27C4002-SY307V1.00 8-759-174-34 s IC ST93CS56M1013TR 8-752-364-91 s IC CXK58257EM-10LL 8-752-364-91 s IC CXK58257EM-10LL 8-759-384-08 s IC SN74LS03NS-E05	IC441 IC523 IC601 IC602 IC603	8-759-082-58 s IC TC7W08FU(TE12R) 8-759-011-63 s IC MC74HC405IFEL 8-759-341-64 s IC UPD4218160LE-60 8-752-332-80 s IC CXD1160AQ 8-752-332-80 s IC CXD1160AQ
IC313	8-759-926-82 s IC SN74HC574ANS-E05 8-759-926-77 s IC SN74HC541ANS-E05 8-759-504-23 s IC RF5C62-E2 8-759-500-05 s IC MSM6338MS-KR1 8-759-082-57 s IC TC7W04FU(TE12R)	IC604 IC605 IC701 IC702 IC703	8-752-332-80 s IC CXD1160AQ 8-759-058-58 s IC TC7S04FU(TE85R) 1-466-312-11 s SYNC-1 UNIT 1-466-467-12 s SYNC-2B UNIT 8-759-096-87 s IC TC7WU04FU(TE12R)
IC317 IC318 IC319 IC320 IC321	8-759-360-99 s IC LT1134ACS-E2 8-759-433-04 s IC UPD78C11AGF-E62-3BE 8-759-061-67 s IC MC34051MEL 8-759-051-53 s IC TD62381F 8-759-051-53 s IC TD62381F	IC704 IC706 IC707 IC708 IC709	1-809-241-11 s VCO MODULE 8-759-926-80 s IC SN74HC573BNS-E05 8-759-926-82 s IC SN74HC574ANS-E05 8-759-926-80 s IC SN74HC573BNS-E05 8-759-926-82 s IC SN74HC574ANS-E05
IC322 IC323 IC324 IC325 IC326	8-759-926-49 s IC SN74HC245ANS-E05 8-759-926-49 s IC SN74HC245ANS-E05 8-759-926-49 s IC SN74HC245ANS-E05 8-759-058-62 s IC TC7S08FU(TE85R) 8-759-327-60 s IC TC7W125FU-TE12R	IC710 IC711 IC712 IC713 IC714	8-759-926-49 s IC SN74HC245ANS-E05 8-759-909-72 s IC CX-7912A 8-759-926-05 s IC SN74HC125ANS-E05 8-759-082-57 s IC TC7W04FU(TE12R) 8-759-925-78 s IC SN74HC10ANS-E05
IC327 IC401 IC402 IC403 IC404	8-759-239-55 s IC TC74HCl23AF(KL) 8-752-030-63 s IC CXA1046M-T6 8-759-082-55 s IC TC7W00FU(TE12R) 8-752-030-63 s IC CXA1046M-T6 8-759-082-55 s IC TC7W00FU(TE12R)	IC715 IC716 IC717 IC718 IC720	8-759-054-54 s IC SRM2016M10-TF 8-759-926-77 s IC SN74HC541ANS-E05 8-759-009-02 s IC MC14046BF 8-759-906-54 s IC TL064CNS-E05 8-759-327-60 s IC TC7W125FU-TE12R
IC405 IC406 IC407 IC408 IC409	8-759-082-55 s IC TC7W00FU(TE12R) 8-759-390-66 s IC CXD8971BR 8-759-327-60 s IC TC7W125FU-TE12R 8-759-013-41 s IC MC4044ML 8-759-030-21 s IC MC1648ML	IC801 IC802	8-759-923-64 s IC AM26LS32ACNS-E05 8-759-013-41 s IC MC4044ML 8-759-030-21 s IC MC1648ML 8-759-927-29 s IC SN74HCU04ANS-E05 8-759-998-40 s IC SN75124NS-E05
IC410 IC411 IC412 IC413 IC414	8-759-927-29 s IC SN74HCU04ANS-E05 8-759-082-57 s IC TC7W04FU(TE12R) 8-759-250-81 s IC TC5081AP 8-759-970-59 s IC TLC272CPS-E05 8-759-096-87 s IC TC7WU04FU(TE12R)	IC808	8-759-998-39 IC SN75121NS-E05 8-759-923-65 s IC AM26LS31CNS-E05 8-759-082-57 s IC TC7W04FU(TE12R) 8-759-327-60 s IC TC7W125FU-TE12R
IC417 IC418 IC419 IC420	8-759-933-84 s IC CXD1008Q 8-759-933-85 s IC CXD1009Q 8-752-364-91 s IC CXX58257BM-10LL 8-759-926-77 s IC SN74HC541ANS-E05	IS58 IS304 IS307	1-526-654-21 1 SOCKET, IC (DP) 16P 1-540-209-11 s SOCKET, PLCC (PCS-068A-1) 1-526-662-21 o SOCKET, IC (DP) 40P 1-412-527-11 s INDUCTOR 15uH
IC421 IC422 IC423 IC424	8-759-926-77 s IC SN74HC541ANS-E05 8-759-970-59 s IC TLC272CPS-E05 8-759-970-59 s IC TLC272CPS-E05 8-759-511-14 s IC TLC274CNS-E05	L2 L3 L4 L5	1-412-533-21 s INDUCTOR 47uH 1-412-533-21 s INDUCTOR 47uH 1-412-533-21 s INDUCTOR 47uH 1-412-533-21 s INDUCTOR 47uH
IC425	8-759-511-14 s IC TLC274CNS-E05	L6	1-406-749-11 s COIL (WITH TERMINAL BOARD)

(SSP-11	BOARD)	(SSP-11 BOARD) (SSP-11 BOARD)					
Ref. No. or Q'ty	Part No. SP Description	Ref. No. or Q'ty	Part No. SP Description				
L7		R51	1-208-810-11 s METAL 15K 0.50% 1/10W				
L51	1-412-533-21 s INDUCTOR 47uH	R52	1-216-627-11 s METAL 100 0.50% 1/10W				
L401 L402	1-412-533-21 s INDUCTOR 47uH 1-408-429-00 s INDUCTOR 470uH	R53	1-249-393-11 s CARBON 10 5% 1/4W 1-216-689-11 s METAL 39K 0.50% 1/10W				
L403	1-412-525-31 s INDUCTOR 10uH 1-412-533-21 s INDUCTOR 47uH 1-412-533-21 s INDUCTOR 47uH 1-408-429-00 s INDUCTOR 470uH 1-408-429-00 s INDUCTOR 470uH	R55	1-218-756-11 s METAL 150K 0.50% 1/10W				
L404 L405	1-426-259-11 s COIL, RF 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH	R56	1-216-689-11 s METAL 39K 0.50% 1/10W				
L406	1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH	K57 R58	1-218-756-11 s METAL 150K 0.50% 1/10W 1-218-325-11 s METAL 120 5% 1/4W				
L407	1-410-482-31 s INDUCTOR 100uH	R59	1-218-325-11 s METAL 120 5% 1/4W				
L408			1-216-635-11 s METAL 220 0.50% 1/10W				
L409 L410	1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH 1-410-482-31 s INDUCTOR 100uH	R61	1-216-635-11 s METAL 220 0.50% 1/10W 1-208-799-11 s METAL 5.1K 0.50% 1/10W				
L411	1-410-482-31 s INDUCTOR 100uH	R102	1-216-699-11 S METAL 100K 0.50% 1/10W				
L412	1-410-482-31 s INDUCTOR 100uH	R103	1-208-799-11 s METAL 5.1K 0.50% 1/10W				
L413			1-216-699-11 s METAL 100K 0.50% 1/10W				
L701 L702	1-408-429-00 s INDUCTOR 470uH 1-408-429-00 s INDUCTOR 470uH 1-410-482-31 s INDUCTOR 100uH 1-408-429-00 s INDUCTOR 470uH 1-410-482-31 s INDUCTOR 100uH	R105	1-216-663-11 s METAL 3.3K 0.50% 1/10W				
L703	1-410-482-31 s INDUCTOR 100uH	K105	1-216-663-11 s METAL 3.3K 0.50% 1/10W 1-216-647-11 s METAL 680 0.50% 1/10W				
L704	1-408-429-00 s INDUCTOR 470uH	R108	1-216-687-11 S METAL 33K 0.50% 1/10W				
L705			1-216-687-11 s METAL 33K 0.50% 1/10W				
L706	1-408-429-00 s INDUCTOR 470uH 1-408-429-00 s INDUCTOR 470uH 1-426-259-11 s COIL, RF 1-410-482-31 s INDUCTOR 100uH	R110	1-208-814-11 s METAL 22K 0.50% 1/10W				
L707 L801	1-408-429-00 s INDUCTOR 470uH 1-426-259-11 s COIL, RF	R111	1-216-660-11 s METAL 2.4K 0.50% 1/10W				
L802	1-410-482-31 s INDUCTOR 100uH	R112	1-216-660-11 s METAL 2.4K 0.50% 1/10W 1-216-682-11 s METAL 20K 0.50% 1/10W				
		R114	1-216-657-11 s METAL 1.8K 0.50% 1/10W				
LV401	1-406-406-11 s COIL (OSC)						
LV402 LV403	1-406-406-11 s COTE (OSC)	R115 R116	1-216-651-11 s METAL 1K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W				
	1 100 100 11 0 0011 (000)	R117	1-216-659-11 s METAL 2.2K 0.50% 1/10W				
PH1	8-719-902-56 s PHOTO COUPLER PC817	R118	1-216-659-11 s METAL 2.2K 0.50% 1/10W				
PJ1	1-406-406-11 s COIL (OSC) 1-406-406-11 s COIL (OSC) 1-406-406-11 s COIL (OSC) 8-719-902-56 s PHOTO COUPLER PC817 1-764-630-11 o JACK, PIN 2P	R119	1-218-768-11 s METAL 470K 0.50% 1/10W				
Q1	8-729-202-03 s TRANSISTOR 2SD1266-Q 8-729-902-11 s TRANSISTOR 2SC2021-R 8-729-902-11 s TRANSISTOR 2SC2021-R 8-729-902-11 s TRANSISTOR 2SC2021-R 8-729-027-31 s TRANSISTOR DTA124FK1-T146	R120	1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-854-11 s METAL 1M 0.50% 1/10W				
Õ2	8-729-902-11 s TRANSISTOR 2SC2021-R	R122	1-208-810-11 s METAL 15K 0.50% 1/10W				
Q3	8-729-902-11 s TRANSISTOR 2SC2021-R	R123	1-208-810-11 s METAL 15K 0.50% 1/10W				
Q4 Q51	8-729-902-11 s TRANSISTOR 2SC2021-R 8-729-027-31 s TRANSISTOR DTA124EKA-T146	R124	1-216-663-11 s METAL 3.3K 0.50% 1/10W				
Δητ	8-729-027-31 s TRANSISTOR DTA124EKA-T146 8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP	R125	1-208-854-11 s METAL 1M 0.50% 1/10W				
Q101	8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP	R126	1-216-659-11 s METAL 2.2K 0.50% 1/10W				
Q1 02	8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP	R127	1-216-662-11 s METAL 3K 0.50% 1/10W				
Q103 Q104	8-729-230-86 s TRANSISTOR 25K17U-GRBLV-TP 8-729-230-86 s TRANSISTOR 25K17U-GRBLV-TP	R128	1-208-751-11 s METAL 51 0.50% 1/10W				
Q201	8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP		1-216-699-11 s METAL 100K 0.50% 1/10W				
0202	8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP	R130	1-208-806-11 s METAL 10K 0.50% 1/10W				
0202	8-729-230-86 s TRANSISTOR 25K170-GRBLV-TP	R131 R132	1-218-768-11 s METAL 470K 0.50% 1/10W 1-216-699-11 s METAL 100K 0.50% 1/10W				
Q204	8-729-230-86 s TRANSISTOR 2SK170-GRBLV-TP	R133	1-216-699-11 S METAL 100K 0.50% 1/10W				
0401	8-729-807-51 = TRANSISTOR 2SC2873Y-TE12L	R134 >	1-216-651-11 s METAL 1K 0.50% 1/10W				
Q402	8-729-027-55 s TRANSISTOR DTC143EKA-T146	R135	1-216-627-11 s METAL 100 0.50% 1/10W				
0801	8-729-807-51 s TRANSISTOR 2SC2873Y-TE12L	R151	1-208-784-11 s METAL 1.2K 0.50% 1/10W				
Q8 Q 2	8-729-205-88 s TRANSISTOR 2SC3074-Y(TE16L)	R152	1-208-774-11 s METAL 470 0.50% 1/10W				
R1	1-220-285-11 s METAL 10K 5% 1/4W	R153	1-216-677-11 s METAL 12K 0.50% 1/10W				
R2	1-220-285-11 S METAL 10K 5% 1/4W 1-208-814-11 S METAL 22K 0.50% 1/10W	R154	1-208-784-11 s METAL 1.2K 0.50% 1/10W				
R23	1-220-277-11 s METAL 2.2K 5% 1/4W	R155	1-208-784-11 s METAL 1.2K 0.50% 1/10W				
R24	1-218-764-11 s METAL 330K 0.50% 1/10W	R156	1-208-784-11 s METAL 1.2K 0.50% 1/10W				
R25	1-216-687-11 s METAL 33K 0.50% 1/10W	R157	1-208-784-11 s METAL 1.2K 0.50% 1/10W				
R26	1-216-627-11 s METAL 100 0.50% 1/10W	R158 R159	1-216-637-11 s METAL 270 0.50% 1/10W 1-216-663-11 s METAL 3.3K 0.50% 1/10W				
R27	1-208-814-11 s METAL 22K 0.50% 1/10W						
R30	1-216-025-91 s METAL 100 5% 1/10W	R160	1-216-671-11 s METAL 6.8K 0.50% 1/10W				
R31 R32	1-216-662-11 s METAL 3K 0.50% 1/10W 1-216-049-91 s METAL 1K 5% 1/10W	R161	1-216-659-11 s METAL 2.2K 0.50% 1/10W				
11.7.2	T DIO OFFICIAL DE HELME IN De 1/10M	R162 R163	1-216-632-11 s METAL 160 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W				
		11703	1 200 000 II 3 MEINE TON U.JUS I/IUN				

6-20

(SSP-11	BOARD)	(SSP-11 BOARD)		
Ref. No. or Q'ty	Part No. SP Description	Ref. No. or Q'ty Part No. SP Description		
R164 R165 R166 R167 R168	1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-216-603-11 s METAL 10 0.50% 1/10W 1-216-603-11 s METAL 10 0.50% 1/10W			LOW /10W /10W
R169 R170 R171 R172 R173	1-216-667-11 s METAL 4.7K 0.50% 1/10W 1-216-667-11 s METAL 4.7K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W	R234 1-216-651-11 s METAL 1K 0.50% 1/10W R235 1-216-627-11 s METAL 100 0.50% 1/10W R251 1-208-784-11 s METAL 1.2K 0.50% 1/10W R252 1-208-774-11 s METAL 470 0.50% 1/10W R253 1-216-677-11 s METAL 12K 0.50% 1/10W	1-216-651-1 1-216-627-1 1-208-784-1 1-208-774-1 1-216-677-1	10W /10W 10W
R174 R175 R176 R177 R178	1-208-806-11 s METAL 10K 0.50% 1/10W 1-216-603-11 s METAL 10 0.50% 1/10W 1-216-603-11 s METAL 10 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-216-603-11 s METAL 10K 0.50% 1/10W			/10W /10W /10W
R179 R180 R181 R182 R183	1-216-603-11 s METAL 10 0.50% 1/10W 1-216-682-11 s METAL 20K 0.50% 1/10W 1-216-682-11 s METAL 20K 0.50% 1/10W 1-216-699-11 s METAL 100K 0.50% 1/10W 1-216-699-11 s METAL 100K 0.50% 1/10W			/10W /10W 10W
R184 R186 R187 R188 R189	1-208-799-11 s METAL 5.1K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-216-651-11 s METAL 1K 0.50% 1/10W 1-216-659-11 s METAL 2.2K 0.50% 1/10W			LOW LOW OW
R191 R192 R193 R194 R195	1-220-259-11 s METAL 150 5% 1/4W 1-216-659-11 s METAL 2.2K 0.50% 1/10W 1-220-259-11 s METAL 150 5% 1/4W 1-216-699-11 s METAL 100K 0.50% 1/10W 1-216-667-11 s METAL 4.7K 0.50% 1/10W	R269 1-216-667-11 s METAL 4.7K 0.50% 1/10 R270 1-216-667-11 s METAL 4.7K 0.50% 1/10 R271 1-208-806-11 s METAL 10K 0.50% 1/10W R272 1-208-806-11 s METAL 10K 0.50% 1/10W R273 1-208-806-11 s METAL 10K 0.50% 1/10W	1-216-667-1 1-216-667-1 1-208-806-1 1-208-806-1 1-208-806-1	/10W LOW LOW
R199 R201 R202 R203 R204	1-216-627-11 s METAL 100 0.50% 1/10W 1-208-799-11 s METAL 5.1K 0.50% 1/10W 1-216-699-11 s METAL 100K 0.50% 1/10W 1-208-799-11 s METAL 5.1K 0.50% 1/10W 1-216-699-11 s METAL 100K 0.50% 1/10W	R274 1-208-806-11 s METAL 10K 0.50% 1/10W R275 1-216-603-11 s METAL 10 0.50% 1/10W R276 1-216-603-11 s METAL 10 0.50% 1/10W R277 1-208-806-11 s METAL 10K 0.50% 1/10W R278 1-216-603-11 s METAL 10 0.50% 1/10W	1-208-806-1 1-216-603-1 1-216-603-1 1-208-806-1 1-216-603-1	OW LOW
R205 R206 R207 R208 R209	1-216-663-11 s METAL 3.3K 0.50% 1/10W 1-216-663-11 s METAL 3.3K 0.50% 1/10W 1-216-647-11 s METAL 680 0.50% 1/10W 1-216-687-11 s METAL 33K 0.50% 1/10W 1-216-687-11 s METAL 33K 0.50% 1/10W	R279 1-216-603-11 s METAL 10 0.50% 1/10W R280 1-216-682-11 s METAL 20K 0.50% 1/10W R281 1-216-682-11 s METAL 20K 0.50% 1/10W R282 1-216-699-11 s METAL 100K 0.50% 1/10W R283 1-216-699-11 s METAL 100K 0.50% 1/10W	1-216-603-1 1-216-682-1 1-216-682-1 1-216-699-1 1-216-699-1	LOW LOW /10W
R210 R211 R212 R213 R214	1-208-814-11 s METAL 22K 0.50% 1/10W 1-216-660-11 s METAL 2.4K 0.50% 1/10W 1-216-660-11 s METAL 2.4K 0.50% 1/10W 1-216-682-11 s METAL 20K 0.50% 1/10W 1-216-657-11 s METAL 1.8K 0.50% 1/10W	R284 1-208-799-11 s METAL 5.1K 0.50% 1/10 R286 1-208-806-11 s METAL 10K 0.50% 1/10W R287 1-208-806-11 s METAL 10K 0.50% 1/10W R288 1-216-651-11 s METAL 1K 0.50% 1/10W R289 1-216-659-11 s METAL 2.2K 0.50% 1/10W	1-208-806-1 1-208-806-1 1-216-651-1	LOW LOW DW
R215 R216 R217 R218 R219	1-216-651-11 s METAL 1K 0.50% 1/10W 1-208-806-11 s METAL 10K 0.50% 1/10W 1-216-659-11 s METAL 2.2K 0.50% 1/10W 1-216-659-11 s METAL 2.2K 0.50% 1/10W 1-218-768-11 s METAL 470K 0.50% 1/10W	R291 1-220-259-11 s METAL 150 5% 1/4W R292 1-216-659-11 s METAL 2.2R 0.50% 1/10 R293 1-220-259-11 s METAL 150 5% 1/4W R294 1-216-699-11 s METAL 100K 0.50% 1/10 R295 1-216-667-11 s METAL 4.7K 0.50% 1/10	1-216-659-1 1-220-259-1 1-216-699-1	/10W
R220 R221 R222 R223 R224	1-208-806-11 s METAL 10K 0.50% 1/10W 1-208-854-11 s METAL 1M 0.50% 1/10W 1-208-810-11 s METAL 15K 0.50% 1/10W 1-208-810-11 s METAL 15K 0.50% 1/10W 1-216-663-11 s METAL 3.3K 0.50% 1/10W	R299 1-216-627-11 s METAL 100 0.50% 1/10W R301 1-216-121-91 s METAL 1M 5% 1/10W R303 1-216-121-91 s METAL 1M 5% 1/10W R309 1-216-049-91 s METAL 1K 5% 1/10W R310 1-216-049-91 s METAL 1K 5% 1/10W	1-216-121-9 1-216-121-9 1-216-0 49 -9	.0 W
R225 R226 R227 R228	1-208-854-11 s METAL 1M 0.50% 1/10W 1-216-659-11 s METAL 2.2K 0.50% 1/10W 1-216-662-11 s METAL 3K 0.50% 1/10W 1-208-751-11 s METAL 51 0.50% 1/10W	R339 1-216-049-91 s METAL 1K 5% 1/10W R340 1-216-049-91 s METAL 1K 5% 1/10W R347 1-216-025-91 s METAL 100 5% 1/10W R379 1-216-017-91 s METAL 47 5% 1/10W	1-216-049-9 1-216-025-9	

```
SV-147A BOARD
Ref. No.
or Q'ty Part No.
                                 SP Description
              A-8312-269-A o MOUNTED CIRCUIT BOARD, SV-147A
(This assembly includes the following parts.)
4pcs
              3-374-740-01 s BRACKET, LED
              1-135-208-11 s TANTAL 1uF 20% 10V
              1-135-208-11 s TANTAL 1uF 20% 10V
1-135-208-11 s TANTAL 1uF 20% 10V
C3
C4
              1-162-969-11 s CERAMIC 0.0068uF 10% 25V
1-135-259-11 s TANTAL 10uF 20% 6.3
C5
              1-162-970-11 s CERAMIC 0.01uF 10% 25V 1-164-227-11 s CERAMIC 0.022uF 10% 25V 1-162-970-11 s CERAMIC 0.01uF 10% 25V 1-162-965-11 s CERAMIC 0.0015uF 10% 50V 1-164-156-11 s CERAMIC 0.1uF 25V
C7
C8
C9
C10
C11
C12
              1-135-259-11 s TANTAL 10uF 20% 6.3
              1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
C13
C14
C15
C16
              1-135-208-11 s TANTAL 1uF 20% 10V
C17
              1-135-208-11 s TANTAL 1uF 20% 10V
1-135-208-11 s TANTAL 1uF 20% 10V
1-135-259-11 s TANTAL 10uF 20% 6.3
C18
C19
              1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
C20
C21
              C22
C23
C24
C25
C26
C27
              1-162-970-11 s CERAMIC 0.01uF 10% 25V
              1-164-156-11 s CERAMIC 0.1uF 25V
1-162-970-11 s CERAMIC 0.01uF 10% 25V
C28
C29
              1-162-916-11 s CERAMIC, CHIP 12PF 5% 50V
1-162-916-11 E CERAMIC, CHIP 12PF 5% 50V
C30
C31
              1-162-970-11 s CERAMIC 0.01uF 10% 25V 1-162-964-11 s CERAMIC 0.001uF 10% 50V 1-162-966-11 s CERAMIC 0.0022uF 10% 50V 1-164-227-11 s CERAMIC 0.022uF 10% 25V 1-164-156-11 s CERAMIC 0.1uF 25V
C32
C33
C34
C35
C36
C37
              1-135-259-11 s TANTAL 10uF 20% 6.3
              1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
C38
C39
              1-128-397-21 s ELECT 100uF 20% 16V
C40
C41
              1-164-156-11 s CERAMIC 0.1uF 25V
C42
              1-164-156-11 s CERAMIC 0.1uF 25V
C43
              1-128-397-21 s ELECT 100uF 20% 16V
              1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
C44
C45
C46
              1-135-227-11 s TANTAL 100uF 20% 6.3
C47
              1-164-156-11 s CERAMIC 0.1uF 25V
              1-164-156-11 s CERAMIC 0.1uF 25V
1-164-156-11 s CERAMIC 0.1uF 25V
C48
C49
              1-135-259-11 s TANTAL 10uF 20% 6.3
1-135-259-11 s TANTAL 10uF 20% 6.3
C50
C51
              1-164-156-11 s CERAMIC 0.1uF 25V 1-164-156-11 s CERAMIC 0.1uF 25V
C52
C53
              1-128-397-21 s ELECT 100uF 20% 16V
1-128-397-21 s ELECT 100uF 20% 16V
C54
```

1-164-156-11 s CERAMIC 0.1uF 25V

C55 C56

NOTE: Please see page 6-10 for the parts that are not listed in the parts list.

(SSP-11 BOARD)

or Q'ty Part No.

SP Description

1-567-098-41 s CRYSTAL 32.768kHz 1-760-429-11 s CRYSTAL 14.5MHz 1-567-970-11 s CRYSTAL 24.576MHz

1-567-965-11 s CRYSTAL 22.5792MHz

Ref. No.

X305

X401 X402

(SV-147A	BOARD)	(SV-147A	BOARD)
Ref. No. or Q'ty	Part No. SP Description	~ -	Part No. SP Description
C57	1-164-156-11 s CERAMIC 0.1uf 25V	Q2	8-729-140-75 s TRANSISTOR 2SD999-T1-CLCK
C58	1-164-156-11 s CERAMIC 0.1uf 25V	Q3	8-729-901-00 s TRANSISTOR DTC124EK-T146
C59	1-164-156-11 s CERAMIC 0.1uf 25V	Q4	8-729-901-00 s TRANSISTOR DTC124EK-T146
C60	1-164-156-11 s CERAMIC 0.1uf 25V	Q5	8-729-140-75 s TRANSISTOR 2SD999-T1-CLCK
C61	1-164-156-11 s CERAMIC 0.1uf 25V	Q6	8-729-140-75 s TRANSISTOR 2SD999-T1-CLCK
C62	1-164-156-11 s CERAMIC 0.1uF 25V	Q7	8-729-901-00 s TRANSISTOR DTC124EK-T146
C63	1-164-156-11 s CERAMIC 0.1uF 25V	Q8	8-729-901-00 s TRANSISTOR DTC124EK-T146
C64	1-162-968-11 s CERAMIC 0.0047uF 10% 50V	Q9	8-729-901-00 s TRANSISTOR DTC124EK-T146
C65	1-135-259-11 s TANTAL 10uF 20% 6.3	Q10	8-729-901-00 s TRANSISTOR DTC124EK-T146
C66	1-162-294-31 s CERAMIC 0.001uF 10% 50V	Q11	8-729-901-00 s TRANSISTOR DTC124EK-T146
CN1	1-691-419-11 o HOUSING, CONNECTOR 8P	Q12	8-729-901-00 s TRANSISTOR DTC124EK-T146
CN2	1-566-532-11 s CONNECTOR, FPC (ZIF) 16P	Q13	8-729-230-49 s TRANSISTOR 2SC2712Y-TE85L
CN3	1-566-195-11 o PIN, CONNECTOR (PC BOARD) 2P	Q14	8-729-040-11 TRANSISTOR 2SB1323-TD
CN4	1-566-526-11 s CONNECTOR, FPC (ZIF) 10P	Q15	8-729-140-75 s TRANSISTOR 2SD999-T1-CLCK
CN5	1-566-524-21 s CONNECTOR, FPC (ZIF) 8P	Q16	8-729-901-00 s TRANSISTOR DTC124EK-T146
CN6 CN7 CN8 CN10 CN11	1-569-529-11 o HOUSING, CONNECTOR 14P 1-506-479-11 s PIN, CONNECTOR 14P 1-566-534-11 s CONNECTOR, FPC (ZIF) 18P 1-566-526-11 s CONNECTOR, FPC (ZIF) 10P 1-506-485-11 s PIN, CONNECTOR 6P	Q17 Q18 R1 R2	8-729-901-00 s TRANSISTOR DTC124EK-T146 8-729-901-00 s TRANSISTOR DTC124EK-T146 1-216-841-11 s METAL 47K 5% 1/16W 1-218-736-11 s METAL 68K 0.50% 1/16W
D1 D2 D3 D4 D5	1-566-534-11 S CONNECTOR, FPC (ZIF) 18P 1-566-526-11 S CONNECTOR, FPC (ZIF) 10P 1-506-485-11 S PIN, CONNECTOR 6P 8-719-016-38 S DIODE LN1351C6-TR 8-719-016-38 S DIODE LN1351C6-TR 8-719-016-38 S DIODE LN1351C6-TR 8-719-980-38 S DIODE SB07-03C-TB 8-719-980-38 S DIODE SB07-03C-TB	R3 R4 R5 R6 R7	1-218-736-11 s METAL 68K 0.50% 1/16W 1-216-635-11 s METAL 220 0.50% 1/10W 1-216-635-11 s METAL 220 0.50% 1/10W 1-216-853-11 s METAL 470K 5% 1/16W 1-216-841-11 s METAL 47K 5% 1/16W
D6 D7 D8 D9	8-719-016-38 s DIODE LN1351C6-TR 8-719-980-38 s DIODE SB07-03C-TB 8-719-980-38 s DIODE SB07-03C-TB 8-719-037-59 s DIODE LN210RP 8-719-037-60 s DIODE LN410YP 8-719-018-39 s DIODE LN310GP 8-719-037-60 s DIODE LN410YP	R8 R9 R10	1-218-716-11 s METAL 10K 0.50% 1/16W 1-218-700-11 s METAL 2.2K 0.50% 1/16W 1-216-651-11 s METAL 1K 0.50% 1/10W 1-218-698-11 s METAL 1.8K 0.50% 1/16W
D10 D11 D12 D13 D14	8-719-018-39 S DIODE LN310GP 8-719-037-60 S DIODE LN410YP 8-719-801-78 S DIODE 1SS184 8-719-801-78 S DIODE 1SS184 8-719-801-78 S DIODE 1SS184 8-719-801-78 S DIODE 1SS184 8-719-980-38 S DIODE SE07-03C-TB	R12 R13 R14 R15	1-218-845-11 s METAL 820 0.50% 1/16W 1-216-841-11 s METAL 47K 5% 1/16W 1-216-651-11 s METAL 1K 0.50% 1/10W 1-216-841-11 s METAL 47K 5% 1/16W 1-218-716-11 s METAL 10K 0.50% 1/16W
D15	8-719-980-38 s DIODE SB07-03C-TB 8-719-801-78 s DIODE 1SS184	R17 R18 R19 R20	1-216-793-11 S METAL 4.7 5% 1/16W 1-216-793-11 S METAL 4.7 5% 1/16W 1-216-793-11 S METAL 4.7 5% 1/16W 1-216-651-11 S METAL 1.7 5% 1/16W
IC1	8-759-929-26 s IC TL431CPS-E20	R21	1-216-635-11 s METAL 220 0.50% 1/10W
IC2	8-752-039-31 s IC CXA1418N-T4	R22	1-216-635-11 s METAL 220 0.50% 1/10W
IC3	8-752-038-71 s IC CXA1127AM-T6	R23	1-216-651-11 s METAL 1K 0.50% 1/10W
IC4	8-759-251-48 s IC UPC358GR-E1	R24	1-216-651-11 s METAL 1K 0.50% 1/10W
IC5	8-759-925-90 s IC SN74HC74ANS-E20	R25	1-218-716-11 s METAL 10K 0.50% 1/16W
IC6	8-759-925-90 s IC SN74HC74ANS-E20	R26	1-218-716-11 s METAL 10K 0.50% 1/16W 1-218-716-11 s METAL 10K 0.50% 1/16W 1-218-716-11 s METAL 10K 0.50% 1/16W 1-216-635-11 s METAL 220 0.50% 1/10W 1-218-716-11 s METAL 10K 0.50% 1/16W
IC7	8-759-927-29 s IC SN74HCU04ANS-E05	R27 ~	
IC8	8-759-926-77 s IC SN74HC541ANS-E20	R28	
IC9	8-752-850-58 IC CXP87532-029Q	R29	
IC10	8-759-998-49 s IC MB3771PF-TF	R30	
IC11	8-759-245-52 s IC TA7291F-EL	R31	1-218-716-11 s METAL 10K 0.50% 1/16W
IC12	8-759-551-68 s IC M6M80021FP-T3	R32	1-216-635-11 s METAL 220 0.50% 1/10W
IC13	8-759-300-71 s IC MC14053BF-T2	R33	1-216-635-11 s METAL 220 0.50% 1/10W
IC14	8-759-926-06 s IC SN74HC126ANS-E20	R34	1-216-635-11 s METAL 220 0.50% 1/10W
IC15	8-759-823-87 s IC LB1638MTP-T2	R35	1-216-857-11 s METAL 220 0.50% 1/16W
IC16	8-759-251-48 s IC UPC358GR-E1	R36	1-218-841-11 s METAL 560 0.50% 1/16W
IC17	8-759-150-61 s IC UPC78L05T-E1	R37	1-216-809-11 s METAL 100 5% 1/16W
IC18	8-759-150-61 s IC UPC78L05T-E1	R38	1-216-841-11 s METAL 47K 5% 1/16W
L1	1-410-381-11 s INDUCTOR CHIP 10UH	R39	1-216-841-11 s METAL 47K 5% 1/16W
L2	1-410-381-11 s INDUCTOR CHIP 10UH	R40	1-216-841-11 s METAL 47K 5% 1/16W
Q1	8-729-230-49 s TRANSISTOR 2SC2712Y-TE85L	R41	1-216-841-11 s METAL 47K 5% 1/16W

6-24 P;M-7040

```
(SV-147A BOARD)
                                                                                       SW-420 BOARD
Ref. No.
                                                                                       Ref. No.
or Q'ty Part No.
                           SP Description
                                                                                       or Q'ty Part No.
                                                                                                                   SP Description
            1-216-841-11 s METAL 47K 5% 1/16W
                                                                                                   1-637-270-11 o PRITED CIRCUIT BOARD, SW-420
                                                                                       1pc
           1-216-841-11 s METAL 47K 5% 1/16W
R43
                                                                                                   1-946-966-11 o HARNESS (SW)
R44
                                                                                       CNR
R45
                                                                                                   1-506-469-11 s PIN, CONNECTOR 4P
                                                                                       CN9
R46
                                                                                       D/19
                                                                                                   8-719-911-19 s DIODE 1SS119-25TD
R47
            1-216-841-11 s METAL 47K 5% 1/16W
                                                                                       D50
                                                                                                   8-719-911-19 s DIODE 1SS119-25TD
            1-216-841-11 s METAL 47K 5% 1/16W
R48
                                                                                       D51
                                                                                                   8-719-911-19 s DIODE 1SS119-25TD
            1-216-809-11 s METAL 100 5% 1/16W
R49
                                                                                       D52
                                                                                                   8-719-911-19 s DIODE 1SS119-25TD
            1-216-841-11 s METAL 47K 5% 1/16W
R50
R51
            1-218-736-11 s METAL 68K 0.50% 1/16W
                                                                                       S28
                                                                                                   1-554-937-11 s SWITCH, KEY BOARD
                                                                                       S29
                                                                                                   1-554-937-11 s SWITCH, KEY BOARD
                                                                                                   1-554-937-11 s SWITCH, KEY BOARD
1-554-937-11 s SWITCH, KEY BOARD
R52
            1-218-716-11 s METAL 10K 0.50% 1/16W
                                                                                       S30
            1-216-841-11 s METAL 47K 5% 1/16W
1-216-829-11 s METAL 4.7K 5% 1/16W
1-218-716-11 s METAL 10K 0.50% 1/16W
R53
R54
R55
R56
            1-218-706-11 s METAL 3.9K 0.50% 1/16W
R57
            1-218-716-11 s METAL 10K 0.50% 1/16W
            1-216-829-11 S METAL 4.7K 5% 1/16W
1-216-841-11 S METAL 47K 5% 1/16W
1-218-700-11 S METAL 2.2K 0.50% 1/16W
1-218-736-11 S METAL 68K 0.50% 1/16W
R58
R59
                                                                                       VR-109 BOARD
R60
                                                                                       -----
R61
                                                                                       Ref. No.
                                                                                       or Q'ty Part No.
                                                                                                                   SP Description
            1-218-700-11 s METAL 2.2K 0.50% 1/16W 1-218-700-11 s METAL 2.2K 0.50% 1/16W 1-218-716-11 s METAL 10K 0.50% 1/16W 1-218-716-11 s METAL 10K 0.50% 1/16W
R62
R63
                                                                                                   1-637-284-13 o PRINTED CIRCUT BOARD, VR-109
                                                                                       1pc
R64
R65
                                                                                       CN1
                                                                                                   1-564-004-11 o PIN, CONNECTOR 5P
            1-216-841-11 s METAL 47K 5% 1/16W
R66
                                                                                       CN2
                                                                                                    1-506-470-11 s PIN, CONNECTOR 5P
R67
            1-216-841-11 s METAL 47K 5% 1/16W
            1-218-698-11 s METAL 1.8K 0.50% 1/16W
1-216-841-11 s METAL 47K 5% 1/16W
1-216-841-11 s METAL 47K 5% 1/16W
R68
R69
R70
R71
            1-218-716-11 s METAL 10K 0.50% 1/16W
            1-216-809-11 s METAL 100 5% 1/16W
1-218-899-11 s METAL 150K 0.50% 1/16W
R72
R73
R74
            1-216-809-11 s METAL 100 5% 1/16W
R75
            1-218-867-11 s METAL 6.8K 0.50% 1/16W
R76
            1-218-867-11 s METAL 6.8K 0.50% 1/16W
            1-218-724-11 s METAL 22K 0.50% 1/16W 1-218-724-11 s METAL 22K 0.50% 1/16W 1-216-635-11 s METAL 220 0.50% 1/10W
R78
R79
            1-216-809-11 s METAL 100 5% 1/16W
1-216-841-11 s METAL 47K 5% 1/16W
R80
R81
R82
            1-216-841-11 s METAL 47K 5% 1/16W
             1-216-841-11 s METAL 47K 5% 1/16W
R83
             1-216-841-11 s METAL 47K 5% 1/16W
R84
R 95
             1-216-841-11 s METAL 47K 5% 1/16W
R86
             1-216-841-11 s METAL 47K 5% 1/16W
 R87
             1-216-841-11 s METAL 47K 5% 1/16W
R88
             1-215-907-11 s METAL 22 5% 3W
             1-216-841-11 s METAL 47K 5% 1/16W
1-218-724-11 s METAL 22K 0.50% 1/16W
 R89
 R90
 S1
            1-570-598-11 s SWITCH, DIP
X1
            1-579-962-21 s CRYSTAL 22.5792MHz
```

```
FRAME
 Ref. No.
 or Q'ty Part No. SP Description
        1-241-332-11 s RES, VAR, CARBON 20K
1-241-331-11 s RES, VAR, CARBON 10K/10K
1-507-863-51 s JACK, LARGE TYPE

• $\Delta$ 1-251-384-11 s INLET (WITH NOISE FILTER), AC
 2pcs
 1pc
 1pc
 1pc
         △ 1-429-937-11 s TRANSFORMER, POWER
 [SUB HARNESS (RF1)]
 CN401 (to SSP-11 board)
             1-565-977-11 s TERMINAL, SOLDERLESS
 CN2 (to RF-53 board)
             1-565-977-11 s TERMINAL, SOLDERLESS
 [SUB HARNESS (RF2)]
             1-956-633-11 o HARNESS, SUB (RF2)
This cable includes the following connectors.
 1pc
             CN404 (to SSP-11 board)
TP1, TP2 (to RF-53 board)
[SUB HARNESS (KY POWER)]
CN12 (to SSP-11 board)
1-562-260-11 p CONTACT, SOCKET
1-580-696-11 p HOUSING, CONNECTOR 9P
 CN6 (to KY-192 board)
             1-562-260-11 o CONTACT, SOCKET
1-580-696-11 o HOUSING, CONNECTOR 9P
 [SUB HARNESS (PS)]
CN3 (to SSP-11 board)
          Δ 1-562-210-11 © CONTACT, CONNECTOR
Δ 1-562-833-11 © HOUSING, CONNECTOR 7P
     (to Power Switch)
          △ 1-570-117-41 s SWITCH, SEESAW (AC POWER)
 [SUB HARNESS (AC IN)]
          Δ 1-956-636-11 o HARNESS, SUB (AC IN)

This cable includes the following connectors.
             CN1 (to SSP-11 board)
- (to AC Inlet)
 [SUB HARNESS (SAFETY GND)]
          ▲ 1-956-636-11 o HARNESS, SUB (SAFETY GND)
             This cable includes the following connector.
               - (to AC Inlet)
 [SUB HARNESS (TR1)]
CN2 (to SSP-11 board)
1-562-210-11 o CONTACT, CONNECTOR
1-562-285-11 o HOUSING, CONNECTOR 4P
 [SUB HARNESS (TR2)]
 CN11 (to SSP-11 board)
1-562-210-11 o CONTACT, CONNECTOR
1-562-800-11 o HOUSING, CONNECTOR 9P
 [SUB HARNESS (REC VR1)]
             1-956-643-11 o HARNESS, SUB (REC VR1)
 1pc
              This cable includes the following connectors.
             CN102 (to SSP-11 board)
CN1 (to VR-109 board)
 [SUB HARNESS (REC VR2)]
             1-956-644-11 o HARNESS, SUB (REC VR2)
             This cable includes the following connectors.
             CN202 (to SSP-11 board)
             CN2 (to VR-109 board)
             1-956-645-11 o HARNESS, SUB (HP)
             This cable includes the following connectors.
             CN52 (to SSP-11 board)
             CN4 (to KY-192 board)
NOTE: Please see page 6-10 for the parts that are not listed
          in the parts list.
```

(FRAME) Ref. No. or Q'ty Part No. SP Description [SUB HARNESS (KY DIAL)] 1-956-647-11 o HARNESS, SUB (KY DIAL) 1pc This cable includes the following connectors. CN303 (to SSP-11 board) CN3 (to KY-192 board) [SUB HARNESS (KY FL)] 1-956-648-11 o HARNESS, SUB (KY FL)
This cable includes the following connectors. 1pc CN304 (to SSP-11 board) CN2 (to KY-192 board) [SUB HARNESS (SV POWER)] 1-956-649-11 o HARNESS, SUB (SV POWER) 1pc This cable includes the following connectors. CN403 (to SSP-11 board) CN11 (to SV-147A board) [SUB HARNESS (SV CONT)] 1-956-650-11 o HARNESS, SUB (SV CONT) This cable includes the following connectors. CN402 (to SSP-11 board) CN7 (to SV-147A board)

6-4. Accessories Supplied

Section 7 Semiconductor Pin Assignments

ここに記載されている半導体は、それぞれの機能を等価的 に表したものです。 なお、互換性のない型名を併記して いることがありますので、部品を交換するときは、Spare Partsの章を参照してください。

等価回路はICメーカーのデータブックに従いました。


Semiconductors of which functions are equivalent are described here. For parts replacement, refer to the section of Spare Parts in this manual. The circuit diagram of each IC is obtained from the IC data book published by the manufacturer.

DIODE	PAGE	DIODE	PAGE	TRANSISTOR	PAGE	IC	PAGE
1S2837-T1	7-3	U1GC44	7-3	2SA1162-Y	7-4	AK5339-VF	77-5
188119-25	7-3	U1GC44-TE12R	7-3	2SA1162Y-TE85L	7-4	AM26LS31	CNS 7-5
1SS119-25TD	7-3			2SB1323	7-4	AM26LS31	CNS-E05 7-5
1SS123-T1				2SB1323-TC	7-4	AM26LS32	ACNS 7-5
188184	7-3			2SC2021-Q		AM26LS32	ACNS-E05 7-5
1\$\$226				2SC2021-R			
1SS352				2SC2223-F14		CX-7912A	7-6
1SS352-TPH3	7-3			2SC2223-T1F14		CXA1046M	7-8
				2SC2712Y-TE85L	7-4	CXA1046M	-T6 7-8
BR3338\$	7-3			2SC2873Y-TE12L	7-4	CXA1127A	M 7-8
				2SC3074-Y	7-4	CXA1127A	M-T67-8
CL-150PG-CD .	7-3			2SC3074-Y(TE16L)		CXA1364R	7-9
CL-150PG-CD-1				2SD1408-Y			7-9
CL-150R-CD	7-3			2SD1266-Q	7-4	CXA1418N	-T4
CL-150R-CD-T	7-3			2SD1623-S	7-4	CXD1008C	
CL-150Y-CD	7-3			2SD999-CLCK	7-4	CXD1009C	7-11
CL-150Y-CD-T	7-3			2SD999-T1-CLCK		CXD1160A	Q 7-12
				2SK170-GRBLV	7-4	CXD8970R	7-31
EBG5334S	7-3			2SK170-GRBLV-TP	7-4	CXD8971B	R 7-32
EMBG3338S						CXK58257	3M-10LL 7-13
ERC88M-009	7-3			DTA114EKA-T146	7-4	CXP87532	029Q 7-14
				DTA143EKA-T146	7-4		
GL453	7-3			DTA124EKA-T146	7-4	HD14053B	FP 7-13
GL453S	7-3			DTC124EK	7-4		
				DTC124EK-T146		LB1638M .	7-13
KV1362A-1	7-3			DTC143EKA-T146	7-4	LB1638MT	P-T2 7-13
KV1372A-1	7-3			DTC143TKA-T146		LM2576T-A	DJ 7-15
						LT1134AC	7-15
LN1351C6	7-3			NJL5803K-F10	7-4		
LN1351C6-TR.	7-3					M6M80021	FP 7-15
LN210RP	7-3			PC817		M6M80021	FP-T3 7-15
LN310GP	7-3			PT4850F	7-4	MB3771PF	7-15
LN410YP	7-3					MB3771PF	-TF 7-15
				THS117	7-4	MB88346B	PFV 7-16
MPY3338S	7-3			THS117-TE85L	7-4	MB88346B	PFV-EF 7-16
						MC14046B	F 7-16
NSQ03A04	7-3					MC14053B	F-T2 7-13
NSQ03A04-TE1	16L 7-3					MC1648M	7-16
						MC1648ML	7-16
PY5334S	7-3					MC34051N	7-16
						MC34051N	EL 7-16
RD33M-B	7-3					MC4044ML	
R033M-T1B	7-3					MC74HC40	51F 7-17
RD5.6M-B2	7-3						51FEL 7-17
RD5.6M-T1B	7-3					MC74HC40	52F 7-17
							52FEL 7-17
S15VB60	7-3					MSC62408	-018GS-V1K - 7-18
SB07-03C						MSM6338N	IS-K 7-17
SB07-03C-TB	7-3					MX27C409	5DC-12 7-19
		•					

IC	PAGE	IC	PAGE
NE5532P	7-19	TA7291F	7-24
NJM5532S	7-19	TA7291F-EL	7-24
NJM78L05A		TA7812S	
NJM79L05A	7-19	TA7815S	
		TA79005S	
PCM69AP-K	7-20	TA79015S	
		TC5081AP	
RF5C62	7-20	TC74HC123AF	
RF5C62-E2		TC74HC123AF(EL)	
		TC74HC74P	
SM5843AP1	7-21	TC74HC86AF	
SN74HC00ANS		TC7S04FU(TE85R)	
SN74HC00ANS-E05		TC7S08FU(TE85R)	
SN74HC04ANS	7-21	TC7W00FU	
SN74HC04ANS-E05	7-21	TC7W00FU(TE12R)	
SN74HC10ANS		TC7W04FU(TE12R)	
SN74HC10ANS-E05	7-21	TC7W08FU	
SN74HC125ANS	7-21	TC7W08FU(TE12R)	7-26
SN74HC125ANS-E05	7-21	TC7W125FU-TE12R	
SN74HC126ANS	7-22	TC7WU04FU(TE12R).	
SN74HC126ANS-E20	7-22	TD62381F	
SN74HC138ANS	7-22	TL064CNS	7-27
SN74HC138ANS-E05	7-22	TL064CNS-E05	7-27
SN74HC175ANS	7-22	TL431CPS	7-27
SN74HC175ANS-E05		TL431CPS-E20	7-27
SN74HC245ANS	7-22	TL7705CPS-B	7-27
SN74HC245ANS-E05	7-22	TL7705CPS-B-E05	7-27
SN74HC541ANS		TLC272CPS	7-27
SN74HC541ANS-E20	7-22	TLC272CPS-E05	7-27
SN74HC573BNS	7-23	TLC274CNS	
SN74HC573BNS-E05	7-23	TLC274CNS-E05	7-27
SN74HC574ANS			
SN74HC574ANS-E05		UPC358GR-E1	7-27
SN74HC74ANS		UPC78L05T	7-27
SN74HC74ANS-E05	7-23	UPC78L05T-E1	7-27
SN74HC74ANS-E20	7-23	UPD4218160LE-60	7-28
SN74HC86ANS-E05		UPD70216L-10	7-29
SN74HCU04ANS-E05	7-21	UPD78C11AGF	
SN74HCU04ANS-E20	7-21	-E62-3BE	7-30
SN74LS03NS-E05			
SN75121NS			
SN75124NS			
SRM2016M10			
SRM2016M10-TF			
ST93CS56M1013TR.	7-24		

7-2

DIODE





ERC88M-009 (FUJI ELECT)




RD33M-B RD5.6M-B2 RD33M-T1B RD5.6M-T1B



1\$\$184 1S2837-T1



GL453S ;INFRARED GL453





188226 1SS123-T1





SB07-03C SB07-03C-TB



KV1362A-1 (TOKO) KV1372A-1



-TOP VIEW-

1SS352 1SS352-TPH3



LN1351C6 GREEN(MATSUSHITA) LN1351C6-TR



BR3338S RED(STANLEY) EBG5334S GREEN(STANLEY) EMBG3338S GREEN(STANLEY) MPY3338S YELLOW(STANLEY) PY5334S YELLOW(STANLEY)



LN210RP ;RED LN310GP ;GREEN LN410YP;YELLOW



CL-150PG-CD ;GREEN CL-150R-CD RED CL-150Y-CD YELLOW CL-150PG-CD-T CL-150R-CD-T CL-150Y-CD-T



NSQ03A04 U1GC44 (TOSHIBA) NSQ03A04-TE16L U1GC44-TE12R





TRANSISTOR

-TOP VIEW-



2SA1162-Y (TOSHIBA) 2SA1162Y-TE85L

2SD1623-S 2SD999-CLCK 2SC2873Y-TE12L 2SD999-T1-CLCK

TOP VIEW

NJL5803K-F10






2SB1323 2SB1323-TC



-TOP VIEW-

2SK170-GRBLV (TOSHIBA) 2SK170-GRBLV-TP





2SC2021-Q (ROHM) 2SC2021-R



DTA114EKA-T146 (R1=10K, R2=10K) DTA143EKA-T146 (R1=4.7K R2=4.7K)



PC817



-TOP VIEW-



2SC2223-F14 (NEC) 2SC2712Y-TE85L (TOSHIBA) DTC143TKA-T146 (ROHM) (R1=4.7K, R2=10K) 2SC2223-T1F14



DTA124EKA-T146



PT4850F



2SC3074-Y (TOSHIBA) 2SC3074-Y(TE16L)



DTC124EK (ROHM) (R1=22K, R2=22K) DTC143EKA-T146 (R1=4.7K, R2=2.7K) DTC124EK-T146



THS117 THS117-TE85L





2SD1408-Y (TOSHIBA) 2SD1266-Q



AK5339-VP (ASAHIKASEI ELECT)

C-MOS OVERSAMPLING STEREO A/D CONVERTER






: ANALOG CALIERATION NORMALLY, CONNECT TO DCAL PIN.
: L CHANNEL ANALOG INPUT
: R CHANNEL ANALOG INPUT
: R CHANNEL ANALOG INPUT
: RAMALOG POWER DOWN
: Ha POWER DOWN MODE) NORMALLY, CONNECT TO DPD PIN.
: MASTER CLOCK
: MASTER CLOCK SELECTION
L: CLX = 2589 H: CLX = 25419
: NOSITAL POWER DOWN (H = POWER DOWN MODE)
: 1289 CLOCK INPUT (CONNECT TO OCLK PIN.)
: INPUT CHANNEL SELECTION
DATA CHANNEL SELECTION
DATA CHANNEL SELECTION
DATA CHANNEL DATA, L = R CHANNEL DATA)
: SERIAL DATA OUTPUT CLOCK
INTERPACE SELECTION
L: CONTROLED MODE H: CONTROL MODE
: TEST (CONNECT TO DOD)
: L CHANNEL ZERO LEVEL INPUT
: R CHANNEL ZERO LEVEL INPUT INPUT ACAL AINL AINR APD DPD ICLK SCLK SMODE TST ZEROL ZEROR

OUTPUT DCAL OCUK SDATA

; DIGITAL CALIBRATION
1285 CLOCK OUTPUT
1 SERNAL DATA OUTPUT
DATA IS OUTPUT IN ORDER FROM MSB IN 2ND COMPLEMENT.
1 REFERENCE VOLTAGE SUPPLY OF ~3.68V

AM26LS31CNS (TI)FLAT PACKAGE AM26LS31CNS-E05

HIGH SPEED DIFFERENTIAL LINE DRIVER




	FUNCTION TABLE						
1	EN2	EN1	OUTPUT				
	0	0	ENABLE				
1	٥	1	ENABLE				
	1	0	H⊢Z				
	1	1	ENABLE				
	0 :LOW LEVEL						
	1 ; HIGH LEVEL						
	HI-Z; HIGH IMPEDANCE						

AM26LS32ACNS (TI)FLAT PACKAGE

AM26LS32ACNS-E05

HIGH SPEED DIFFERENTIAL LINE RECEIVER




FUNCTION TABLE				
EN2	EN1	OUTPUT		
0	0	ENABLE		
0	1	ENABLE		
. 1	٥	HI-Z		
1	1	ENABLE		
; LOW LEVEL ; HIGH LEVEL				
HI-Z ; HIGH IMPEDANCE				

	SENSE	INPUT VOLT
C32/LS32	±200mV	±7V
1622	+E00mW	-15M


CX-7912A (SONY)

C-MOS TIME CODE READER



- 4	4000
PIN	ASSIGNMENT

23	81	OUT	SYMBOL	PIN NO	IN	OUT	SYMBOL	PIN NO	IN	олт	SYMBOL	PIN NO	IH	OUT	SYMBOL.
3	0		S1	17		0	AD4	33	0		SLCT	49		0	AD 3
8	0		RSTt	18		0	RDSY	34	0		OUIOS	50		0	BSRL.
3		0	OER	19		0	CKO	35	0		34	51		0	TCT
4		0	BER	20	0		CKIN	36	0		32	52	0		SCKI
5		0	FWRE	21		0	SCKO	37	0		TSG 1	50		0	TMO
6	0		DCS	22	0		DMSS	38	0		TSG 2	54		0	GND
7		0	WR	23	0		PN	30	0		TSG 3	55	0		IPN
8	0		ACS	24		0	PNO			0	CIND	54		0	AS 6
9		0	DO 0	85		0	ASS	41		0	H40	57		0	AS 4
10		0	CFSA	26		0	ASS	42		0	HEO	58		0	AS 2
11		0	CFS 8	27		0	ASI	43		0	H160	50		0	DCLK
12		0	CFS C	29		0	DATA	44		0	DO 1	80		0	CAL
13		0	CFS D	29	0		FRE	45		0	DO 5	61	0		Voo(-SV)
14		0	FLO	30	0		CTLI	44		0	DO 3	62	0		SLTC
15	匚	0	ADO	31	0		TC IN	47	0		Y00(+5V)	63	0		TPN
16		0	AD2	22		0	OVF	46	_	0	AD1	44	0		TEST




HODE SELEC


SLCT	SLTC	MODE	ו ו	CTL C	THUO	
0	0	AUTO	1 1	FRE	RSTI	COUNT
0	. 1	TIME CODE	1 1	0	×	DOWN COUNT
. 1_	0	CTL		1	×	UP COUNT
1	1	AUTO]	Х	7	RESET


SIGNAL FORMAT SELECT

\$4	SZ	\$1	PORMAT	FRAME	
0	0	0	FILM	24	
0	0	1			
0	1	0		_	1
0	1	1			
1	0	0	EBU (PAL SECAM)	25	1
1	0	1	NOT ALLOWED	-	
1	1	0	NTSC (NON DROP FRAME)	30	0 : LOW LEVEL 1 : HIGH LEVEL
1	1	1	NTSC (DROP FRAME)	30	X DON'T CAR

TIMING CHART








CXA1364R (SONY)

REC/PB AMP FOR R-DAT




PSN Na.	\ 0	SIGNAL	PIN No.	1/0	SIGANL	PIN No.	10	SIGNAL	PIN No.	10	SIGNAL
1	0	LIM OUT	13	0	PLT OUT	25	-	B PC	37	0	A 140 CIVE
2	-	LIM GND	14		GCA CTL	26	-	B HA IN	38	-	SAG TC
3		MOD1 IN	15	-	EQ PHASE	27	0	B RA OUT	39	-	
4		MOD2 IN	16	-	EQ Q	28	-	HA GND	40		B R PCM
5		LIM Vcc	17	~	EO HIGH	29	-	REC GNO	41		
6	0	ENV OUT	18	-	EQ LOW	30	-	REC BIAS	42		
7	1	ENV COMP	19	-	PB GND	31		HA Voc	43	<u> </u>	
8	-	ENV PEAK	20	1	EQ #N	32	-	REC Voc	44	-	PB Vcc
9	1	LIM IN	21	0	SWA OUT	33	0	A RA OUT	45		REDT IN
10	0	EQ OUT	22	0	V REG	34		A HA IN	46		REPB IN
11	0	P EV OUT	23	0	B HA OUT			A PC	47	-	PIPC IN
12		P ENV IN	24	-	8 LPC	36	_	A LPC	48	-	SWP IN

RIPUT
A HA IN
B HA IN


OUTPUT
A HA OUT
A RA OUT
B HA OUT
EN OUT
E

SWA OUT
VREG
REGULATOR OUTPUT
VREG
COTHERS
A LPC
CONNECTION PIN FOR SMOOTHING CAPACITOR OF ACH HEAD
AMPLIFIER DC SERVO
CONNECTION PIN FOR SMOOTHING CAPACITOR OF ACH HEAD
AMPLIFIER RIST STAGE GROUNCED ENTITER TRYASSITOR
B LPC
B LPC
CONNECTION PIN FOR RESISTOR DETERMINING ALC CURRENT
CONNECTION PIN FOR RESISTOR DETERMINING ACH REC CURRENT
CONNECTION PIN FOR DESISTOR DETERMINING ALC OWNERTH
RESISTOR OF PIN 38 ACH PILOT SIGNAL REC CURRENT
CONNECTION PIN FOR DESISTOR DETERMINING ALC OWNERTH
RESISTOR OF PIN 38 ACH PILOT SIGNAL REC CURRENT
CONNECTION PIN FOR DESISTOR DETERMINING ALC OWNERTH
RESISTOR OF PIN 39 ACH PILOT SIGNAL REC CURRENT
CONNECTION PIN FOR RESISTOR DETERMINING ALC OWNERTH
RESISTOR OF PIN 40, BICH PILOT SIGNAL REC CURRENT
RESISTOR OF PIN 40, BICH PILOT SIGNAL REC CURRENT
RESISTOR OF PIN 40, BICH PILOT SIGNAL REC CURRENT
RESISTOR OF PIN 40, BICH PILOT SIGNAL REC CURRENT
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN FOR HOT SIGNAL REC CURRENT
FOR CONNECTION PIN OF THE CAPACITOR FOR REP PEAK PILOT
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HIGH BAND PEAK FREQUENCY AND PILOT FILTER CUT OFF
REQUENCY
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMINING
PIN ED HASE CHARACTERISTIC.
RESISTOR OF CURRENT SOURCE IS CONNECTED FOR DETERMI




CXA1418N (SONY) CXA1418N-T4

SENSOR AMPLIFIER FOR R-DAT




CXD1008Q (SONY)


C-MOS R-DAT SIGNAL PROCESSING(ERROR CORRECTION)



PIN No.	1/0	SIGNAL	PIN No.	1/0	SIGNAL	PIN No.	VO	SIGNAL	PIN No.	10	SIGNAL
1	1	RST	17	1/0	LR03	33	1/0	CTL1	49	ō	A2
2	1	TST	18	5	DFCK	34	1/0	EXCK	50	0	Al
Э	0	PHCO	19	10	DIOC	35	1/0	STAT	51	0	AO
4	1	TST2	20	0	DADT	36	1/0	SBSY	52	0	PRGE
5		DALF	21	0	ERRE	37	1/0	SRVS	53	ō	PTRO
6	1/0	VCOI	22		ADOT	38		ADAE	54	0	AW
7	F	ADLF	23	1/0	XBCK	39	1/0	FLGC	55	1	DOE
8	-	XT2I	24	0	BCK	40	1	CKRS	56	1/0	D7
9	0	XT20	25	1/0	WCK	41	1	CLKI	57	1/0	D6
10	-	GND	26	-	Voo	42	-	GND	58	-	You
11	1	XT3!	27	10	LRCK	43	1	PREN	59	1/0	D5
12	0	XT3O	28		FSEN	44	1/0	RCPB	60	1/0	D4
13	1	AUDR	29		MUTG	45	1/0	PRGS	61	10	03
14	1/0	MNTG	30	1/0	PION	46	1/0	CIC2	62	1/0	D2
15	1/0	LROI	31	1/0	PIUP	47	0	A4	63	1/0	D1
16	1/0	LR02	32	1/0	CTL2	48	0	EA	64	1/0	DO










CXD1009Q (SONY)

C-MOS SIGNAL PROCESSING(RAM CONTROL) FOR R-DAT - TOP VIEW -




PIN No.	1/0	SIGNAL	PIN No.	1/0	SIGNAL	PtN No.	V0	SIGNAL	PIN No.	1/0	SIGNAL
1	-	PTRD	21	1	SWP	41	0	PHCO	51	1/0	AD05
2	1	PRGE	22		DPG	42	1	TEST	62	1/0	AD06
3	1	ECAC	23	0	SVRF	43	1	VCOI	63	1/0	AD07
4		ECAT	24	1	RSEL	44	0	VCOO	64	1/0	AD08
- 5	1	ECA2	25	0	SBSY	45	-	CKOE	65	1/0	AD09
6	-	ECAS	26	1/0	SBOT	46		PBOT	66	0	AD10
7	\equiv	ECA4	27	1	EXCK	47	1	CLR	67	0	AD11
8	0	C1C2	28	1	DTC1	48	0	REDT	68	0	AD12
9	0	PRGS	29	1	DTC2	49	0	REPB	69	0	AD13
10	0_	ECRP	30	1	LRCK	50	0	XTIO	70	1/0	DO
11	0	PREN	31	1	WCK	51		XTII	71	1/0	D1
12	-	GND	32	1/0	EXSY	52	-	GND	72	1/0	D2
13	1/0	CLKO	33	-	V00	53	0	EAN	73	-	Vap
14	0	CSET	34	0	ATD2	54	0	WE	74	1/0	D3
15	0	FLCT	35	0	ATDI	55	0	ŌĒ	75	1/0	D4
16	0	DARE	36		ATSY	56	1/0	AD00	76	1/0	D5
17		SRVS	37	0	ATS3	57	1/0	AD01	77	1/0	D6
18	0	C94M	38	0	ATS2	58	1/0	AD02	78	1/0	D7
19	0	PLCK	39	0	AT\$1	59	1/0	AD03	79	Ó	DE
20	0	CRCM	40	1	RFSFO	60	1/0	AD04	80	1	RW






CXD1160AQ (SONY)

C-MOS DIGITAL AUDIO SIGNAL PROCESSOR



PIN NO	1/0	SYMBOL	PIN NO.	1/0	SYMBOL	PIN NO.	1/0	SYMBOL	PIN NO.	1/0	SYMBOL
1	-	NC	21	_	MCK2	41	-	NC	61	0	A2
5	-	NC	22	-	NC	42	-	MC	62	-	NC
3	-	NC	23	-	NC	43	-	NC	63	-	HC.
4		TST	24	-	NC	44	1	XCLR	64	-	NC
5	-	NC	25	-	NC	45	-	NC	65	-	HC
- 6	-	NC	26	-	NC	46	-	NC	66	-	MC
7	- 1	WC.	27	I	\$ i	47	-	HC	67	0	AO
В	-	NC	28	0	\$0	48	-	HC	68	0	XRAS
9	-	GND	29	1	BCK	49	-	V 90 I+5V)	69	0	XWSQ
10	-	MC	30		LRCK	50	-	NC	70	1/0	DIO
11	-	NC	31	0	XOVF	51	-	NC	71	0	XCAS
12	-	NC	32	-	NC	52	-	NC	72	-	NC
13	-	HC	33	-	NC	53	-	NC	73	-	NC
14	-	NC	34	0	A6	54	-	NC	74		SOT
15	I - I	NC	35	0	A3	55	-	NC	75		SCK
16	1	MCK1	36	0	A4	56	0	A1	76		XSLD
17	-	NC	37	0	A5	57	-	NC	77	1	5102
18	-	NC	38	0	A7	58	-	NC	78		DYSL
19	-	NC	39	-	NC	59	-	NC	79	-	NC
20	- 1	NC	40	-	NC	60	-	NC	80	-	NC



SERIAL BIT CLOCK
FOR SERIAL INPUT DATA
ISI) AND SERIAL OUTPUT
DATA (SO)
DELAY I/O MODE SELECT
SAMPLING FREQ CLOCK
MASTER CLOCK ?
MASTER CLOCK ?
SERIAL CLOCK FOR SDT
SERIAL DATA FROM CPU
SERIAL DATA FROM CPU
SERIAL DATA IZ'S COMPLEMENT)
BCK CLOCK MODE SELECT
(L IGMD) 32 BIT CLOCK MODE.
H 1-5V):24 BIT CLOCK MODE:
FOR TEST
LATCH FOR SDT ISERIAL DATA)
ACTIVE LOW BCK DYSL LRCK MCK1 MCK2 SCK SDT S | S | 02 TST XCLR XSLD OUTPUT

A0-A7 : ADDRESS FOR EXT. DRAM

SO : SERIAL DATA (2's COMPLEMENT)

XCAS : COLUMN ADDRESS STROSE FOR

EXT. DRAM

XOVF : OVERFLOW DETECT

XRAS : ROW ADDRESS STROSE FOR


EXT. DRAM

75 SID2
77 SID2
78 SID2
79 SCK
76 SCK
76 XSLD
16 MCK 1
21 MCK 2
4 TST
4 KCL 8 XWS0 69 210 40 28AS 71 XCAS 67 A0 56 A1 61 A2 25 A3 36 A4 37 A5 34 A6 38 TST XCLR

INPUT/OUTPUT
DIO :SERIAL DATA INPUT (DYSL=L) OR
DATA IMPUT/OUTPUT FOR
EXT. DRAM (DYSL=H)


CXK58257BM-10LL (SONY)

C-MOS 256K (32,768×8)-BIT STATIC RAM




ÇE	ΟĒ	WE	MODE	VO TERMINAL
1	×	×	NOT SELECT	HIGH IMPEDANCE
0	. 1	1	OUTPUT DISABLE	HIGH IMPEDANCE
0	0	. 1	READ	OUTPUT DATA
Ċ	×	0	WRITE	INPUT DATA
				0 - LOWLEVEL

1 : HIGH LEVEL X : DON'T CARE



HD14053BFP (HITACHI)FLAT PACKAGE MC14053BF-T2


C-MOS TRIPLE 2-CHANNEL ANALOG MULTIPLEXERS/DEMULTIPLEXERS — TOP VIEW —




LB1638M (SANYO)FLAT PACKAGE LB1638MTP-T2

FORWARD/REVERSE MOTOR DRIVE


-TOP VIEW-





CXP87532-029Q (SONY)

C-MOS 8-BIT MICROCOMPUTER -TOP VIEW-



PIN NO.	NO	SIGNAL	PIN NO.	Ю	SIGNAL	PIN NO.	МО	SIGNAL	PIN NO.	М	SIGNAL
1	0	PBS/PPOS	26	10	P14	51	70	SCK1/PH0	76	20	PK2
2	0	PB4/PPO4	27	20	PI3	52	1	CS0	77	10	PKIMICLK
3	0	PB3/PPO3	28	Ю	Pt2	53	1	S10	78	10	PKO/RFDT
4	0	PB2/PPO2	29	Ю	Pl1	54	٥	SOO	79	0	PE7/SWP
5	0	PB1/PPO1	30	1/0	Pio	55	Ю	SCKO	80	0	PEG/PWM4
6	0	PB0/PPO0	31	0	PJ7	56	-	AGND	81	0	PES/PWM3
7	10	PC7	32	0	PJ6	57	_	AVREF	82	0	PE4/PWM2
8	1/0	PC6	33	0	PJ5	58	_	AVDD	83	0	PE3/PWM1
9	NO	PC5	34	0	PJ4	59	1	PF7/AN7	84	0	PE2/PWMO
10	1/0	PC4	35	0	PJ3	60	-	PF6/AN6	85	1	PET/EC/INT2
11	10	PC3	36	0	PJ2	61	J	PF5/AN5	86	1	PEONNTO
12	1/0	PC2	37	٥	PJ1	62	1	PF4/AN4	87	-	NM
13	1/0	PC1	38	0	PJO	63	1	PF3/AN3	88	-	GND
14	10	PC0	39	F	MP	64	1	PF2/AN2	89	-	VDD
15	100	PD7	40	¥O	AST	65	1	PF1/AN1	90	-	NC
16	10	PD6	41	_	GND	66	1	PF0/AN0	91	0	PA7/ATFS2
17	1/0	PD6	42	-	XTAL	67	1	PG7/PFG1	92	0	PAS/AREA
18	10	PD4	43	1	EXTAL	68	1	PG6/PFG0	93	0	PAS/ATFS3
19	3/0	PD3	44	0	PH7	69	1	PG5/CFG	94	0	PAVATES1
20	10	PD2	45	0	PH6	70	1	PG4/DFG	95	o	PASPROUT
21	Ю	PD1	46	0	PHS	71	1	PG3/DPG	96	0	PA2/PPO10
22	100	PD0	47	1/0	PH4	72	1	PG2/DREF	97	0	PAI/PPO9
23	NO	PI7	46	1	OS1/INT1/PH3	73	-1	PG1/EXI1	98	0	PAWPPOB
24	NO	PI6	49	1	SI1/PH2	74	T	PG0/EXI0	99	0	P87/PP07
25	10	PIS PIS	50	1/0	SO1/PH1	75	NO	PK3	100	0	PB6/PPO6


93 94	PASATE PASATE									PE	BPWM3 BPWM3 WPWM2	81 82
	PA3/PR									PE	DPWN I	181
97	PA2/PPC PA1/PPC										ECANT2	\$5
	PAGPE	28									BONNTO	*
	P87/PP									Pi	G7/PFG1	67 49
,	PBOPP										36/PEQ0	5
2	PBS/PPC PBs/PPC										GSCFG	70
3	PEOPP	-									GUDFG	71
	PB2/PPC										200REF	72
5	PEI/PP	21									GLEXI	73
ŀ	PBOPP	30									GD-EJ00	76
긔	PC7										P1-17	20
긁	PC4										P946	46
10	PCs PCs										PHS	
11	PC3									200.4	PH4 RT1/PHG	47
12	PC2									GO IN	Sh/H2	40
	PC1										BOL/PHI	50
- 1	PC0										CKWHO	51
15	PD7										P17	23
<u>"=</u>	PD6										PHB	24
Ή	PD6										PIS	25
5	PDI										P14	27 29 29
20	PD3										PI3 PI2	2
21	en:										PE	29
믝	PD7 PD6 PD6 PD6 PD7										P11 P10	30
=	MP										PJ7	31
웩	AST										Pus	
أوا											PJ5	
13	EXTAL										P.M	35
	EXIAL										P,I3	38
3	CSO										Put Put Put Put	36 36 37
13	SIO									. .	Puo	
	500	PF7/AN7	PF6/AND	PFWAN	PF2/AND	PF1/AN1			N N N	20		
		33	z 3	3	3 S	2 2	AGND	AVID		€ €		

meut	
AND - ANT	; A - D CONVERTOR'S ANALOG INPUTS
CFG	CAPSTAN FG INPUT
CS0	; SERIAL INTERFACE OHIP SELECT INPUT
RFG0, RFG1	: REEL FG INPUTS
DPG, DFG	; DURM PG AND FG INPUTS
DREF	DRUM REF, SIGNAL INPUT
₹C	; EVENT CONTROL INPUT FOR TIMER/COUNTER
EXIO, EXII	EXTERNAL INPUTS
EXTAL	GRYSTAL CONNECTION OR EXTERNAL CLOCK INPUT
INTO - INTO	FOR SYSTEM CLOCK GENERATOR
	: INTERRUPT REQUEST INPUTS (FALLING EDGE ACTIVE)
MCLK	CHANNEL CLOCK INPUT
MP	: TEST MODE INPUT
REDT	: NON-MASKABLE INTERRUPT REQUEST
PEO. PE1	; PLAY BACK DATA INPUT
PFO - PF7	: INPUTS OF PORT E (PE2 - PE7 : OUTPUTS)
PG0 - PG7	; INPUTS OF PORT F : INPUTS OF PORT G
PHO - PH3	; INPUTS OF PORT H (PH4 - PH7 : OUTPUTS)
SIO, SI1	: SERIAL DATA INPUTS
310, 311	; SCHAL DATA REPORT
OUTPUT	
ATFS1 - ATFS3, AREA	: MONITOR OUTPUTS FOR ATF
PAO - PA7	OUTPUTS OF PORT A
P80 - P87	: OUTPUTS OF PORT 8
PE2 - PE7	: OUTPUTS OF PORT E (PEO, PE1 : INPUTS)
PH4 - PH7	: OUTPUTS OF PORT H (N-CH OPEN DRAIN OUTPUTS)
PPO0 - PPO10, PROUT	PROGRAMMABLE PATTERN GENERATOR OUTPUTS
PWMO - PWM4	: PULSE WIDTH MODULATION OUTPUT
SO0, SO1	; SERIAL DATA OUTPUTS
SWP	; SWP OUTPUT
XTAL	: CRYSTAL CONNECTION
PK0 - PK3	; INPUTS/OUTPUTS OF PORT K
INPUT/OUTPUT	
PCO - PC7	: INPUTS/OUTPUTS OF PORT C
P00 - P07	: INPUTS/OUTPUTS OF PORT D
P10 - P17	: INPUTS/OUTPUTS OF PORT (
PJD - PJP	: INPUTS/OUTPUTS OF PORT J
RET	: SYSTEM RESET INPUT AND POWER ON RESET OUTPUT
SCKO, SCKO	: SERIAL CLOCK INPUTS/OUTPUTS
	, manufacture dispositions
OTHER	
ACNE	

: A - D CONVERTOR'S GROUND ; A - D CONVERTOR'S VDD ; A - D CONVERTOR'S REFERENCE VOLTAGE INPUT


LM2576T-ADJ (NSC)

STEP-DOWN TYPE VOLTAGE REGULATOR SIDE VIEW -



LT1134ACS (LINEAR TECH)FLAT PACKAGE

RS232C DRIVERS/RECEIVERS -TOP VIEW-



INPUT
DRIVER IN
RX EM
OUTPUT
DRIVER OUT
RX GUT

:RS-232C DRIVER IMPUTS RECEIVER INPUTS


:RS-202C DRIVER OUTPUTS
.RECEIVER OUTPUTS TEL/CHOS VOLTAGE LEVELS

51+, G1=, G2+, G2+

.EXTERNAL CAPACITORS :POSITIVE SUPPLY RS-232C-0AIVERSI .MEGATIVE SUPPLY RS-232C 0AIVERSI

M6M80021FP (MITSUBISHI)FLAT PACKAGE M6M80021FP-T3


C-MOS 2k(128x16)BIT ERASABLE PROM - TOP VIEW -




RESET

MB3771PF (FUJITSU)FLAT PACKAGE MB3771PF-TF


2-WAY SUPPLY VOLTAGE SUPERVISOR - TOP VIEW -






MB88346BPFV (FUJITSU)FLAT PACKAGE(SMALL) MB88346BPFV-EF

C-MOS 8-BIT D/A CONVERTER




AC1 - AC12 : 8-BIT DIA OUTPUTS
CK : CLOCK INPUT
DI : SERIAL DATA INPUT
DO : DATA CUTPUT
LD : DATA COAD CONTROL INPUT (M:LOAD)



MC14046BF (MOTOROLA) FLAT PACKAGE


C-MOS PHASE LOCKED LOOP



+2 to +6V

MC1648M (MOTOROLA)FLAT PACKAGE MC1648ML


ECL VOLTAGE CONTROLLED OSCILLATOR



Supply Vallage	Supply Pias	GND Pins
+5.0Vdc	1,14	7,8
~ 5.2 Vec	7,8	1,14

MC34051M MC34051MEL (MOTOROLA)

RS-422 DRIVER / RECEIVER





DR EN	MODE
0	DISABLE
1	ENABLE
0 ; LOW LET	
DA ; DA	IVER



MC4044ML (MOTOROLA)


PHASE-FREQUENCY DETECTOR - TOP VIEW -





MC74HC4052F (MOTOROLA)FLAT PACKAGE MC74HC4052FEL

C-MOS DUAL 4-CHANNEL ANALOG MULTIPLEXER/DEMULTIPLEXER



REF	;	REFERENCE IN	
VAR	;	VARIABLE IN	

- R VARIABLE IN
 UP OUT 1
 DOWN OUT 1
 UP OUT 2
 DOWN OUT 2
 CHARGE PUMP UP IN
 CHARGE PUMP UP OUT
 CHARGE PUMP UP OUT
 CHARGE PUMP DOWN IN
 CHARGE PUMP UP OUT D1 D2 D2 PU F5 A1
- FILTER AMP IN

PHASE FREQ. DET-1 FALLING EDGE SENSING TYPE

INPUTS	OUT	PUTS
MICIS	U1	D1
fv = fe		Γ. Π
SV= SR	L'	L'.
fv <fr< th=""><th>_</th><th>$\overline{}$</th></fr<>	_	$\overline{}$
Pv lags Pa	Iٽ	١,١
fv > fn		
DV leads BR	Ι'	"


PHASE FREQ.DET-2 FOR 50% DUTY CYCLES

INP	INPUTS		PUTS
REF	VAR	U2	02
0	0	1	1
0	7	1	-1
1	0	0	1
1	1	1	0

O LOW LEVEL


MSM6338MS-K (OKI)

C-MOS DIGITAL AUDIO PEAK LEVEL DETECTOR





MC74HC4051F (MOTOROLA)FLAT PACKAGE MC74HC4051FEL


C-MOS 8-CHANNEL ANALOG MULTIPLEXER/DEMULTIPLEXER -TOP VIEW-



00	NTRO	LINPL	ITS	
EN	S	ELEC	T	SELECTED
EM	С	В	Α	
٥	0	0	0	XO
0	0	0	1	X3
0	0	1	0	X2
۵	0	1	1	жa
0	1	0	0	X4
0	. 1	0	1	X5
٥	1	1	0	X6
0	1	1	1	X7
1	x	X	X	OPEN
		1	:	LOW LEVEL HIGH LEVEL DON'T CARE









MX27C4096DC-12 (MACRONICS)

C-MOS 4M(256lox16)-BIT EPROM -TOP VIEW-






NE5532P (TI)

DUAL OPERATIONAL AMPLIFIER — TOP VIEW —



NJM5532S (JRC)

DUAL OPERATIONAL AMPLIFIER - SIDE VIEW -




NJM78L05A (JRC)+5V(100mA)

POSITIVE VOLTAGE REGULATOR






NJM79L05A (JRC)-5V(100 mA) NEGATIVE VOLTAGE REGULATOR



PCM69AP-K (BURR-BROWN)

C-MOS DUAL 18-BIT D/A CONVERTER



HCEO 181

1=D--- 1=D---


Y = A - B = A + B


SN74HC00ANS (TI)FLAT PACKAGE SN74HC00ANS-E05


INPUT INTERFACE CIRCUIT

BCK 11 SYS-CLK 12 WDCK 13

C-MOS QUAD 2-INPUT NAND GATES









RF5C62 (RICOH)FLAT PACKAGE RF5C62-E2


C-MOS REAL TIME CLOCK -- TOP VIEW --



AO - A3
CE
CS:
DO - D3
INTR
OSCIN
OSCIN
OSCOUT
HID
TMOUT
WE ADDRESS BUS INPUTS
CHIP EMABLE INPUT
CHIP SELECT INPUT
DATA BUS INPUTSOUTPUTS
INTRUDE OUTPUT
CRYSTAL/CLOCK INPUT
CRYSTAL/CLOCK OUTPUT
TRADE OUTPUT
TIMER OUTPUT
TIMER OUTPUT
WHITE STROBE INPUT




SM5843AP1 (NPC)



SN74HC04ANS (TI)FLAT PACKAGE SN74HCU04ANS-E20 (TI)FLAT PACKAGE SN74HC04ANS-E05 SN74HCU04ANS-E05

C-MOS HEX INVERTERS



VDO

111	의	
	OW LE	

INPUT BIT CLOCK
INPUT FREQUENCY SELECT (N: 384%/L: 258%)
DE-EMPHASIS CONTROL (L: OFFA: ON)
INPUT DATA (INFINAL JINPUT FORMAT SELECT 2 (INFINAM)
DE-EMPHASIS SELECT


19 (H2)
328: 44.114, 48K, TEST MODE
SETTING
FSEL2 H L H L
INPUT POPMAT SELECT 1
INPUT WORD LENGTH 1 (INFINAL)/Ich DATA INPUT (TINFINAM)
INPUT WORD LENGTH 2 (INFINAL)/Ich DATA INPUT (TINFINAM)
SAMPLE RATE CLOCK (A)
ATTENUATION SERIAL DATA
ATTENUATION SERIAL SERIAL
ATTENUATION SERIAL
AT

INFIN INVINDIL INVINDIR LRCI MCK MDT MLEN MUTE OW20N

SYSTEM RESET (L: RESETH: NORMAL)
SYNC MODE SELECT (L: EXECUTION SYNC MODE/H: JITTER FREE MODE)
DITHER ONOFF SELECT (L: ON/H: OFF)
FILTER CHARACTER SELECT
OSCILLATOR NPUT

OUTPUT BIT CLOCK OSCILLATOR OUTPUT CLOCK

OUTPUT BCKO CKO DOL DOR WCKO XTO ; Leh DATA ; Reh DATA ; OUTPUT WORD CLOCK ; OSCILLATOR OUTPUT




SN74HC10ANS (TI)FLAT PACKAGE SN74HC10ANS-E05

C-MOS 3-INPUT NAND GATE

NOTE:


TYPE


74AC/74VHC/74VHC/T +2 to +5.5V 74AC/7/4HC/T +4.5 to +5.5V 74LC/X +2 to +3.6V OTHER TYPE +2 to +6V



SN74HC125ANS (TI)FLAT PACKAGE SN74HC125ANS-E05

C-MOS BUS BUFFER GATES WITH 3-STATE OUTPUT






NOTE:	
TYPE	V00
74AC/	+2 to +5.5V
74VHC	+2 10 +3.5V
74ACT/74HCT	+4.5 to +5.5V
74LCX	+2 to +3.6V
74LVT/74LVC	+2.7 to +3.6V
OTHER TYPES	+2 to +6V


SN74HC126ANS (TI)FLAT PACKAGE SN74HC126ANS-E20

C-MOS BUS BUFFER GATE WITH 3-STATE OUTPUT



SN74HC138ANS (TI)FLAT PACKAGE SN74HC138ANS-E05


C-MOS 3-TO-8 LINE DECODER / DEMULTIPLEXER



SN74HC175ANS (TI)FLAT PACKAGE SN74HC175ANS-E05


C-MOS QUAD D-TYPE FUP-FLOPS WITH RESET -TOP VEW-


+2 to +6V



SN74HC245ANS (TI)FLAT PACKAGE SN74HC245ANS-E05


C-MOS BILATERAL BUS TRANSCEIVERS WITH 3-STATE OUTPUTS TOP VIEW.






SN74HC541ANS (TI)FLAT PACKAGE SN74HC541ANS-E20

C-MOS BUFFERS AND LINE DRIVERS WITH 3-STATE OUTPUTS - TOP VIEW -



SN74HC573BNS SN74HC573BNS-E05 (TI)FLAT PACKAGE


C-MOS 3-STATE OUTPUT OCTAL LATCHE -TOP VIEW -




10 GND	11 CK N	CK10		1	1	1
NOTE:		02-9				
TYPE	Voc					
AC	+2 10 +67					
HC						
ABT	1					
ACT	+5V					
HCT / VHCT	1					
TC74AC573	+2 to +5.5V					

TC74HC74P SN74HC74ANS (TI)FLAT PACKAGE SN74HC74ANS-E20 (TI) SN74HC74ANS-E05

C-MOS DUAL D-TYPE FLIP-FLOPS WITH DIRECT SET/RESET






	TYPE	VDD
So 9	74HCT/74ACT	+4.5 to +5.5V
	74LVC	+2.7 to +3.6V
	74AC/74VHC	+2 to +5.5V
1.	OTHERS	+2 10 +6V


SN74HC574ANS (TI)FLAT PACKAGE SN74HC574ANS-E05

C-MOS 3-STATE D-TYPE EDGE-TRIGGERED FLIP-FLOP




SN74LS03NS-E05 (TI)

TTL 2-INPUT POSITIVE-NAND GATE WITH OPEN-COLLECTOR -TOP VIEW-



SN75121NS (TI)


DUAL LINE DRIVER



74ACT/74FCT/74HCT


SN75124NS (TI)

TRIPLE LINE RECEIVER




SRM2016M10 (SEIKO EPSON)FLAT PACKAGE SRM2016M10-TF

C-MOS 16K (2048 X B)-BIT STATIC RAM




FUNCTIO	N TABLE			
CON	CONTROL INPUTS		11000	
CÉ	OE	WE	MODE	D1 - D8
1	×	×	STANOBY	HI-Z
0	1	1	DISABLE OUTPUT	HI-Z
_ 0	. 0	1	FEAD	OUTPUT
0	¥	0	WRITE	0.00 C

0 ; LOW LEVEL
1 ; HIGH LEVEL
X ; DON'T CARE
HI-Z ; HIGH IMPEDANCE




ST93CS56M1013TR (SGS)FLAT PACKAGE


C-MOS 2K (128x16)- BIT SERIAL ACCESS EEPROM



TA7291F (TOSHIBA)FLAT PACKAGE TA7291F-EL


DC MOTOR FULLBRIDGE DRIVER - TOP VIEW -






TA7812S (TOSHIBA) +12V (1A) TA7815S (TOSHIBA)+15V(1 A)

POSITIVE VOLTAGE REGULATOR



TA79005S (TOSHIBA)---5V

NEGATIVE VOLTAGE REGULATOR (500mA)



TA79015S (TOSHIBA)---15V


NEGATIVE VOLTAGE REGULATOR(1A) - SIDE VIEW -






TC5081AP (TOSHIBA)

C-MOS PHASE COMPARATOR — SIDE VIEW —





PHASE COMPARATOR TIMING CHART



TC74HC123AF (TOSHIBA)FLAT PACKAGE TC74HC123AF(EL)

C-MOS DUAL RETRIGGERABLE MONOSTABLE MULTIVIBRATORS






TYPE	Voc
TC74HC123AF	+5V
TC74VHC	+2V to 4.5V
OTHER TYPES	+2V to 6V

TC74HC86AF (TOSHIBA) FLAT PACKAGE SN74HC86ANS-E05


C-MOS QUAD EXCLUSIVE OR GATES



TYPE	VDD				
74AC/74VHC	+2V to +5.5V				
74ACT/74HCT	+4.5 to +5.5V				
OTHER TYPES	+2V to +6V				

TC7S04FU(TE85R) (TOSHIBA)FLAT PACKAGE


C-MOS INVERTER



TC7S08FU(TE85R) (TOSHIBA)FLAT PACKAGE


C-MOS 2-INPUT AND GATE

+2 to +5.5V




TC7W00FU (TOSHIBA)CHIP PACKAGE TC7W00FU(TE12R)

C-MOS DUAL 2-INPUT NAND GATE .TOP VIEW.




TC7W04FU(TE12R) (TOSHIBA)FLAT PACKAGE

C-MOS HEX INVERTERS




TC7W08FU (TOSHIBA)CHIP PACKAGE TC7W08FU(TE12R)

C-MOS 2-INPUT AND GATE



TC7W125FU-TE12R (TOSHIBA)


C-MOS DUAL BUS BUFFER - TOP VIEW-



INP	UTS	OUTPUT
G	A	Υ
H	×	Z
L	L.	Ĺ
1	H	Н


TC7WU04FU(TE12R) (TOSHIBA)CHIP PACKAGE

C-MOS HEX INVERTERS -TOP VIEW-




TD62381F (TOSHIBA)FLAT PACKAGE

OCTAL LOW SATURATION DRIVER




TL064CNS (TI)FLAT PACKAGE TL064CNS-E05

OPERATIONAL AMPLIFIER
(J FET INPUT)
--TOP VIEW-




TL431CPS (TI)FLAT PACKAGE TL431CPS-E20


ADJUSTABLE PRECISION SHUNT REGULATOR -TOP VIEW-



TL7705CPS-B (TI)FLAT PACKAGE TL7705CPS-B-E05

POWER VOLTAGE SUPERVISOR —TOP VIEW—





TLC272CPS (TI)FLAT PACKAGE TLC272CPS-E05

OPERATIONAL AMPLIFIER



TLC274CNS (TI)FLAT PACKAGE TLC274CNS-E05

C-MOS OPERATIONAL AMPLIFIER —TOP VIEW—

3 4 5

UPC358GR-E1 (NEC)


DUAL OPERATIONAL AMPLIFIER (HIGH GAIN)



NOTE				
	Voc	VEE		
SINGLE	+3 to +32V	GND		
SPUT SUPPLIES	+1.5 to +16V	-1.5 to -16V		


UPC78L05T (NEC)+5V UPC78L05T-E1


POSITIVE VOLTAGE REGULATOR (100mA)



UPD4218160LE-60 (NEC)CHIP CARRIER


C-MOS 16M(1,048,576x16)-BIT DRAM -TOP VIEW-






UPD70216L-10 (NEC)


C-MOS 16 BIT MICROPROCESSOR - TOP VIEW -



NI SI		BOB		B		e	
PIN NO.	FUNCTION	PIN MO	FUNCTION	MO.	FUNCTION	no.	FUNCTION
1	V00(+3V)	18	GND	35	DMAAK3/T x D	52	GND
2	RES OUT	19	AD7	36	NEW TOUR VALUE	53	X2
3	HLDAK	20	AD6	37	INTPI	54	X I
4	HLDRO	121	AD5	36	INTP 2	55	CLK out
5	REFRO	22	AD4	39	INTPS	36	BUFEN
6	A19/PS3	23	AD3	40	INTP4	57	BUFR/W
7	A10/PS2	24	AD2	41	INTPS	36	BUSLOCK
	A17/PS1	25	ADI	42	INTPG	59	IOWR
9	A16/PSQ	26	ADO	43	INTP?	60	MWR
10	ADIS	27	END/TC	44	TCLK	61	IORD
11	ADIG	28	DMARGO	45	TouT2	62	MRD
12	AD13	23	DMAAKO	46	TCTL2	63	BSO
13	ADIZ	30	DMA RO 1	47	POLL	64	851
ia.	8011	181	CHART	40	001	00	200




A16/PS0-A19/PS3	(0)		ADDRESS/PROCESSOR STATUS
AD0-AD15	(1/0)	:	ADDRESS BUS/DATA BUS
ASTB	(0)	i	ADDRESS STROBE
BSO-BS2	(0)	-	BUS STATUS
BUFEN	(0)	3	BUFFER ENABLE
BUP T/W	(0)	-	BUFFER READ/WRITE
HUSLOCK	(0)		BUS LOCK
CLKOUT			CLOCK OUTPUT
DNAAKO-Z	(0)	-	DMA ACKNOWLEDGE 0 - 2
DMARS/TED DMARQO-2	(0)	2	DHA ACKNOWLEDGE & FTRANSHITE DAM
DMARQO-2	(1)	•	DMA REQUEST 0-2
DMARQ3/RxD	(1)		DMA REQUEST/DECETVE DATA
DHARO3/RXD END/TC HLDAK	(I/O)		END/TERMINAL COUNT
HLDAK	(0)	•	BUS HOLD ACKNOWLEDGE
HLDRO	171	•	BUS HOLD REQUEST
INTAK/SRDY/TOUT L	(0)		INTERRUPT ACKNOWLEDGE/SERIAL
	***		READY/TIMER OUT 1
INTPO-INTP7	(1)	2	INTERRUFT REQUEST FROM
		•	PERIPHERAL 0-7
IORD	(0)	2	I/O READ STROBE
EOWR			I/O WRITE STROBE
H RD			MEMORY READ STROBE
HWR	(0)	2	MEMORY WRITE STROBE
NMI	(7)		NOW MACKABLE CUTEROUSE
POLL OSO, OS 1 READY BEFRO	(1)	ř	POLL QUEUE STATUS READY
QS0, QS l	(0)	ï	OURUE STATUS
READY	(1)	÷	READY
RES OUT	(0)	2	SYSTEM RESET
ICILE	(1)	i	TIMER CONTROL 2
10012	(0)	2	TIMER OUT 2
380	(0)	2	UPPER BYTE ENABLE
X1,2	(1)	2	CRYSTAL 1,2
		*	




UPD78C11AGF-E62-3BE (NEC)


C-MOS 8-BIT MICROCOMPUTER - TOP VIEW -



PIN No.	ю	SIGNAL,	PIN No.	NO	SIGNAL	PtN No.	NO	SIGNAL.	PIN No.	ю	SIGNAL
1	VO	PA6	17	Ø	PCS/CO0	33	1	AN5	49	NO	PD0/AD0
2	NO	PA7	18	NO	PC7/CO1	34	1	ANG	50	NO	PF1/AD1
3	VO	PBO	19	i i	NAIL	35	ı	AN7	51	NO	PD2/AD2
4	VO	PB1	20		INT1	36		VAREF	52	NO	PD3/AD3
5	VO	PB2	21	Ю	MODE1	37	-	AVDO	53	NO.	PD4/AD4
6	NO	PB3	22	1	RESET	38	0	RO	54	NO	POS/ADS
7	VO	PB4	23	8	MODEO	39	0	WR	55	Ю	PO6/AD6
8	VO	PB5	24		X2	40	0	ALE	56	NO	PD7/AD7
9	VO	PB6	25	+	X1	41	WO	PF0/AB8	57	1	STOP
10	VO	P87	26	-	GND	42	10	PF1/A89	58	-	VDO
11	W	PC0/TxD	27	-	A-GNO	43	VO	PF2/AB10	59	NO	PAO
12	VO	PC1/RbiD	28		ANO	44	8	PF3/AB11	60	ю	PA1
13	Ю	PC2/SCK	29	1	AN1	45	90	PF4/AB12	61	NO	PA2
14	NO	PC3/INT2/T	30		ANS	46	vo	PF5/AB13	62	W	PA3
15	100	PC4/TO	31	1	ANS	47	10	PF6/AB14	63	W	PA4
16	100	PC5/CI	32	1	AN4	48	VO	PF7/AB15	64	Ю	PA5




59	INPUT	
60	ANO-7	: ANALOG DATA
61	CI	COUNTER
62	INT 1	: MASKABLE INTERRUPT REQUEST 1
63	INT 2	: MASKABLE INTERRUPT REQUEST 2
84	NMI	: NON-MASKABLE INTERRUPT REQUEST
1	RESET	: SYSTEM RESET
2	RAD	: RECEIVE DATA
	STOP	: SYSTEM STOP
3	TI	: TIMER
4	VARIEF	: REFERENCE VOLTAGE
5	X1, 2	: EXTERNAL CRYSTAL, X1; SYSTEM CLOCK INPUT
6	20.10	CANCEL OF ISING, AT, STSTEM CLOCK MPD
7	CUTPUT	
8	AB8-15	: ADDRESS BUS
9	ALE	: ADDRESS LATCH ENABLE
10	C00, 1	: COUNTER 0. 1
_	RO	: READ STROBE
49	TO	: TIMER
50	TxD	TRANSMIT DATA
51	WA	: WRITE STROBE
52 53 54		
53	IMPUT/OUT	PUT
54	AD0-7	; ADDRESS DATA BUS
55	MODE 0, 1	: MEMORY MODE
56	PA0-7	: PORT A
	PB0-7	: PORT 8
41	PC0-7	: PORT C
42	PD0-7	: PORT 0
43	PF0-7	: PORT F
44	SCK	: SERIAL CLOCK
45		
46		
414 45 45 46 47 48 47 48 47 48 47 48 48 48 48 48 48 48 48 48 48 48 48 48		
48		
40		
39		



CXD8970R (SONY)

C-MOS GATE ARRAY



No. Model	_	$\overline{}$		1	_			_						_	(V00 = +5V)
	PIN	VO.	SIGNAL	PIN	l vo	SIGNAL	PIN	WO.	SIGNAL	MM	NO.	SHOWAL	PIN	I IO	SIGNAL
1.												-	NO.		210100
1		_		62	0		123	0	APO0	184		A16	245	0	P07
3 O AR13 64 I SYSKI 125 O APCZ 186 I A16 947 — GNO 1 O AR15 86 — GNO 127 O APCZ 187 I A16 947 — GNO 2 O AR15 86 — GNO 127 O APCZ 188 I A17 X17 848 — GNO 3 O AR15 86 — GNO 127 O APCZ 188 I A17 848 — GNO 4 O AR17 86 I FESCK 129 O APCZ 188 I ASTT 840 O P12 7 O AR17 86 I FESCK 129 O APCZ 188 I ASTT 840 O P12 7 O AR17 86 I FESCK 129 O APCZ 188 — V00 551 O P13 9 O AR19 70 O PLOTHING 151 O APCZ 188 — GNO 251 O P13 10 — GNO 71 I FESCK 139 O APCZ 188 — GNO 255 O P13 11 I/O 080 72 I FESCK 139 O APCZ 189 — GNO 255 O P13 11 I/O 080 72 I FESCK 139 — GNO 180 I I ONR 255 O P14 11 I/O 080 77 I FESCK 139 — GNO 180 I I ONR 255 O P14 11 I/O 080 77 I FESCK 139 — GNO 180 I I ONR 255 O P15 11 I/O 080 77 I GUN 250 O APCZ 189 I I ONR 255 O P16 11 I/O 080 77 I GUN 250 O APCZ 189 I I ONR 255 O P17 11 I/O 080 77 — GNO 130 O APCZ 189 I I ONR 255 O P17 11 I/O 080 77 — GNO 130 O APCZ 189 I I ONR 255 O P17 11 I/O 080 77 — GNO 130 O APCZ 189 I I ONR 255 O P17 11 I/O 080 77 — GNO 130 O APCZ 189 I I ONR 255 I P21 11 I/O 080 77 — GNO 130 O APCZ 189 I I SUFERN 258 I P21 11 I/O 080 77 — V00 130 O APCZ 189 I J SUFERN 258 I P21 11 I/O 080 77 — V00 130 O APCZ 189 I J SUFERN 258 I P21 11 I/O 080 77 — V00 130 O APCZ 189 I J SUFERN 258 I P21 11 I/O 080 77 — V00 130 O APCZ 189 I J SUFERN 258 I P21 12 I/O 080 77 I I RLO 140 I J SPAN 250 O APCZ 189 I J SUFERN 258 I P21 13 I/O 080 77 I I RLO 140 I J SPAN 250 O APCZ 189 I J SUFERN 258 I P22 14 I/O 080 77 I I RLO 140 I J SPAN 250 O APCZ 189 I J SUFERN 258 I P25 15 I/O 080 78 I I RLO 140 I J SPAN 250 O I CUUNTY 264 O P22 16 I/O 080 78 I I RLO 140 I J SPAN 250 O I CUUNTY 264 O P22 17 I/O 080 62 I RLO 140 I J SPAN 250 O I CUUNTY 264 O P22 18 I/O 080 62 I RLO 140 I J SPAN 250 O I CUUNTY 264 O P22 18 I/O 080 62 I RLO 140 I J SPAN 250 O I ROO 289 I V00 28 I/O 080 68 I I RLO 140 I SPAN 250 O I ROO 289 O I RUNCE 29 I/O 080 68 I I RLO 140 I J SPAN 250 O I ROO 289 O I RUNCE 29 I/O 080 68 I I RLO 140 I RLO 140 I SPAN 250 O I ROO 289 O I RABACS 20 I O 080 68 I I RLO 140 I RLO 140 I PACC 277 O RABACS 21 I O 080 68 I I RLO	. 2		GNO	63	0	SVSO	124	0	APC1	186		A17	246	0	P10
1	3	0	AB13	64	T	SVSI	125	0	APC2	186				-	GND
1	4	0	A814		1									-	
1					-									<u> </u>	
7. 0. A817. 468 1 F.EXCK 129 0 APOS 190 — V00 551 0 P13 0 — 600 A819 70 0 PLSO 150 0 APOT 191 — GMO 253 0 P15 10 — 600 71 P1 P10					-			_							
9. O. A616 69 O. P.LT30XT 150 O. APCT 151 — GMO 252 O. P14 9. O. A819 70 O. P.LT30XT 151 O. APCD 152 — GMO 253 O. P14 10. — GMO 77 I. I. PLEER 133 — GMO 150 I. U6E 254 O. P16 11. I/O 080 72 I. PLEER 133 — GMO 150 I. U6E 254 O. P16 11. I/O 080 72 I. PLEER 133 — GMO 150 I. U6E 255 O. P17 11. I/O 080 72 I. PLEER 133 — GMO 150 I. U6E 255 O. P17 11. I/O 080 73 — GMO 130 — GMO 150 I. IOWR 255 — GMO 11. I/O 080 73 — GMO 130 O. APOL 150 I. IOWR 255 — GMO 11. I/O 080 73 — GMO 130 O. APOL 150 I. IOWR 256 — GMO 15. I/O 080 73 — GMO 137 O. APOL 150 I. IOWR 250 I. P22 15. I/O 080 73 — WO. 139 O. APOL 150 I. J. RIES 30 O. P22 17. I/O 080 73 — WO. 139 O. APOL 150 I. J. RIES 30 O. P22 18. I/O 080 73 — WO. 139 O. APOL 150 I. J. RIES 30 O. P22 19. — WO. 80 I. R.GO 141 I. BRAD 250 — GMO 251 I. INTA 82 I. P24 19. — WO. 80 I. R.GO 141 I. BRAD 250 — GMO 251 I. INTA 82 I. P24 19. — WO. 80 I. R.GO 141 I. BRAD 250 — GMO 251 I. P26 11. I/O 080 62 I. R.GO 141 I. BRAD 250 — GMO 250 — GMO 251 I. P26 12. I/O 080 62 I. R.GO 141 I. BRAD 250 — GMO 250 — GMO 251 I. P26 13. I/O 081 62 I. R.GO 144 I. BRAD 250 — GMO 250 — WO. P27 14. I/O 081 62 I. R.GO 144 I. BRAD 250 — R.GO 266 — WO. P27 15. I/O 081 62 I. R.GO 144 I. BRAD 250 — R.GO 266 — WO. P27 16. I/O 081 62 I. R.GO 144 I. BRAD 250 — R.GO 266 — WO. P27 17. I/O 081 62 I. R.GO 144 I. BRAD 250 — WO. P27 18. I/O 081 62 I. R.GO 145 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 145 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 145 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.GO 146 I. BRAD 250 — WO. P27 19. I/O 081 65 I. R.											=				
9. 0. A819 70 0. FLIDWIT 191 0. APOD 192 — GMD 153 0 P15 10 — GMO 71 1 FLIDWS 132 0. APOD 192 — GMD 155 0 P15 11 I/O 580 72 1 FLIDWS 132 0. APOD 193 1 I U66 256 0 P17 11 I/O 580 72 1 FLIDWS 132 0. APOD 196 1 I U68 256 0 P17 11 I/O 580 72 1 FLIDWS 132 0. APOD 196 1 I U68 256 0 P17 11 I/O 580 73 — GMO 134 — GMO 156 1 I U68 257 1 P20 11 I/O 580 73 — GMO 135 0 APOD 156 1 I U68 257 1 P20 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 257 1 P20 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 258 — GMD 196 1 I U68 258 1 P21 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 258 1 P21 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 258 1 P21 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 258 1 P21 11 I/O 580 77 — WD 138 0 APOD 196 1 I U68 258 1 P21 11 I/O 580 77 — WD 138 0 APOD 200 — GMO 281 1 P25 12 I/O 580 78 — WD 146 1 I U68 25											=				
10											=				
11 10 0 0 0 72 1 Files 130 680 196 1 0 0 0 0 0 0 0 0 0											_				
12 10		-						0					254	0	P16
13	11		D80	72	. 1	FLERR	183	_	GMC)	194	- 8	IORO	256	0	P17
13	12	100	D81	73	0	\$1.00	134	_	GNO	198	1	IOWR	256	-	CHID
14 IO DRS 73	13	NO	DB2	74	0	SL01		0		196	4				
15 10	16	NO	DE3	75							1				
19 10 10 10 10 10 10 10					_			_			_				
17 17 17 17 17 18 17 17					⊢					_	_				
19														_	
19														1	P24
10		180						0	APO7	201	1	INTA	262	1	P25
21 IVO D88 68 1 RLC2 140 1 BPA2 200 O PCWT 865 — V10 22 IVO D88 68 1 RLC3 144 1 BPA4 200 I AVA 207 — GRO 23 IVO D810 64 I RLC4 145 I BPA4 200 I AVA 207 — GRO 24 IVO D811 65 I RLC5 140 I BPA4 200 I AVA 207 — GRO 25 IVO D812 80 I RLC5 140 I BPA4 200 I AVA 207 — GRO 26 IVO D812 80 I RLC5 140 I BPA4 200 I AVA 207 — GRO 27 IVO D812 80 I RLC5 140 I BPA4 200 I AVA 207 — GRO 28 IVO D813 87 I RLC7 146 I BPA4 200 I AVA 207 — GRO 29 IVO D813 87 I RLC7 146 I BPA4 200 I AVA 207 — GRO 29 IVO D814 80 O SL07 146 I BPA4 200 I AVA 207 O RAMACS 20 IVO D815 80 O SL10 150 — GRO 20 IVO D815 80 O SL10 150 — GRO 21 I AVA 207 O REMEMB 20 — GRO SO O SL11 150 I BACK 211 O RC2 772 O REMEMB 20 — GRO SO O SL12 150 — V00 212 I AVA 207 O REMEMB 20 O IORDAK 91 I RLS0 152 — V00 213 O RC00 274 O MAXCXX 22 I ASSINT 90 I RLS1 151 — V00 212 I AVA 207 O REMEMB 20 I SWPA 91 I RLS2 154 — GRO 210 — GRO 278 O SYSLED 21 I SWPA 91 I RLS2 155 I — V00 213 O STSPR 770 O SYSLED 21 I SWPA 91 I RLS2 155 I — V00 213 O STSPR 770 O SYSLED 21 I SWPA 91 I RLS2 155 I — GRO 210 I AVA 207 O SYSLED 23 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 277 O SYSLED 24 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 277 O SYSLED 25 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 277 O ROME 26 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 277 O ROME 27 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 277 O ROME 28 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 278 O ROME 29 I SWPA 91 I RLS2 155 I — GRO 210 I O PD0 278 O ROME 20 I SWSTO 92 I RLS4 150 I DRS 219 IVO PD0 278 O ROME 20 I SWSTO 92 I RLS4 150 I DRS 219 IVO PD0 278 O ROME 20 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 20 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 20 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 21 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 22 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 23 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 24 I O SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 279 O ROME 25 I SWSTO 91 I RLS4 150 I DRS 219 IVO PD0 270 I ROME 26 I O SWSTO 91 I RLS4 177 IVO ROME 220 IVO PD0 270 O ROME		-				PLOO	141		SPAC	202	0	ICUDINT	263		P26
21 I/O D8B 62 I RLCC 143 I BPA2 200 D PCWR 865 — VVO	20	-	GNO	81		FIL01	142	1	BPA1	200	0	ICU1INT	264	0	P27
22	21	1/0	088	62		PLOS	143	1	RP42						
27 10														_	
24 10 0911														_	
25 10 0912															
28 MO D813 87 1 RL07 148 1 BPA7 259 VDD 270 0 RAMCCS 29 MO D914 88 0 SL10 189 WDD 270 0 RAMCCS 29 MO D915 88 0 SL11 150 1 BAGLK 211 0 RQ2 272 0 RAMCGS 29 MO D915 88 0 SL11 150 1 BAGLK 211 0 RQ2 272 0 RAMCGS 29 MO D915 88 0 0 SL11 150 1 BAGLK 211 0 RQ2 273 0 RAMCGS 29 MO D915 88 0 0 SL11 150 VBO 212 1 AAV2 273 0 RAMCGS 30 0 EVRDAK 91 1 RL12 151 VBO 213 0 RQ3 274 0 MISCOCK 31 0 EVRDAK 92 1 RL13 153 GMO 214 1 AM9 275 0 MISCOCK 32 1 SSYNT 93 1 RL13 153 GMO 215 0 SYSERR 275 0 MISCOCK 33 1 SSYNT 94 1 RL13 155 GMO 215 0 SYSERR 277 0 SYSERY 33 1 SSYNT 98 GMO 157 GMO 216 GMO 277 0 SYSERY 35 1 SSYNT 98 GMO 157 GMO 216 GMO 277 0 SYSERY 35 1 SSYNT 98 GMO 157 GMO 216 GMO 277 0 SYSERY 35 1 SSYNT 98 GMO 157 GMO 216 GMO 277 0 SYSERY 37 VOD 98 1 RL15 159 0 T11 CMO PDO 281 0 TOCK 38 VD 99 1 RL15 159 0 T11 CMO PDO 281 0 TOCK 40 GMD 100 1 RL16 169 1 CTT 221 VD PDO 281 0 TOCK 41 0 EUCKA 102 1 DMAL B 163 1 RXD 224 VD PDO 286 0 11000 42 VO SBDTA 108 1 DMAL B 163 1 RXD 224 VD PDO 286 0 11000 44 0 DTC1A 104 1 APA0 164 GMD 225 0 TXD1 287 0 11000 45 0 DTC1A 106 1 APA0 164 GMD 225 0 TXD1 287 0 11000 46 0 DTC1A 106 1 APA2 106 VD AD0 227 GMO 288 0 AB1 47 VO SBDTD 108 1 APA3 108 VD AD0 222 VBO 299 0 AB1															
27 10													269		
29 MO										209	_		270	0	RAMECS
29 - GNO 80 O SL12 151 - V50 122 1 AV2 273 O PREMEM NO DIO O DIO O DIO O PREMEM NO DIO O D				86	0	SL10	149		GND	210	_	GND	271	0	RAMHCS
0	26	10		80	0	SL11	150	1	BACLK	211	0	RC12	272	0	RMEMEN
30 O IORIDAK 91 I. R.110 152 V00 213 O RCC0 274 O MAXDCXX 22 II. RSYNT 95 II. R.111 153 GRIO 214 I. AX3 275 O MEXOCX 23 II. RSYNT 95 II. R.112 154 GRIO 215 O SYSERR 275 O MEXOCX 24 II. RSYNT 95 II. R.113 155 I PCK 216 GRIO 277 O SYSERD 25 II. SWPA 94 II. R.13 155 I PCK 216 GRIO 277 O SYSERD 26 II. SWPA 95 GRIO 155 I CKNO 277 VO PCO 277 O SYSERD 27 II. SWPA 95 II. R.114 155 I DS 1 PCK 216 GRIO 277 O SYSERD 28 II. SWPA 95 II. R.115 155 I DS 27 I VO PCO 277 O ROCEN 27 II. SWPA 95 II. R.114 155 I DS 27 I VO PCO 277 O ROCEN 27 II. SWPA 95 II. R.114 155 I DS 27 I VO PCO 278 O PCO 278 O ROCEN 28 II. SWSYO 95 II. R.114 155 I DS 27 I VO PCO 278 O PCO CEN 29 II. R.114 155 I DS 20 II. PCK 216 VO PCO 278 O PCO CEN 29 II. R.115 150 I D TH 222 IVO PCO 283 O I IOCK 40 II. SWPA 96 II. R.116 I D II. TS 221 IVO PCO 283 O I IOCK 41 O EKCKA 102 I DALA B 153 I R.10 223 IVO PCO 283 O II. DCK 41 O EKCKA 102 I DALA B 153 I R.10 223 IVO PCO 285 I D TO CEN 44 O DECKA 102 I DALA B 153 I R.10 223 IVO PCO 285 I O TOCK 45 O DECKA 104 I APA3 167 I R. AXD 224 IVO PCO 285 I O TOCK 46 O DECKA 105 I APA3 167 I CK AZD 223 I VO PCO 285 I O IIICK 46 O DECKA 105 I APA3 167 I CK AZD 223 I VO PCO 285 I O IIICK 47 VO SSOITO 109 I APA4 166 IVO ADO 286 I R.100 289 O ABS 48 O EKCKO 109 I APA4 166 IVO ADO 286 I R. ROCEN 289 O ABS 49 I RACKO 109 I APA4 I R. B IVO ADO 281 I R. ROCEN 289 O ABS 50 I LECK III. APA5 I R. ROCEN 283 I R. ROCEN 289 O ABS 51 I SYAO 113 I VO ADO 275 IVO ADO 285 I R. ROCEN 289 O ABS 51 I SYAO 113 I VO ADO 275 IVO ADO 285 I R. ROCEN 289 O ABS 51 I SYAO 113 I APA5 I R. ROCEN 285 I ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 51 I SYAO 115 I APA5 I R. ROCEN 285 I R. ROCEN 289 O ABS 52 I SYAO 115 I APA5 I R. RO	29		GND	90	0	SL12	151	_	Voo	212	1	AK2	273	0	PMEMEN
93	30	0	IORDAK	91	_	RL10	152	-	Voc	213	0	903		0	
22 1	31	0	IOWRAK	92	1	RL11	153	_							
1	10	-	RSMINT	63	-			_			-				
94 I. EKSYA 89 — GNO 198 I. CLK10 177 FO POD 278 O SPEN 25 I. SWPO 98 — GNO 157 — GNO 218 FO POD 278 O SPEN 25 I. EKSYO 97 I. RL14 158 I. DØR 279 FO POD 278 O POD 27 — VIO 98 I. RL15 159 O TH POD 279 FO POD 278 O POD 28 — VIO 98 I. RL15 159 O TH POD 279 FO POD 281 O POD 39 — GNO 100 I. RL17 161 O TH POD 272 FO POD 283 O THO 40 — GNO 100 I. RL17 161 O RT3 221 FO POD 283 O THO 41 O EKCKA 102 I. DØAL 8 ISS II. RND 224 FO POD 285 — GNO 42 FO EKCKA 102 I. DØAL 8 ISS II. RND 224 FO POD 285 — GNO 43 O DTC1A 104 I. APAI 165 IO ADO 226 I. DVD 187 O HOPK 44 O DTC2A 105 I. APAI 165 IO ADO 228 I. DVD 187 O HOPK 45 O DTC1A 106 II. APAI 165 IO ADO 228 I. DVD 187 O HOPK 46 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 187 O HOPK 47 VO SEOTO 108 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 48 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 187 O HOPK 49 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 187 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 187 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 187 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 40 O DTC2A 105 II. APAI 165 IO ADO 228 II. DVD 287 O HOPK 40 O DTC2A 105 II. APAI 170 IVO ADO 228 II. DVD 280 O ABO 40 O EKCKO 109 II. APAI 170 IVO ADO 230 O RIB 100 ADO 280 O ABO 40 O EKCKO 109 II. APAI 171 IVO ADO 230 O RIB 100 ADO 280 O ABO 40 II. LECK 111 II. APBO 172 IVO ADO 232 O RIB 286 O ABO 50 II. LECK 111 II. APBO 172 IVO ADO 232 O POD 289 O ABO 51 I. SVAO 113 II. APBO 177 IVO ADO 232 O POD 289 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO 177 IVO ADO 232 O POD 280 O ABO 50 O EKCO 117 II. APBO											-				
Section Sect		-									=		_		
					$\overline{}$										
97 - VID 98 1 RIGH 159 0 TH 220 NO PD3 287 0 BIGGS 1 RIGH 159 1 CT 221 NO PD3 287 0 BIGGS 1 RIGH 150 1 CT 221 NO PD3 287 0 BIGGS 1 RIGH 150 1 CT 221 NO PD3 287 0 TCEN 29					_								279	0	
38				-								PD2	260	0	MOEN
99 — GMD 100 I RLTT 191 O RTS 222 UO POS 850 O 1100X 40 — GMD 101 I DALA 162 O TXD 223 UO POS 850 O 1100X 41 O EKCKA 102 I DALA 8 183 I TXD 224 UO POS 850 O 1100X 42 UO SEDTA 100 I APAO 164 — GMC 225 O TXDI 285 — GMC 43 O DTC1A 104 I APAO 164 — GMC 225 O TXDI 286 — GMC 44 O DTC2A 106 I APAO 164 — GMC 225 O TXDI 286 — GMC 45 O DTC1D 106 I APAO 167 UO ADI 277 — GMC 288 O 1110X 46 O DTC1D 106 I APAO 167 UO ADI 277 — GMC 288 O 1110X 47 UO SEDTO 109 I APAO 168 UO ADI 277 — GMC 280 O ABI 48 O DTC3D 109 I APAO 168 UO ADI 277 — GMC 280 O ABI 49 — GMD 110 I APAO 170 UO ADI 270 — VVO 290 O ABI 49 — GMD 110 I APAO 171 — VVO 232 O TXDI 282 O ABI 50 I LUCK 111 I APBO 172 I O ADI 270 — VVO 290 O ABI 50 I LUCK 111 I APBO 172 I O ADI 271 — GMC 288 O ABI 51 I TMCK 112 I APBI 173 IVO ADI 230 O TXDI 282 O ABI 52 I SYAO 113 — VVO 174 IVO ADI 237 — GMC 288 O ABI 53 I VSSYNO 114 — VVO 175 IVO ADI 237 — GMC 298 O ABI 54 O EMCD 117 I APBO 172 — GMC 233 O TXDI 282 O ABI 55 I SYAO 117 — VVO 175 IVO ADI 237 — GMC 298 O ABI 56 O EMCD 117 I APBO 175 IVO ADI 237 — GMC 298 O ABI 57 — VVO 118 I APBS 177 IVO ADI 237 — GMC 299 O ABI 58 O EMCD 117 I APBS 177 IVO ADI 227 — GMC 299 O ABI 57 — VVO 118 I APBS 177 IVO ADI 227 — GMC 299 O ABI 58 O EMCD 117 I APBS 177 IVO ADID 280 O PO 299 O ABI 58 O EMCD 117 I APBS 187 IVO ADID 280 O PO 299 O ABI 59 O EMCD 117 I APBS 187 IVO ADID 280 O PO 299 O ABI 50 O XMSSO 120 I APBS 181 — GMC 242 O PO 290 O O ABI 50 O XMSSO 120 I APBS 181 — GMD 242 O PO 290 O O ABI 50 O XMSSO 120 I APBS 181 — GMD 242 O PO 90 330 — VVO	37			96	_ 1	RL15	159	0	TH	220	10	PD3	261	0	DIOEN
39 — GAID 100 R.LT7 161 O RT3 222 I/O PD6 283 O 1100X 40 — GAID 101 DALA RS2 O TXO 223 I/O PD6 883 O 1100X 41 O EKCKA 102 I DALA RS2 O TXO 223 I/O PD6 883 O 1100X 41 O EKCKA 102 I DALA RS2 O TXO 223 I/O PD7 285 — GAID 42 I/O SSD17A 109 I APA1 165 I/O AD0 226 I TXD1 287 O TXD1 43 O DTG1A 106 I APA1 165 I/O AD0 226 I TXD1 287 O TIDOT 44 O DTG2A 106 I APA2 166 I/O AD0 226 I TXD1 287 O TIDOT 45 O DTG1A 106 I APA2 166 I/O AD0 226 I TXD1 287 O TIDOT 46 O DTG2A 107 I APA2 166 I/O AD2 222 — V00 289 O A89 47 I/O SSD1D 109 I APA4 168 I/O AD2 222 — V00 289 O A89 48 O EXCKO 109 I APA4 168 I/O AD5 221 O TXD1 222 O A83 49 — GAID 110 APA5 TYO I/O AD5 221 O TXD 222 O A83 50 I LRCK 111 AP80 I/T2 — GAID 233 O CTLS 234 O A85 51 I TARK 112 AP81 TY3 I/O AD6 224 I E 234 O A85 52 I SYAO 113 — V00 I/T3 I/O AD9 227 — GAID 298 O A89 53 I SYAO 115 — GAID 176 I/O AD7 225 I RPD 298 O A89 54 O ENDD 117 I AP82 TY8 I/O AD10 227 — GAID 298 O A89 55 I SYAO 115 — GAID 175 I/O AD10 227 — GAID 298 O A89 56 O ENDD 117 I AP82 TY8 I/O AD12 236 C P00 239 O A89 57 — V00 118 AP83 TY8 I/O AD12 236 C P00 230 O A81 58 O ENDD 117 I AP83 TY8 I/O AD12 236 C P00 230 O A81 59 O ZARES 120 I AP88 181 — GAID 242 O P04 303 — V00 50 O ZARES 120 I AP88 181 — GAID 242 O P04 303 — V00 50 O ZARES 120 I AP88 181 — GAID 242 O P04 303 — V00 50 O ZARES 120 I AP88 181 — GAID 242 O P04 303 — V00 50 D	36	-		99	. 1	RL16	160	1	CTS	221	NO	PD4	282	0	TCEN
40	39	_	GMD	100	1	RL17	161	0	RTS	Z22 ·	1/0	PD6		0	
49 O EKCKA 102 I DULL B 153 I RXD 224 I/O P77 855 — GRID 40 O DTC1A 104 I APA1 165 I/O ADD 226 I RXD 227 — GRID 41 O DTC1A 104 I APA1 165 I/O ADD 226 I RXD 227 — GRID 42 O DTC1A 104 I APA1 165 I/O ADD 226 I RXD 227 — GRID 43 O DTC1D 105 I APA2 176 I/O ADD 226 I RXD 227 — GRID 44 O DTC2D 107 I APA2 176 I/O ADD 226 I RXD 227 — GRID 229 O AB2 45 O DTC1D 106 I APA3 I RXD I/O ADD 226 I RXD 229 — VVV 280 I/O AB2 46 O DTC2D 107 I APA4 168 I/O ADD 222 — VVV 280 I/O AB2 47 I/O SBIDTO 109 I APA5 I RXD I/O ADD 220 — VVV 280 I/O AB2 48 O EKCKO 109 I APA5 I RXD I/O ADD 220 — VVV 282 I O AB3 49 — GRID 110 APA5 I RXD I/O ADD 220 I RXD 220 O AB3 50 I LRCK III I APA6 I RXD I/O ADD 220 I RXD 220 O AB5 51 I TRRCK 112 I APA6 I RXD I/O ADD 227 — GRID 238 O AB5 52 I SYAO 113 — VVO I/O ADD 227 — GRID 287 — GRID 53 I VYSON III APA5 I RXD I/O ADD 227 — GRID 288 O AB5 54 I VYSON III APA5 I RXD I/O ADD 227 — GRID 289 O AB5 55 I SYAO III APA6 I RXD I/O ADD 227 — GRID 289 O AB5 56 O ENDO 117 I APA6 I RXD I/O ADD 227 — GRID 298 O AB5 57 — VVO III APA8 I RXD I/O ADD 227 — GRID 299 O AB6 58 O ENDO 117 I APA8 I RXD I/O ADD 227 — GRID 299 O AB6 58 O ENDO 117 I APA8 I RXD I/O ADD 227 — GRID 299 O AB6 59 O ENDO 117 I APA8 I RXD I/O ADD 227 — GRID 299 O AB6 50 O ENDO 117 I APA8 I RXD I/O ADD 227 — GRID 299 O AB6 50 O ENDO 117 I APA8 I RXD I/O ADD 247 — GRID 290 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 290 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 290 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 290 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O ADD 247 — GRID 200 O AB6 50 O XXESO 120 I APA8 I RXD I/O	40	_	GND	101	1	DIALA	162	0	TXD	223	140		284		
Region R		0			_										
0					_			÷						$\overline{}$	
4								-							
G					_						1				
					_		_				-				
0 0 0 0 0 0 0 0 0 0											=				
48 O EXCKD 109 I APAS 170 IO ADS 231 C TX0 232 D ABS 49 — GND 110 I APAZ 177 — VOD 232 C RX1 250 O ABS 50 I LRCK 1111 APBO 172 — GND 233 C CTLS 254 O ABS 51 I LRCK 1112 APBO 172 — GND 233 C CTLS 254 O ABS 51 I TWRCK 112 APBO 173 IO ADS 234 I LE 255 O ABS 52 I SYAO 113 — VOD 174 IVO ADS 236 I WR 257 — GND 53 I SYOO 114 — VOD 175 IVO ADS 236 I WR 257 — GND 54 I VSSYNC 115 — GND 176 IVO ADS 236 I WR 257 — GND 55 O ENDA 116 — GND 177 IVO ADS 256 I WR 257 — GND 55 O ENDA 116 — GND 177 IVO ADS 256 I WR 257 — GND 55 O ENDA 116 — GND 177 IVO ADS 250 C PDD 259 O ABS 56 O ENDA 116 — GND 177 IVO ADS 250 C PDD 259 O ABS 57 — VOD 118 I APBS 179 IVO ADS 250 C PDD 250 O ABS 58 O ENDA 116 I APBS 179 IVO ADS 250 C PDD 250 O ABS 59 O ENDA 117 I APBS 179 IVO ADS 250 C PDD 300 C ABS 157 — GND 119 I APBS 180 IVO ADS 250 C PDS 302 C ABS 250 C PDD 305 C ABS 150 C PDD 305 C PDD										229	_	Voo	290	0	AB1
46 O EXCKD 199 I APAS 170 I/O ADS 231 O T70 1222 O ABS 489 O ABS 49 — GAID 110 I APAS 171 — VOO 232 O TR0 399 O ABS 59 I							189	NO	AD4	230	-	Voo	291	D	AB2
EP GND 110 I APAZ 171 — V00 232 O RN0 280 O A84 20 I LSCK 111 I APB0 172 — GND 223 O CTLS 224 O A85 31 I TMRCK 112 I APB1 172 IC ADS 224 I LE 235 O AB6 52 I SYAO 113 — V00 174 IC AD7 225 I RD 286 O AB6 51 SYNO 114 — V00 175 8° AD8 226 I RW 297 — AB7 — AB7 225 I RW 297 — AB7 —	46	0	EXCKD	100	T	APA6	170	NO	AD5	231	0				
S	49	_	GND		T			_							
1 TERRICK 112 1 APB1 173 PO AD6 234 1 LE 285 0 AB6 284 1 SYAO 113 VDO 174 PO AD7 235 1 RD 286 0 AB7 SS 1 SYAO 114 VDO 175 870 AD8 236 1 WR 237 CRAD SS 1 SYAO S		1	LRCK		1										
SYAO 113 - WD 174 FO A07 288 RO 286 O A87 287		_			_			NO.		-					
					_										
H V\$5YNC 115 GMD 176 8°C A09 277 GMD 298 0 A88					=						_			0	
55 O ENDA 116 — GND 177 9°C AD10 238 C P90 289 O AB9 59 0 ENDD 117 1 AP82 178 8°C AD11 230 O P90 300 O A810 57 — V00 118 I AP84 179 9°C AD12 240 O P02 301 O A811 58 — GND 119 I AP84 180 8°O AD13 241 O P03 302 O A8812 99 O XPES0 120 I AP85 181 — GND 242 O P04 303 — V0b 60 O XPES0 122 I AP86 182 V0 AD14 243 O P05 304 — V0b					_						1			=	
80 0 84000 117 1 AP80 178 8°O AD71 258 C P90 300 O A810 57 - V00 118 1 AP80 179 8°O AD71 258 C P90 300 O A810 57 - V00 118 1 AP80 170 400 AD72 240 C P90 300 O A811 59 - GND 119 1 AP84 180 8°O AD73 241 O P90 302 O A812 99 O 201650 120 1 AP80 191 - GND 242 O P90 303 - V00 A812 40 O P00 A812 40 O P00 A812 40 O P00 A812					-						-	GND	298	0	ABO
57 — Voo 118 I AP83 179 I/O AD12 240 C P02 301 O A811 95 — GND 119 I AP84 180 I/O AD13 241 O P03 302 O A812 99 O X7650 120 I AP85 181 — GND 242 O P04 303 — Voo 60 O X7651 121 I AP86 182 I/O AD14 243 O P05 304 — Voo	55	0			L=	GND	177	100	AD10	238	0	P00	299	0	AB9
57 — V00 118 I APB3 179 90 AD12 240 C P02 301 O AB11 59 — GRD 119 I APB4 180 100 AD13 241 O P03 302 O AB12 90 O XPES9 120 I APB5 181 — GND 242 O P04 302 — V00 60 O XPES1 121 I APB6 182 V0 AD14 243 O P05 304 — V00	56	0	ENDD	117	1	APB2	178	80	AD11	230	0	PO1	300	0	AB10
99 — GND 119 I APB4 180 IV AD13 241 C P03 302 D AB12 99 O XRES0 120 I APB5 181 — GND 242 O P04 303 — V00 60 O XRES1 127 I APB6 182 IV AD14 243 O P05 304 — V00	57	-	VDD	118	T	APB3	179	1/0	AD12						
59 O XRESO 120 I APBS 181 — GNO 242 O POI 303 — YDO 80 O XRES1 121 I APBS 182 I/O AD14 243 O POS 304 — YDO		_	GND		T										
60 C XRES1 121 I AP86 162 NO AD14 243 C P05 304 - V00		0												-	
														=	
91 1 3 2811 [122 APIS7 TE3 FO ADIS 244 O POS													304	-	A00
	61		SAMAI	172		APB7	183	NO	AD15	244	Lo_	POS		_	

	ADDRESS BUS
	; DATA BUS ; IORD AND ; AK
	IOWR AND : AK
RSVINT	CU2 - INTP7
	: SWITCHING PULSE-A INPUT : EXSY-A INPUT
SWPD	SWITCHING PULSE-D INPUT
	EXSY-D INPUT
	: EXCK-A BYPUT : SUBCODE DATA-A
	DTC1-A OUTPUT
	DTC2-A OUTPUT
	: DTC1-D OUTPUT : DTC2-D OUTPUT
SBOTO	SUBCODE DATA-0
	EXCK-D OUTPUT
	: FS CLOCK (48/44.16/12) INPUT : TIME CLOCK (LRCK/8) INPUT
SYAO	: SBSY-A INPUT
SYDO VSYNC	; SBSY-D INPUT ; VIDEO SYNC INPUT
BNDA	: END-A OUTPUT
ENDD	END-D OUTPUT
XRES0 XRES1	: RESET TO KY ; RESET TO SP, SV
	: REQUEST SIGNAL OUTPUT FOR SY
SVTXRDY	TRANSMIT READY OUTPUT FOR SV
	: SERIAL DATA OUTPUT FOR SV ; SERIAL DATA INPUT FOR SV
	SERIAL CLOCK INPUT FOR SV
PLCLK	: 4MHz CLOCK INPUT FOR FL
	; SERIAL CLOCK INPUT FOR KY ; SERIAL DATA OUTPUT FOR FL
	INT OUTPUT TO FL
	STATUS (BUSY) INPUT FROM PL
FLERR SL00 - SL02, SL10 - SL12	STATUS (ERROR) INPUT FROM FL
RL00 - RL17	RETURN LINE INPUTS
	Z-PHASE SIGNAL-A INPUT
DIAL B APA 0	; Z-PHASE SIGNAL-B INPUT ; STOP COMMAND INPUT
	FF COMMAND INPUT
	: PLAY COMMAND INPUT
	; REWIND COMMAND INPUT ; STAND BY COMMAND INPUT
	MONITOR COMMAND INPUT
	REC COMMAND INPUT
	; NEXT COMMAND INPUT ; PREV COMMAND INPUT
'APB 1	STID COMMAND INPUT
	; SKID COMMAND INPUT ; END ID COMMAND INPUT
	: CHASE COMMAND INPUT
	RSV0 COMMAND INPUT
	; RSV1 COMMAND INPUT ; EXT 96 SELECT INPUT
	STOP START OUTPUT
APC 1	FF START OUTPUT
	; PLAY START OUTPUT ; REW START OUTPUT
	STAND BY START OUTPUT
	MONITOR START OUTPUT
	; REC START OUTPUT ; LOCATE START OUTPUT
	ST ID START OUTPUT
	SKID START OUTPUT
	: END ID START OUTPUT : CHASE START OUTPUT
APD 4	SV START OUTPUT
	RSV START OUTPUT
APD 7	STOP START OUTPUT FOR 8P
	SPEED-B INPUT
	SPEED-A INPUT
	CUE RVS INPUT STOP COMMAND INPUT FOR 8P
BPA7	PLAY COMMAND INPUT FOR BP
	614.4KHz CLOCK INPUT
	; 16MHz CLOCK INPUT ; 10MHz CLOCK INPUT (CPU CLOCK)
DSR	DATA SET READY INPUT FOR RS-232C
DTR RTS	DAAT TERMINAL READY OUTPUT FOR RS-232C REQUEST TO SEND OUTPUT FOR RS-232C
TOD	: TRANSMIT DATA DUTPUT FOR RS-232C
FOXD	RECEIVE DATA INPUT FOR RS-232C
	ADDRESS BUS MIDNES
	ADDRESS BUS INPUT ADDRESS STROB OUTPUT
UBE :	UPPER BYTE ENABLE OUTPUT
	: IORD (I/O READ) OUTPUT : IOWR (I/O WRITE) OUTPUT
MRD	MRD (MEMORY READ) OUTPUT
BUFEN	BUFFER ENABLE OUTPUT


BUFFIW
XRES
INTA
ICUOINT
ICUOINT
ICUIINT
PCWR
RQO, RQ1, RQ2, RQ3
AK0, AK1, AK2, AK3
SYSERR
POO-PO7
TXD1
TXD1
RXD1

: BUFFER READWRITE OUTPUT
: SYSTEM RESET INPUT
: SYSTEM RESET INPUT
: INTERRUPT CONTROLLER UNIT 0 IMP OUTPUT
: INTERRUPT CONTROLLER UNIT 1 IMP OUTPUT
: INTERRUPT CONTROLLER UNIT 1 IMP OUTPUT
: PCWR OUTPUT
: DMA ACKNOWLEDGE IMPUT
: SYSTEM ERROR OUTPUT
: DMA ACKNOWLEDGE IMPUT
: SYSTEM ERROR OUTPUT
: SYSTEM ERROR OUTPUT
: AD BUS INPUTS/OUTPUT FOR PS-422
: RECEIVE DATA IMPUT FOR RS-422
: RECEIVE DATA IMPUT FOR PS-100
: NON MASKABLE INTERRUPT OUTPUT FOR 9PIN CPU
: NON MASKABLE INTERRUPT OUTPUT FOR 9PIN CPU
: ROINPUT FOR 9PIN CPU
: PORT DO - PORT DO OUTPUT
: EEPROM CE OUTPUT
: EEPROM CE OUTPUT
: EEPROM WR OUTPUT
: EEPROM WR OUTPUT
: EEPROM CE OUTPUT
: RESET INH OUTPUT
: RESET INH OUTPUT
: RESET INH OUTPUT
: PRINT IS INPUT
: PRINT IS INPUT
: PRINT STE INPUT
: SYS SWITCH INPUT FOR RAM LOWER BYTE
: CHIP SELECT OUTPUT FOR RAM LOWER BYTE
: CHIP SELECT OUTPUT FOR PERIOCK
: CHIP SELECT OUTPUT FOR PERIOCK
: CHIP SELECT OUTPUT FOR PERIOCK
: CHIP SELECT OUTPUT FOR MEM BLOCK (RECORDER NO AREA)
: CHIP SELECT OUTPUT FOR MEM BLOCK (PLAYER MEM AREA)
: CHIP SELECT OUTPUT FOR MEM BLOCK (PLAYER MEM AREA)
: CHIP SELECT OUTPUT FOR MEM BLOCK
: CHIP SELECT OUTPUT FOR MEMER BLOCK
: CHIP SELECT OUTPUT FOR MEMERE IC
: ADORESS BUS OUTPUTS RXD1
TXI
CTL5
LE
RD
WR
P00 - P07
P19
P19
P12
P13
P14
P15
P17
P20
P21
P23
P24
P25
P26
RAMICS
R

ABO - AB12

CXD8971BR (SONY)

C-MOS GATE ARRAY





1 GRID 62 1 C1CSA 123 D ALO 184 O PLVAR 246 1 ARIES 2 GRID 63 O MUTDA 124 O ALI 186 O WDISSEL 246 O CLITI CLITI 3 WD RD 63 I D2A 125 O ALI 186 O WDISSEL 246 O CLITI 4 WO RD0 65 I D2A 125 O ALI 186 O WDISSEL 246 O CLITI 4 WO RD0 65 I D2A 126 O ALI 186 O PLREF 247 O AND CLITI CL	-	_					_							_	(700 = +5V)
2		100	SIGNAL		No	SIGNAL		1/0	SIGNAL		ю	SIGNAL		ю	BIGNAL
2	1	-	GND	62		C1C2A	123	0	410	184	0	PIVAR	245	-	MRES1
10 RDB	2	-	GND	63	0	MUTGA		6							
4 NO ROP 65 1 DOA 126 0 AL3 197 CHO 546 CHO		W	RDS												
S	4	NO.	RDD		1						_				
S	5	10	RD10												MEMEN
7 NO RO12 69 O 10DT 129 O 76ADS 190 - V00 221 I 1 SPEE 9 NO RO13 69 O 8 SOK 191 O 8 SOK 191 - NO RO12 225 I 1 ROEF 19 NO RO13 69 O 8 SOK 191 O 8 SOK 191 - NO RO 225 I 1 ROEF 19 NO RO15 71 - SAND 122 O RAMCS 180 O 8 SOK 191 I 1 ROEF 11 - GAD 72 I 256F38 133 - GRO 198 O 8 SW70 236 I 1 TCER 11 - GAD 73 O XTALER 139 - GRO 198 O 8 SW70 236 I TEST 12 O ROM LD1 74 I XTALAM 135 I ROEF 13 O ROM LD1 74 I XTALAM 135 I ROEF 14 O ROM LD2 75 - GRO 134 O MGSY 197 O TWRCK 288 O XMA 15 I TESTI 75 - GRO 139 O 62 198 I NOWNA 289 O NOWN 16 I TESTI 75 - GRO 139 O 62 198 I NOWNA 289 O NOWN 16 I TESTI 75 - GRO 139 O 62 198 I NOWNA 289 O NOWN 17 O ROM SOK 79 I XTALAM 140 O LG4 SW70 288 O MGS 19 - GRO 280 O 8 TALER 141 O LG4 SW 20 O MGS 22 O ROPB 80 O XTALER 141 O LG4 SW 20 O MGS 22 O ROPB 80 O XTALER 141 O LG4 SW 20 O MGS 22 O ROPB 80 O XTALER 141 O TOL 20 NO DB13 286 O NOWN 23 O MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 24 I DDTD 86 O XDEW 144 NO TD1 255 NO DB13 286 O NOWN 25 I MGTGO 81 O XDEW 144 NO TD1 255 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 286 O NOWN 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 - GRO 280 NO DB13 280 O TROG 25 I MGTGO 81 I TESTS 142 -		10	RD11	67	1	D7A					=				MEMEN
100 RD19 69 0 BOK 190 0 BSGM 191 SHC 255 1 ROSE								0			=				
10 100 101		1/0		40											
100 RO15 71											_				
11		100	RD15		_						0				
12	11	=	GND	72	1			_						-	
13	12	0			_			=							
14								÷						_	
15					_										
16		_													
17					$\overline{}$										
18											-			_	
19															
20														_	
21 C ADOT ER O REWD 143 IO TOO 594 VO DBF12 285 VOD		-		-	_										
22								_						0	
22 0 MUTIGO 61 0 XCT69 145 140 T02 205 170 D89 2897 — GADO 2898 1 MUTIGO 66 0 XCT6 147 140 T03 209 170 D89 2888 — GADO 2898 1 MUTIGO 66 0 XCT6 147 140 T03 209 170 D89 2888 — GADO 2898 1 MUTIGO 66 0 XCT6 147 140 T03 209 — V60 270 0 TRG88 2898 — T04 140 T03 209 — V60 270 0 TRG88 2898 — T04 140 T03 209 — V60 270 0 TRG88 2898 — T04 1 MUTIGO 2898 1 MUTIGO 2898 — T04 MU										77				-	VDD
1 DOTD 66 0 CPMP 146 100 TO3 207 170 D88 288 - GAD										205	MO	DB11	266	dire	ADD
1											10	DB10	267	_	GNE
1							146	NO		207	NO	DB9	266	-	GND
						XC16	147	NO	TD4	208	NO	DBs	269	0	TRIGAP
Beauty B			REPBO	87	0	SEA	148	NO.	TD5	209	-	VDD	270	0	TAGBIP
28	27	- 1	REDTO	88	_	GND	149	VO	TD6	210	-	GND	271	1	(SPSD4P
29			GND			RCDTA	150	NO	107	271	1/0	D87	272	1.1.	ISPSDOR
1	29	0	PESFD	90	0	RCDTD	151	-	VDD	212	NO	D86	273	0	ISPSDOP
1 SYRED 50	30		ATD2D	91		ARE	152	_	VDD	213	10		274	0	ISPSDOR
12 1 1 1 1 1 1 1 1 1	31	- 8	SBSYD	92		LSWP	153	-	GND	214	VO	D84	275	6	RESDOP
March Marc	32	1	SVRFD	93	-	GND	154	-	GND	215	10	DB3		0	RESDOR
1	33	0	- DPGD	94	_	CLKO	155	1	LCLK	216	8	DB2	277	-	GND
15	34	1	TESTS	95	~	GND	156	-	GND	217	10	DB1	278	0	
1	35		CKRD	96		GND	157	0	GENSY						
37	36	1	C1C2D	97	0	CHRF	158	0	LSHSY		_				
38	37		Von	98	0										
199	38	_	VDQ	99	=	GNO		0							
60	39				0										
1	40	-	GND	101			162								
1		7												Ť	
33 1 DAD 104 1 RFDETA 165 1 SYAB 228 0 ABB 287 0 RAZ 44 1 D7D 105 1 RFDETA 165 1 SYAB 228 0 ABB 287 0 RAZ 44 1 D7D 105 1 RFDETD 165 0 SELPS 227 GMO 288 0 RAS 45 1 ATD1 105 0 GMO 167 0 CLVS 228 0 CMO 288 0 RAS 46 1 SRVS 107 1 DTAD 188 0 WHD 229 0 VOD 280 0 RAS 47 1 DDTA 108 0 DDLT 189 FRAM 230 0 VOD 281 0 CAS 48 1 CSHMA 109 0 EMP 170 FOUT 231 0 ABS 282 0 OE 49 0 GMO 110 0 DEELP 177 0 VOD 223 0 ABS 282 0 OE 50 1 MATGA 111 0 MSVF 172 0 GMO 223 0 ABS 224 0 GMF 51 1 REPBA 112 0 MSSF 173 1 CSVNC 240 0 ABS 226 10 RDC 52 1 REDTA 113 0 WSSF 173 1 CSVNC 240 0 ABS 226 10 RDC 53 0 RISSA 114 0 VDC 175 0 VCOM 280 0 ABS 287 10 RDC 54 1 ATDA 115 GMO 177 0 SYAD 286 0 ABS 289 10 RDC 55 1 SSSVA 16 GMO 177 0 SYAD 286 0 ABS 280 10 RDC 57 0 VDC 118 0 GMO 179 0 SYAD 280 0 ABS 300 10 RDS 57 0 VDC 119 1 DL0 180 1 AESN 241 1 MRO 302 10 RDC 59 0 DPDA 120 1 DL1 180 1 AESN 241 1 MRO 302 10 RDC 50 0 DPDA 120 1 DL1 180 1 AESN 241 1 MRO 302 10 RDC 50 0 DPDA 120 1 DL1 180 1 AESN 241 1 MRO 303 300 3															
1							_							-	
S															
1								_							
1 DOTA 108 0 DOUT 189 FRAM 230 V00 28T 0 CAS					-						=				
1								~			_				
19								-							
1		$\overline{}$													
11 REPBA 112 O MSRF 173 CSYNC 254 O A.B. 256 VO ROD		_									_			0	
1														=	
SS O RFSFA 114 Vb0 176 O VCON 286 O A.83 297 I/O RQ2					-										
54 1 ATD2A 115 — GRO 176 O DATFRM 237 O A32 286 VO R03 55 1 S85VA 116 — GRO 177 O SYAO 238 O A31 289 VO R04 56 1 SYFRA 117 1 VGLK 179 O SYDO 239 O A30 300 VO R05 57 — VOO 118 — GRO 179 — GRO 240 — GRO 301 VO R05 58 — GRO 119 I DLI 180 T AESN 241 I MRO 302 VO R07 59 O DPGA 120 I DLI 181 — GRO 240 — GRO 301 VO R05 59 O DPGA 120 I DLI 181 — GRO 240 — GRO 301 VO R05 59 O DPGA 120 I DLI 181 — GRO 240 — GRO 301 VO R05 59 O DPGA 120 I DLI 181 — GRO 240 — GRO 301 — VO R05 50 O DPGA 120 I DLI 181 — GRO 240 — GRO 301 — VO R05 — VO R															
SS SBSVA 116															
96 1 SYRFA 117 1 VCLK 178 O SYDO 239 O A86 300 VO RDS 57 — VDO 118 — GND 179 — GNO 240 — GND 301 VO RDS 58 — GND 119 I DLO 180 I AESN 241 I MAD 302 VO RDS 59 O DPGA 120 I DLI 181 — GND 242 I MWR 303 — VD					_										
57 — Veo 118 — GNO 179 — GNO 240 — GNO 301 I/O ROS 58 — GNO 119 I DLO 180 I AESN 241 I MRO 302 I/O RO7 59 O DPGA 120 I DL1 181 — GNO 242 I MRO 303 I VO															
58 — GND 119 I DL0 180 I AESIN 241 I MRD 302 VO RD7 59 O DPGA 120 I DL1 181 — GND 242 I MWR 303 — VDO		1			1			0		239	0	AB0	300		RD5
59 O DPGA 120 I DL1 181 - GND 242 I MWR 303 - VD0		_]]		179	= 1	GND	240		GND	301		RD6
			GND	139	1	DLD	180	1	AESIN	241	1	MRD	302	10	RD7
		0	DPGA	120	1	DL1	181	-	GND	242	1	RWM	303	=	Voo
TOOK TOOK O MEDOUT 243 1 BUPEN 304 VDO	60	_	TEST4	121	7	DL2	162	0	AESOUT	243	1	BUFEN	304	-	VDO
61 1 CKRA 122 1 DL3 183 1 WDFS 244 1 BUFRW	61	1						_							

RD8 - RD15	DATA BUS FOR DRAM
	LOAD SIGNAL OUTPUTS FOR DSP PROGRAM DATA
	TEST INPUTS (NORMINALY "L")
	DSP PROGRAM SERIAL DATA OUTPUT
PGMSCK	SHIFT CLOCK OUTPUT FOR PGMSDO
	AD DATA (REC DATA) OUTPUT
	REC/PB SIGNAL OUTPUT (TO RF BOARD)
	: MUTE SIGNAL OUTPUT FOR CXD1008 (TRAILING) ("H": MUTE)
	TRAILING DA DATA (PB/REC MONITOR) INPUT
MNTGD	ERROR MONITOR OUTPUT TO D7 - D0 (WHEN : "H")
	REC/PB SWITCHING SIGNAL INPUT FROM CXD1009 (TRAILING)
	REC DATA INPUT FROM CXD1009 (TRAILING)
	RF SAFE-D OUTPUT
	ATD2-D INPUT
	: SBSY-D INPUT : SVRF-D INPUT
	DELAY EDDP-D OUTPUT
	FS/SYSTEM CLOCK (4.704MHz TYPE)
	C1/C2 DISCRIMINATION SIGNAL INPUT
	DATA BUS FOR CXD1008/1009 (TRAILING)
	OFF TRACK DETECTING SIGNAL INPUT
	FS CLOCK (128KHz TYPE)
	DADT-A INPUT
CHIMA	FS CLOCK (9.408MHz TYPE) IMPUT
MNTGA	: ERROR MONITOR OUTPUT TO D7 - D0 (WHEN : "H")
REPBA	REC/P8 SWITCHING SIGNAL FROM CXD1009 (LEADING)
REDT-A	; REC DATA INPUT FROM CXD1009 (TRAILING)
RFSFA	RF SAFE-A OUTPUT
	ATD2-A INPUT
	SBSY-A INPUT
	SVRF-A INPUT
	DELAY EDOP-A OUTPUT
	FS/SYSTEM CLOCK
	C1/C2 DISCRIMINATION SIGNAL INPUT
	MUTE OUTPUT TO CXD1008 (LEADING) ("H": MUTE)
D2A, D3A, D4A, D7A IDDT	: DATA BUS INPUTS FROM CXD1008/1009 (LEADING) : LEVEL DETECTION SIGNAL OUTPUT
	FS CLOCK (32 • FS) OUTPUT
	; FS CLOCK (FS) INPUT
E-10-1	FS CLOCK (256 • FS) INPUT
	44.1KHz XTAL ENABLE SIGNAL OUTPUT
	44.1KHz •512 CLOCK INPUT
	: 48KHz =512 CLOCK INPUT
	48KHz XTAL ENABLE SIGNAL CUTPUT
RFWD	RF WINDOW OUTPUT
XREW, XC168, CFWD, XC16	RF PLL CONTROL SIGNAL OUTPUTS
SEA	DPG GNE OUTPUT
	: REC DATA OUTPUT FOR LEADING (TO RE BOARD)
RCDTD	: REC DATA OUTPUT FOR TRAILING (TO RF BOARD)
	; ARE INPUT
	; LSWP INPUT
	CHANNEL PLL CLOCK INPUT
	CHANNEL PLL REFERENCE SIGNAL OUTPUT
	CHANNEL PLL COMPARISON SIGNAL OUTPUT
	; ATD-2 OUTPUT (TO RF SOARD)
	; DRUM FG INPUT
	SVCK INPUT
	: EXTERNAL SOURCE INPUT : RF DET-A INPUT
	; RF DET-D INPUT
	; AD DATA INPUT (FROM ADC)
	: DATA OUTPUT
	: PRE-EMPHASIS ON SIGNAL OLITPUT
	DE-EMPHASIS ON SIGNAL OUTPUT
	MASTER PLL REFERENCE SIGNAL OUTPUT
	MASTER PLL COMPARISON SIGNAL OUTPUT
	MASTER PLL CLOCK INPUT
DL0 - DL3	EXTERNAL DATA BUS FOR TO DATA
ALO - AL3	: EXTERNAL ADDRESS BUS FOR TC DATA
	: LTC READER OUTPUT
	TO WAIT INPUT
	EXTERNAL ADDRESS BUS FOR TC DATA
BSGN	: TIME CODE LOAD SIGNAL OUTPUT
	: TIME CODE LATCH SIGNAL OUTPUT
	; CHIP SELECT SIGNAL OUTPUT FOR EXTERNAL RAM ; TIME CODE SYNCHRONISED SIGNAL INPUT
	; TIME CODE SYNCHRONISED SIGNAL INPUT ; RESET SIGNAL OUT PUT OF INTERNAL RECMIK COUNTER
	: MESET SIGNAL OUT PUT OF INTERNAL RECNIK COUNTER ; RESISTOR LATCH SIGNAL OUTPUTS
	; RESISTOR LOAD SIGNAL OUTPUTS
	; TC DATA BUS
	TO GENERATOR CLOCK INPUT
	TO GENERATOR REFERENCE SIGNAL OUTPUT
	TO GENERATOR COMPARISON SIGNAL OUTPUT
	: LTC INPUT
LTCOUT	LTC OUTPUT
	TC GENERATOR INTERRUPT REQUEST INPUT
	: V\$YNC INPUT
	FRAME COMPARISON SIGNAL OUTPUT
	: SAW 600 OUTPUT
	SYAB OUTPUT
	SELPS OUTPUT
	CLVS OUTPUT
	: WIND OUTPUT
	FRAM OUTPUT
	FOUT OUTPUT
	CSYNCOUTPUT
	: FSHL OUTPUT : VCOIN OUTPUT
	DATA FRAME OUTPUT
	; DATA FRAME OUTPUT ; SBSY-A OUTPUT
JI MO	, www95001F01

SYDO : SBSY-D OUTPUT
AESIN : AES/EBU SKINAL INPUT
AESOUT : AES/EBU SKINAL INPUT
WOPS : WORD CLOCK INPUT
PLYAR : DI PLL COMPARISON SIGNAL INPUT
WORSEL : WORD SCHOCK INPUT
PLYAR : DI PLL COMPARISON SIGNAL INPUT
WORSEL : WORD SWINCHING SIGNAL OUTPUT
PLOK : DI PLL CLOCK INPUT
PLOK : DI PLL CLOCK INPUT
EXSYD : EXSY-D OUTPUT
SWPD : SWITCHING PULSE-D OUTPUT
SWPD : SWITCHING PULSE-A OUTPUT
SWPA : EXSY-A OUTPUT
SWPA : SWITCHING PULSE-A OUTPUT
SWPA : SWITCHING PULSE-A OUTPUT
TURICK : THARCK OUTPUT
SWPA : SWITCHING PULSE-A OUTPUT
TOROUK : ON WRITE SIGNAL INPUT
FOR SIGNAL INPUT
DBIS - DBO : DATA BUS
ABIS - ABD : ADDRESS BUS
MRD : MSD INPUT
WWR INPUT
BUFEN : BUFEN INPUT
BUFEN : BUFEN INPUT
SUFEN : BUFEN INPUT
ZRESI : RESET INPUT
ZRESI : RESET INPUT
ZRESI : RESET INPUT FOR MEM BLOCK (RECORDER MEM AREA)
PINEMEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER MEM AREA)
PINEMEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR MEM BLOCK (PLAYER I/O AREA)
PIOEN : OHP SELECT INPUT FOR RECORDER I/O AREA)
PIOEN : OHP SELECT INPUT FOR RECORDER I/O BROCK
PIOEN : OHP SELECT INPUT FOR PLAYER I/O DSP)
PIOEN : OHP SELECT INPUT FOR PLAYER I/O DSP)
PIOEN : OHP SELECT INPUT FOR PLAYER I/O DSP)
PIOEN : OHP SELECT INPUT

• • , • ``





1. MDブロック (MT-PCM-7040-103)

MT-PCM-7040-103は、メカデッキASSY、RF-53基板及びSV-147A基板で構成され、4CHドラム採用の、RAW、RMW機能を実現したDATメカデッキレコーダーモジュールであり、新開発のサーボマイコンにより、標準速記録再生、倍速記録再生が可能である。(注)(注)PCM-7040では、標準速記録再生モードでしか、使っていません。

2. RF-53基板

RF-53基板は、ヘッドで再生した微小信号を増幅しSSP-11基板及び SV-147A基板に送る機能と、SSP-11基板から送られてきたデジタル 信号を電流に変換しヘッドに送る機能を有する標準速、倍速対応 4CH記録再生AMPでありハードウエアーは以下のブロックから構成される。

(1) 記録再生AMP

IC101は先行ヘッド用のRF録再AMP、IC201は後行ヘッド用のRF録 再AMPであり記録時は、SSP-11基板からの記録信号REDT-A、 REDT-Dを電流に変換しヘッドに流す。再生時は、ヘッドからの微 小信号を増幅し、波形等化後リミッターAMPで約870 mVにクラン プレPBDT-A、PBDT-Dとして出力する。

また、ATFサーボ用信号として、再生信号からPILOT信号を抜取り、エンベローブ検波しPILOT-A、PILOT-D信号として出力する。この信号のゲインは、SV-147A基板からのAGC信号により波高値一定となるように自動的に制御される。

さらに、RF液形検出用に再生信号のPCM帯域をエンベロープ検液 し、RFENV-A、RFENV-D信号として出力する。

(2) DAコンバーター

IC301は、12CHの8ビットDAコンパーターで、IC101、IC201のイコライザーAMPの定数、記録電流AMPのゲインを設定する。これらの値は、SV-147A基板からのシリアルデータDIとCLK、LD信号で設定され、イコライザーAMPの定数は標準速、倍速で切り換えられる。

(3) バッファーAMP

PBDT-A、PBDT-DはIC101, IC201から出力後、バッファーAMPを通してSSP-11基板に送られる。

RF-A, RF-Dは, IC101, IC201から出力後, バッファーAMPで6dB 増幅される。この信号は外部には出力されないが, RF観測用に使用する。

3. SV-147A基板

SV-147A基板は1チップCPUを搭載し、メカデッキの制御及びRF-53 基板のDAコンパーターのアナログ出力電圧の設定を行なう機能と、SSP-11基板とシリアル双方向通信により、メカデッキの制御コマンドを受信し、動作結果及びスイッチ情報等のステータスを送信する機能を有する標準速、倍速対応サーボ基板でありハードウエアーは以下のブロックから構成される。

(1) センサーAMP

ドラムFG、PG及びキャプスタンFG出力は、センサーAMP (IC2) で増幅、コンパレートされる。テンションレギュレータのホール 素子出力は、オペAMP (IC16)で増幅される。

テープエンドは、マイコンからのLIGHTON信号により交流駆動された赤外発光LEDの光をエンドセンサーでSEND信号、TEND信号として検出する。結露は、IC1の基準電圧を結露センサーの抵抗とR14で分圧し、湿度による結露センサーの抵抗の変化を電圧値で検出する。以上の検出信号はマイコン(IC9)のポートに入力される。

(2) モータードライバー

ドラムモーターは、DFG、DPG、DREF信号により、速度・位相 サーボがかけられ、駆動用エラー信号はDPWMとしてマイコンか ら出力された後、LPF (IC4)で電圧に変換されドラムモーター内部 の駆動回路へ送られる。

キャプスタンモーターはCFG、PILOT、PBDT信号により、速度・ 位相サーボがかけられ、駆動用エラー信号はCPWMとしてマイコ ンから出力された後、LPF (IC4)で電圧に変換され、モータードラ イバー(IC3)に送られる。IC3は、エラー電圧を3相にスイッチング し直接キャプスタンモーターを駆動する。

リールモーターは、SFG1、TFG1信号により、速度サーボがかけられ、駆動用エラー信号はSPWM、TPWMとしてマイコンから出力された後、そのままリールモーター内部の駆動回路へ送られる。FWD時のバックテンションは、テンションレギュレーターの出力が一定になるようにSPWMで制御される。

ドライブモーターは、モータードライバー(IC15)により駆動される。ドライバーの制御はマイコンがRE1、RE2、RE3、RE4及び UPSWTの位置情報信号により行なう。

(3) リールブレーキ及び保護回路

リールブレーキプランジャーは、モータードライバー (IC11)により駆動される。FF/REW中に電源が瞬断した時にブレーキをかけ、テープの吐き出しを防止するため、IC11の電源はC40、C43で常にチャージされており、瞬断時のIC10からの検出信号DOWN12、RESET信号により強制的にプランジャーを駆動しブレーキをかける。EMGTRG信号は、強制ブレーキが、FF/REW中以外で働かないようにしている。また、プランジャー発熱対策として、マイコンは、電流モニター信号KICKMONを監視し、長時間電流が流れている時、Q14によりIC11の電源を切る。

(4) 不揮発メモリー

不揮発メモリーIC12は、メカデッキが正常に動作するためのサーボデータ及びRFAMP設定データを記憶している。電源投入時これらのデータが、マイコンにより読み出され各種定数設定に使われる

1. Mecha Deck Block (MT-PCM-7040-103)

MT-PCM-7040-103 is made up of the mechanism deck assembly, RF-53 board, and SV-147A board. It is a DAT mechanism deck recorder module with a 4-channel drum and RAW and RMW functions. Using the newly developed servo microprocessor, it is able to carry out standard speed and double speed recording and playback. (Note)

Note: PCM-7040 supports only the standard speed recording and playback.

2. RF-53 Board

The RF-53 board has a function which amplifies minute signals played back by the head and transmits then to the SSP-11 board and SV-147A board, and a function which converts the digital signals transmitted from the SSP-11 board to currents and transmits them to the head. It is a 4-channel recording and playback amplifier that is capable of both standard speed and double speed recording and playback. The hardware is made up of the following blocks.

(1) Recording and playback amplifiers

IC101 is the RF recording/playback amplifier for the leading head and IC201 is the RF recording/playback amplifier for the trailing head. During recording, they convert the recording signals REDT-A and REDT-D from the SSP-11 board to currents and transmits them to the head. During playback, they amplify the minute signals from the head, and after equalizing the waveforms, clamps them at approximatery 870 mV using the limiter amplifier, and outputs them as PBDT-A and PBDT-D.

These amplifiers also extract the pilot signal from the playback signal to use as the ATF servo signal, detect the envelopes, and output them as the PILOT-A and PILOT-D signals. The gain of these signals is automatically controlled by the AGC signal from the SV-147A board so that the peak value of the waves is kept consistent.

They also detect the envelope in the PCM band of the playback signal for detecting the RF waveform and outputs them as the RFENV-A and RFENV-D signals.

(2) DA converters

IC301 is a 12-channel 8-bit DA converter. It sets the constants of the equalizer amplifier and the gain of the recording current amplifier of IC101 and IC201. These values are set by the serial data DI and CLK, and LD signals from the SV-147A board. The constant of the equalizer amplifier is switched when the speed changes from standard to double or vice versa.

(3) Buffer Amplifiers

After being output from IC101 and IC201, PBDT-A and PBDT-D are passed through the buffer amplifier and transmitted to the SSP-11 board.

After being output from IC101 and IC201, RF-A and RF-D are amplified to 6 dB by the buffer amplifier. These signals are not output outside but used for observing RF.

3. SV-147A Board

The SV-147A board incorporates a one chip CPU. It is a servo board which is capable of both standard speed and double speed recording and playback. It has a function which controls the mechanism deck and sets the analog output voltage of the DA converter of the RF-53 board, and a function which through bi-directional serial communication with the SSP-11 board, receives the control commands for the mechanism deck and transmits the status of the operation results and switch information, etc. The hardware is made up of the following blocks.

(1) Sensor Amplifier

The drum FG, drum PG, and capstan FG outputs are amplified and comparated by the sensor amplifier (IC2). The hall element output of the tension regulator is amplified by the operational-amplifier (IC16).

Ξ

For tape end detection, the intrared emitting LED's light AC driven by the LIGHTON signal from the microprocessor is detected by the end sensor as SEND and TEND signals. For condensation, the IC1 reference voltage is voltage divided by the resistor of the condensation sensor and R14, and the changes in the resistance of the condensation sensor due to humidity is detected in voltage. The above signals detected are input to the port of the microprocessor (IC9).

(2) Motor Driver

The drum motor is imposed with the speed and phase servos by the DFG, DPG, and DREF signals. The error signal for driving is output from the microprocessor as DPWM, converted to voltage by the LPF (IC4), and transmitted to the driving circuit inside of the drum motor.

The capstan motor is imposed with the speed and phase servos by the CFG, PILOT, and PBDT signals. The error signal for driving is output from the microprocessor as CPWM, converted to voltage by the LPF (IC4), and transmitted to the motor driver (IC3). IC3 switches the error voltage to three phase and directly drives the capstan motor.

The reel motor is imposed with the speed servo by the SFG1 and TFG1 signals. The error signal for driving is output from the microprocessor as SPWM and TPWM and transmitted as they are to the driving circuit inside the reel motor. During FWD, the back tension is controlled by the SPWM so that the tension regulator output becomes regular.

The drive motor is driven by the motor driver (IC15). The driver is controlled by the microprocessor using the signals carrying information on the positions of RE1, RE2, RE3, RE4, and UPSWT.

(3) Reel Brake and Protection Circuit

The reel brake plunger is driven by the motor driver (IC11). When the power supply is momentarily cut during FF/REW, it imposes the brake. To prevent tape spilling, the power supply of IC11 is constantly charged by C40 and C43. When the power is cut momentarily, it is made to drive the plunger by the detection signal DOWN12 from IC10 and RESET signal to impose the brake. The EMGTRG signal ensures that the forced brake dose not work except during FF and REW. As a countermeasure against plunger heating, the microprocessor observes the current monitor signal KICKMON. If the current has been flowing for quite some time, it cuts the power of IC11 using Q14.


(4) Non-Volatile Memory

The non-volatile memory IC12 stores the servo data for the mechanism deck to operate properly and the RFAMP setting data. When the power is turned on, these data are read by the microprocessor and used for setting various constants.

8-2

8-2

PCM-7040



SONY-SP0529 / Druck 3

SSP-11: AD/DA BLOCK DIAGRAM

ADAブロック

ADAブロックは、2チャンネルのA/D変換部、D/A変換部、パワーユニットおよびタイミングコントロール部で構成されている。A/D変換部では、2チャンネルのアナログ入力信号をデジタル信号に変換してSPブロックに出力(DTAD)する。D/A変換部では、SPブロックより出力されたデジタル信号 (DOUT)をアナログ信号に変換して出力する。

1. A/D変換部

-20/+4 dBsの入力レベル切換回路, LINE IN AMP (IC101/IC210), MUTE (Q101, Q102, Q104/Q201, Q202, Q204), PRE-EMPHASIS (IC102, Q103/IC201, Q203), Buffer Amp (IC102/IC202), ADコンバータ(IC51)で構成されている。

ここでAD変換された16 bitオーディオ信号(DTAD)は、SPブロックに出力される。

電源投入時には、自動的に回路のオフセットをキャンセルするようOFFSET CALIBRATIONが働く。ADコンバータには、DCサーボをかけて温度ドリフトを防いでいる。

また、INPUT ATT (S101/S201)を切り替えることにより、基準入力レベルを-20 dBs、または+4 dBsに設定することができる。

2. D/A変換部

DIGITAL FILTER (IC57)、D/Aコンバータ(IC57)、電流/電圧変換 AMP (IC103/IC203)、L.P.F. (IC104/IC204)、OUTPUT ATT (S102/ S202)、LINE OUT AMP (IC105、IC106、IC107/IC205、IC206、 IC207)、MONITOR OUT AMP (IC60)、HEAD PHONE AMP (IC59)で構成されている。

SPブロックから出力された再生オーディオ信号(DOUT)は、 DIGITAL FILTERで8倍オーバーサンプリングされた後、DAコン バータでアナログ変換される。

これにより、L.P.F.の遮断特性が緩やかとなり、可聴帯域内の直線 位相性を改善している。

また、OUTPUT ATT (S102/S202)を切り替えることにより、基準 出力レベルを-20 dBs、または+4 dBsに設定することができる。

3. タイミングコントロール部

ここでは、SPブロックから送られてくる各クロック信号からADコンパータ、DIGITAL FILTERで使用する最適なタイミングクロックを生成している。

4. パワーユニット部

ここでは、PSブロックから供給される。±15 Vの電源から±5 V電源を作り、ADコンバータとDAコンバータに供給している。

ADA block

The ADA block consists of the 2-channel A/D converter block, D/A converter block, power unit and timing control block. The A/D converter block converts the 2-channel analog input signal to the digital signal, and outputs (DTAD) it to the SP block. The D/A converter block converts the digital signal (DOUT) which is output from the SP block, to the analog signal, and outputs it.

1. The A/D converter block

The A/D converter block consists of the input level selector circuit selecting either -20 or +4 dBs, the LINE-IN amplifier (IC101/IC210), mute circuit (Q101, Q102, Q104/Q201, Q202, Q204), pre-emphasis circuit (IC102, Q103/IC201, Q203), buffer amp (IC102/IC202) and the A/D converter.

The 16-bit audio signal (DTAD) which is converted from analog to digital, is output to the SP block.

When the main power is turned on, the offset calibration functions automatically so as to cancel offset of the circuit. The A/D converter has the DC servo loop which prevents the A/D converter from the temperature drift.

The reference input level can be switched to either -20 dBs or +4 dBs by selecting the input attenuator (S101/S201).

2. The D/A converter block

The D/A converter block consists of the digital filter (IC57), D/A converter (IC57), current-to-voltage conversion amplifier (IC103/IC203), low-pass filter (IC104/IC204), output attenuator (S102/S202), LINE OUT amplifier (IC105, IC106, IC107/IC205, IC206, IC207), moitor out amplifier (IC60) and headphone amplifier (IC59).

The playback audio signal (DOUT) which is output from the SP block is converted to the analog signal using the D/A converter after it is 8-times over-sampled by the digital filter.

The cut-off characteristics of the low-pass filter is dull by this processing so that the linear phase characteristics within the audible range is improved.

The reference output level can be switched to either -20 dBs or +4 dBs by selecting the input attenuator (S102/S202).

Timing control block

The timing control block generates the optimum timing clock from the various clock signals which are supplied from the SP block, to be used in the A/D converter and digital filter.

4. Power unit block


The power unit block generates the \pm 5 V power supply from the \pm 15 V power which is supplied from the PS block. The regulated \pm 5 V power supply is sent to the A/D converter and the D/A converter. interface.

8-4

8-4

PCM-7040

3



PCM-7040

8-5

8-5

SYブロックは、PCM-7040の主制御を行うメインCPU(IC304)とその周辺回路により構成される。

周辺には、ROM(IC307)、RAM(IC309, 310)、EEPROM(IC308)、バッテリーバックアップ回路、リアルタイムクロック(IC314)、テープブランク部検出回路(IC327)、オーディオレベル検出回路(IC315)、9ピンサプCPU(IC318)、ゲートアレイ(IC306)がある。

また、ゲートアレイには次の機能がある。 アドレスデコーダ、割り込みコントローラ(ICU)、タイマーカウンタ (TCU)、パラレルコントローラ(PCU)、キーエンコーダ、2相クロックカウン タ、DAT信号処理にシリアルJ/F、サーボCPU1/F、ディスプレイCPU1/F、 9ピンサブCPU1/F、37/8ピンリモートI/F、RS-232C1/F。

メインCPU (IC304) μPD70216·10(V50)は、16ビット、動作周波数10 MHzのマイクロプロセッサ である。

ROM (IC307)、RAM (IC309, 310) メインCPUのプログラムROMとメモリである。

EEPROM (IC308) アワーメーターデータを記憶する。バッテリーバックアップ回路の不良によって、RAMのアワーメーターデータが失われた場合でも、このICで保持される。

バッテリーバックアップ回路 コンデンサ(C324, 325)とリチウム道池(BT301)を使用して、電源オフ時にメ モリ(RAM)とリアルタイムクロックIC (IC314)のバックアップをする。

リアルタイムクロック(IC314) 32.768 kHzの水晶(X304)を外付けした時計IC。

テープブランク部検出(IC327) テープのブランク(未記録)部を検出する。

オーディオレベル検出(IC315) 入力信号、または再生信号のピークレベルを検出する。

9ビンサブCPU (IC318) 9ビン (RS-422)シリアルデータをパラレルデータに変換し、メインCPUと通信する。

ゲートアレイ(IC306: CXD8970R) アドレスデコーダ V50のアドレス/データパスを分離し、アドレスデータからチップセレクト 侵号を作る。

ICU (Interrupt Control Unit) メインCPUのICUにスレープ接続し、16レベルの割り込み入力をコントロールする。

TCU (Timer Counter Unit) 6x16ビットのカウンタで、タイマ、ボーレートジェネレータ、REF. VIDEO信号検出などに使用される。

PCU (Parallel Control Unit) 3x8ビットのI/Oボートで、EEPROM (IC308) I/F、テープのプランク部検 出回路I/Fに使用される。

キーエンコーダ KY-192基板のキー/スイッチデータを入力して、キーのオン/オフを検出 する。

2相クロックカウンタ サーチダイアル(ロータリーエンコーダ)の2相クロックカウンタ。

DAT信号処理ICシリアルI/F SPブロックの信号処理IC CXD1009 (IC418, 432)とシリアル通信をして、IC のモード設定やサブコード入出力を行う。メインCPUとは、DMA (Direct Memory Access)を使ってデータ入出力を行う。

サーボCPU |/F SV-147A基板のサーボCPU (IC9)インターフェイス用I/Oボート(シリアル)。

ディスプレイCPU I/F KY-192基板のディスプレイCPU (IC6)インターフェイス用I/Oポート(シリアル)。

9ピンCPU I/F 9ピンCPU I/F 9ピンCPU I/テレル) とSCU (Serial Control Unit)。

37/8ピンパラレルリモートI/F 37/8ピンパラレルリモート用I/Oポート。

RS-232C I/F RS-232Cインターフェース用SCU(Serial Control Unit)。 SY Block (System Control Block)

The SY block consists of the main CPU (IC304) which is the main controller of PCM-7040 and its peripheral circuit.

The peripheral circuit comprises ROM (IC307), RAM (IC309, IC310), EEPROM (IC308), battery backup circuit, real time clock (IC314), tape blank segment detector circuit (IC327), audio level detector circuit (IC315), 9-pin sub CPU (IC318) and gate array (IC306).

The gate array has the following functions:
Address decoder, interrupt controller (ICU), timer counter (TCU), parallel controller (PCU), key encoder, two-phase clock counter, DAT signal process IC serial interface, servo CPU interface, display CPU interface, 9-pin sub CPU interface, 37/8-pin remote interface and RS-232C interface.

Main CPU (IC304) The main CPU type $\mu PD70216$ (V50) is a microprocessor with the operating frequency of 10 MHz.

ROM (IC307), RAM (IC309, IC310) They are the program ROM and memory of the main CPU.

EEPROM (IC308)
This IC stores the hours meter data. When the hours meter data in the RAM is deleted due to defective battery backup circuit, the hours meter data is kept stored in this IC.

The battery backup circuit consists of the capacitors (C324, C325) and lithium battery (BT301) which backs up the memory (RAM) and the real time clock IC (IC314) while the main power is turned off.

Real time clock (IC314)
The clock IC to which the 32.768 kHz crystal (X304) is externally connected.

Tape blank segment detector (IC327) The blank (non-recorded) segments of a tape are detected.

Audio level detector (IC315)
Peak level of the input signal or the playback signal is detected.

9-pin sub CPU (IC318) The CPU converted the 9-pin (RS-422) serial data to the parallel data, and communicates with the main CPU.

Gate array (IC306: CXD8970R) Address decoder

The address decoder separates the address bus from the data bus of V50, and generates the chip select signal from the address data.

ICU (Interrupt Control Unit)
The ICU is connected to the ICU of the main CPU as the slave, and controls the interrupt input of 16 different levels.

TCU (Timer Counter Unit) The TCU is the 5×16 bit divider which is used as timer, baud rate generator, and to detect the REF. VIDEO signal.

PCU (Parallel Control Unit)
The PCU is the 3 x 8 bit I/O port which is used for EEPROM (IC308) interface and the tape blank segment detector circuit's interface.

Key encoder
The key encoder receives the key and switch data from the KY-192
board, and detect on and off the respective keys.

2-phase clock counter
This is a two-phase clock counter for the search dial (rotary encoder).

DAT signal process IC serial interface
This interface performs the mode setting of ICs, and inputs and outputs
the sub code using the serial communication with the SP block signal
process IC CXD1009 (IC418, IC432) This interface inputs and outputs
data using the DMA (Direct Memory Access) with the main CPU.

Servo CPU interface
This is the serial I/O port for interfacing with the servo CPU (IC9) on the SV-147A board.

Display CPU interface
This is the serial I/O port for interfacing with the display CPU (IC6) on the KY-192 board.

9-pin CPU interface
This is the parallel I/O port for interfacing with the 9-pin CPU, and the SCU (Serial Control Unit).

37/8-pin parallel remote interface
This is the I/O port for 37/8-pin parallel remote.

RS-232C interface This is the SCU (Serial Control Unit) for the RS-232C SSP-11: SP BLOCK DIAGRAM

SPブロック

SPブロックは、先行の信号処理LSI (IC417,IC418,IC419)、後行の信号処理IC (IC431, IC432, IC433)、MASTER PLL ブロック、CHNNEL PLLブロック、MASTER CLOCKブロックとGA(CXD8971BR SPブロック,IC406)で構成されている。

ここでは、オーディオ信号およびサブコード信号をDATのフォーマットに 従ってエンコードして記録アンプに送る機能と、再生アンプから来た信号を デコードして取り出したオーディオおよびサブコード信号を各ブロックに送 る機能を持つ。

A/DコンバータからGA CXD8971BR (IC406)に入力するオーディオ信号 (DTDA)と、GA (IC406)内のDIOブロックでエンコードされたAES/EBU DIN 信号(DTDD)は、SPブロックのSIGNAL CTL部に入力する。SIGNAL CTL部では、入力したオーディオ信号のうち、一つが選択(DTDAまたはDTDI)されて、16 bit slotから32 bit slotに変換される。変換されたオーディオ信号 (ADDT)は、CXD1008 (IC417, IC431)に送られる。一方、SYブロックから送られてきたサブコードデータは、CXD1009 (IC418, IC432)に入力される。オーディオ信号とサブコード信号は、CXD1008およびCXD1009でインターリーブ、ECCエンコード、810変換された後、記録アンプに送られ、テーブに記録される。(RCDT-A RCDT-D)

再生アンプから送られてくる再生信号(PBDT-A, PBDT-D)は、CXD1009 (IC418/432)に入力する。RF PLLによってデータ抽出クロックが生成され、このクロックによりデータが抽出される。抽出されたデータは、CXD1008およびCXD1009で10-8変換、ECCデコード、デインターリーブが行われ、オーディオデータ、サブコードデータとして出力される。サブコード信号は、SYブロックに送られCPUで処理される。

オーディオ信号は、GA (IC406)に入力し、32 bit slotから16 bit slotに変換される。変換されたオーディオ信号は、ZERO CROSS MUTE 回路を通りAES/EBU DOUT(DIOブロックGA)、メモリ(MEMブロックGA)に送られる。また、同時にDOUT信号としてGA (IC406)から出力され、DAコンバータ(ADAブロック)、メータIC (KY ブロック)に送られる。

DAT用信号処理IC(CXD1008, CXD1009)は、先行ヘッド、後行ヘッド用としてそれぞれに1組ずつ使われている。通常は先行ヘッドで記録し、後行ヘッドで再生(RAW)するが、SUB INSERTモード時は、先行ヘッドで再生を行い、後行ヘッドでサブコードを記録(WAR)する。

PLLブロック

マスタークロックを生成するMASTER PLL (IC408/409)、および記録信号の 基準クロックを生成するCHANNEL PLL(IC412/413/414)がある。分周比 を、CPUよりコントロールすることで、パリスピードを可能にしている。

ZERO CROSS MUTEプロック(CXD8971BR)

再生時のエラーレートが、あらかじめ設定された値より悪くなると、再生 オーディオ信号にゼロクロスミュートをかける。

ERROR CHECKERブロック

再生時にエラーの検出されたブロックの個数を数え、CPU (SYブロック)が エラーレートをモニタできるようにする。 SP Block

The SP block consists of the signal processing LSI (IC417, IC418, IC419) for the advance signal, and the signal processing IC (IC431, IC432, IC433) for the trailing signal, the master PLL block, channel PLL block, master clock block and GA (CXD8971BR, SP block, IC406).

The SP block has the function of encoding the audio signal and the sub code signal in compliance with the DAT format and sending it to the record amplifier, and the function of decoding the signal from the playback amplifier and sending the decoded audio and sub code signals to the respective blocks.

3

The audio signal (DTDA) which is input from the A/D converter to the GA CXD8971BR (IC406), and the AES/EBU DIN signal (DTDI) which is encoded by the DIO block in the GA (IC406), are input to the SIGNAL CTL block. In the SIGNAL CTL block, one signal is selected (DTDA or DTDI) from the input audio signals, and is converted from 16-bit slot to 32-bit slot. The converted audio signal (ADDT) is sent to CXD1008 (IC417, IC431). On the other hand, the sub code data which is supplied from the SY block, is input to CXD1009 (IC418, IC432). The audio signal and the sub code signal receive the interleaving, the ECC encoding and 8-to-10 conversion at CXD1008 and CXD1009, then are sent to the record amplifier to be recorded on tape (RCDT-A, RCDT-D).

The playback signal (PBDT-A, PBDT-D) which is supplied from the playback amplifier, is input to CXD1009 (IC418/IC432). The data extracting clock is generated from the playback signal by the rf PLL. The playback data is extracted using this clock. The extracted playback data receives 10-to-8 conversion, ECC decoding and de-interleaving at CXD1008 and CXD1009 from which the audio data and the sub code data are output. The sub code signal is sent to the SY block where it is processed by the CPU. The audio signal is input to GA where it is converted from 32 bit slot to 16 bit slot. The converted audio signal passes through the zero cross mute circuit and is sent to the AES/EBU DOUT (DIO block GA) and the memory (MEM block GA). A the same time, the converted audio signal is output the GA (IC406) as the DOUT signal, and is sent to the DA converter block (ADA block) and the meter IC (KY block).

The DAT signal processing IC (CXD1008, CXD1009) is used as a pair for the advance head and the trailing head respectively. The advance head records the data while the trailing head plays back (RAW) the data normally. However, in the sub insert mode, the sub code is recorded by the trailing head while it is recorded (WAR) by the advance head.

PLL Block

The PLL block consists of the master PLL (IC408/IC409) generating the master clock and the channel PLL (IC412/IC413/IC414) generating the reference clock of the record signal. Vari-speed is enabled by controlling the dividing ratio of the master clock from the CPU.

Zero Cross Mute Block (CXD8971BR)


When the error rate during playback becomes worse than the pre-set value, zero cross is applied to the playback audio signal.

Error Checker Block


The error checker block counts the numbers of block from which error is detected during playback so that the CPU (SY block) can monitor the error rate.


8-6 PCM-7040

3



PCM-7040





SP BLOCK PCM-7040 B-VPCM7040-8D-SP-S/M

MEMブロック

MEMブロックは、16 MbitのDRAM(IC601)、DSP(IC602、IC603、IC604)とGA (CXD8971BR MEMブロック) (IC406)で構成されている。

テープの再生音をDRAMにリード/ライトしDSPで処理することで、メモリスタート機能、スポットイレース機能、メモリを用いた頭だし機能を持つ。さらに、編集点でプレーヤ音とのクロスフェードを可能にしている。

インスタントメモリ

GA (IC406)内のSPブロックからのテープ再生音(DOUT) は、MEMブロックのRECORDER側ブロック(MEM-Rブロック)でシリアル/パラレル変換され、DRAMの上位8 Mbitに書き込まれる。

DRAMの容量は16 Mbitあり、上位の8 MbitをRECORDER 側(MEM-Rブロック)に、下位8 MbitをPLAYER側ブロック (MEM-Pブロック)に割り当てている。従って、RECORDER、PLAYER側とも記録時間は、サンプリング周波数が48 kHzの時、約5.5秒(MAX.)になる。DRAMとDSPの制御は、メインCPUによってコントロールされているアドレスジェネレータ、DSP I/Fによって行われている。

アドレスジェネレータでは、RAMに対するライトアドレス/リードアドレスを発生させる。また、DSPI/FではDSPに対するプログラムのロード、クロスフェードタイム、レベル等の係数の転送を行っている。

次に、DRAMから読み出されたオーディオ信号は、DSP (IC602)に送られる。ここでは、JOG時の線形補間、レベル調整、ディザ処理、フェードイン/アウト処理を行う。次のDSP(IC604)では、PLAYER側データとのクロスフェード処理、OUTPUT MUTE処理を行う。DSPから出力された信号は、再びGA (IC406)に入り、SPブロックに送られる。送られたオーディオ信号は、DOUT信号としてDIOブロック、ADAブロック、SYブロックに送られ処理されたり、テープに記録されたりする。また、外部入力信号に関しては、SPブロックから送られてきた信号(DPD)がMEM-Pブロックに入力する。入力した信号は、DRAMには記録されずに直接DSP (IC603)に送られ、ここでINPUT TRIMされて、再びSPブロックに送られる。

MEM Block

The MEM block consists of 16 Mbit DRAM (IC601), DSPs (IC602, IC603, IC604) and GA (CXD8971BR, MEM block).

The functions such as the memory start function, spot erase function and cueing function using memory, are made possible by reading/writing the playback sound of tape to/ from the DRAM and by processing with the DSP. Crossfade at the edit point with the player sound is also made possible by the memory block.

Instant Memory

The tape playback sound (DOUT) that is supplied from the SP block of the GA (IC406), is converted from serial to parallel by the recorder side block (MEM-R block) of the MEM block, then written into the upper 8 Mbits of the DRAM.

The DRAM capacity is 16 Mbits. The upper 8 Mbits are assigned to the recorder side block (MEM-R block) side while the lower 8 Mbits are assigned to the player side block (MEM-P block). Therefore, the recording time of both recorder side and the player side is about 5.5 seconds (maximum) when the sampling frequency is 48 kHz. The DRAM and DSP are controlled by the address generator and the DSP interface which are controlled by the main CPU.


The write address and read address for the RAM are generated in the address generator. The DSP interface has the function of transferring the coefficients such as program load, cross fade time and level to the DSP.

The audio signal which is read from the DRAM, is sent to the DSP (IC602) where the linear interpolation during JOG, level adjustment, dithering process and fade-in and fade-out processes are performed.

The next DSP (IC604) has the function of cross-fade process with the player side data and output mute process. The signal which is output from the DSP, is again input to GA (IC406) again then sent to the SP block. This audio signal is sent to the DIO block, ADA block and SY block as the DOUT signal, and is also recorded on tape. Regarding the external input signal, the signal (DPD) that is supplied from the SP block, is input to the MEM-P block. This signal is not recorded into the DRAM, but is sent directly to the DSP (IC603) where the input trim is applied, then sent back to the SP block again.

8-10

3



MEM BLOCK PCM-7040 B-VPCM7040-BD-SSPMEM-SM

SSP-11: TC BLOCK DIAGRAM

TCブロック

TCブロックは、VIDEOのSync Seperator (IC701), Phase Comperator (IC702), VCO (IC704), TC Reader (IC711), RAM (IC715), TC PLL(IC717), TC入出力AMP(IC718)とGA (CXD8971BR TCブロック) (IC406)で構成されている。ここでは、外部から入力されたタイムコードの読み取りと出力タイムコードの発生を可能にしている。また、VIDEO 信号から抽出されたフレーム信号を基準信号として、ワードクロックも生成している。

外部(TC INコネクタ)から入力されたタイムコード信号は、差動AMP (IC718)でTTLレベルに変換され、GA (IC406)に送られる(LTC IN)。ここで通常LTC IN信号は、そのままLTCRDR信号としてGA (IC406)から出力され、TC READER(IC711)に入力される。TC READERで読み込まれた後、RAM (IC715)に書き込まれたタイムコード値(READER TC)と、READER SYNC信号とDATFRM信号の位相差(REC SAMPLE NUMBER)は、データバスを介して、SY BLOCK(CXD8970R)に送られCPU処理される。CPUから送られてきたPB SAMPLE NUMBERとタイムコード値(GENERATOR TC)は、GA (IC406)内で処理される。TC PLL (IC717)で生成されたクロックを基準にして処理されたLTC OUT信号は、バッファ(IC718)を介してCP-268基板に出力される。

また、VIDEO REFコネクタ(CP-269基板)に入力されたビデ オ入力信号(VREF)は、Sync Seperator (IC701)で同期信号成 分(C.Sync)が抽出されGA (IC406)に入力する。さらにGA (IC406)内のFRAM DETECTORで、フレーム成分が抜き取 られてFRAM信号として出力される。 VCO (IC704)は、サンプリング周波数の200逓倍のFOUT信 号を出力し、1/200 DIVIDERで分周されサンプリング周波 数VRFS信号を出力する。VRFS信号は、SPブロックの CLOCK CONTROLに送られる。ここで、VRFS、WDFS. DIFS信号の中から選択された信号がMASTER PLLブロック に送られ、SYSTEM CLOCKが作られる。 FEED BACK COUNTERは、FOUT信号を分周して600 Hzまた は630 HzのFSPLS信号を生成し、PHASE COMPERATORに送 られ、FRAM信号と位相比較される。PHASE COMPERATOR では、位相差に応じたコントロール電圧をVCO (IC704)に送り VRFS信号の200逓倍のFOUTを発振する。

Block Diagram SSP-11: TC SSP-11: TC Block Diagram

TC Block

The TC block consists of the video sync separator (IC701), phase comparator (IC702), VCO (IC704), TC reader (IC711), RAM (IC715), TC PLL (IC717), TC input/output amplifier (IC718) and GA (CXD8971BR, TC block) (IC406).

In the TC block, read-out of the externally input time code and generation of the output time code are performed. The word clock is also generated using the frame signal as the reference signal where the frame signal is extracted from the video signal.

The time code signal which is input externally (through TC IN connector), is converted to the TTL level by the differential amplifier (IC718) and sent (LTC IN) to the GA (IC406) where the normal LTC IN signal is output from the GA (IC406) as the LTCRDR signal and is input to the TC reader (IC711) as it is. After reading in the TC reader, the time code signal is written into the RAM (IC715). The time code value (reader TC) stored in the RAM (IC715) and the phase difference (REC SAMPLE NUMBER) between the reader sync signal and the DATFRM signal are sent to the SY block (CXD8970R) via data bus and processed by the CPU.

The PB SAMPLE NUMBER which is supplied from the CPU and the time code value (generator TC) are processed in the GA (IC406). The LTC OUT signal which is processed using the clock as the reference where the clock is generated by the TC PLL (IC717), is output to the CP-268 board via the buffer (IC718).

The video input signal (VREF) which is input to the VIDEO REF connector (CP-269 board), is extracted of its sync signal component (C. sync) by the sync separator (IC701). The separated sync signal is input to the GA (IC406). Again the video input signal (VREF) is extracted of its frame component by the frame detector in the GA (IC406). The extracted frame signal is output as the FRAM signal.


The VCO (IC704) generates the FOUT signal which is 200 times signal of the sampling frequency. The FOUT signal is divided by the 1/200 divider, and outputs the sampling frequency VRFS signal. The VRFS signal is sent to the clock control of the SP block. In the clock control of the SP block, the signal selected from the VRFS, WDFS and DIFS signals is sent to the master PLL block where the system clock is generated.

The feed back counter divides the FOUT signal to generate the FSPLS signal of either 600 Hz or 630 Hz which is sent to the phase comparator to be compared of its phase with the FRAM signal. The phase comparator generates the control voltage in proportion with the phase difference, and sends the control voltage to the VCO (IC704) where the FOUT (200 × VRFS signal) signal is oscillated.

3

8-12

8-12



DIOブロック

DIOプロックは、RS-422レシーバ/トランシーバ、DIPLL、 ラインレシーバ/トランシーバ, GA (CXD8971BR DIOブ ロック) (IC406)で構成されている。

ワードシンク信号の入出力およびAES/EBU規格のデジタ ルオーディオ入力信号(AES/EBU D-IN)をデコードして、 SPブロックに出力(DTDI)する。そして、SPブロックより 出力されるデジタル信号(DOUT)をエンコードしてデジタ ルオーディオ出力信号(AES/EBU D-OUT)として出力す る。

1. DIGITAL IN部

ここでは、AES/EBU規格のデジタルオーディオ入力信号 をデコードして、L/R 16 bit Slot信号に変換する。また、 チャンネルステータス、ユーザーズビット情報を読む。 AES/EBUデジタルオーディオ入力信号(DI)は、RS-422レ シーバ(IC801)でバランス/アンバランス変換されて、GA (CXD8971BR) (IC406)に入力する。SYNC DETブロックで は、DI信号(バイフェーズ信号)から同期パルスを検出して いる。検出は、DIPLLブロックで生成された同期クロック (PLCK)により行われる。

DECODERブロックでは、オーディオ信号、チャンネルス テータスおよびユーザーズビット情報(サンプリング周波 数,エンファシス)等の信号の復調(NRZ信号)を行う。 オーディオ信号は、L/R 16 bit Slot 信号に変換され、DIDT 信号としてSPブロックに送られる。SPブロックでは、ADA ブロックからの入力信号(DTAD)と同様に、外部入力信号 として処理される。

また、チャンネルステータス、ユーザーズビット情報、Fs UNLOCK情報は、データバスを介して、SYブロック (CXD8970R)に送られCPU処理される。

同期パルス検出で抽出された同期信号(LRCK)は、DIDT信 号との位相補正が行われて、DIFS信号としてSPブロックの CLOCK CONTROLに送られる。そして、

DIFS,WDFS,VRFS信号の中から選択された信号がMASTER PLLブロックに送られ、SYSTEM CLOCKが作られる。

2. DIGITAL OUT部

SPブロックからの出力オーディオ信号(DOUT)は、16/32 bit変換されて、ENCODERプロックに入力する(DADT信 号)。また、データバスを介して送られてきたサンプリング 周波数、エンファシス等の情報は、ENCODERブロック で、チャンネルステータス(C bit)、ユーザーズビット(U bit)にエンコードされる。

DADT信号は、C bit, U bit信号と共に、TRANSMITTERブ ロックでパイフェーズ変調される。(1 WORDは、データエ リア、チャンネルステータス、ユーザーズビット等のデー

タ系列に同期信号を加えて菰成している。) 変調された信号(AES OUT)は、RS-422トランシーバ(IC807) で、バランス/アンバランス変換されて、AES/EBUデジタ ルオーディオ出力信号(DO)として、CP-268基板に出力され

3. Word Sync信号部

CPU-269基板から送られてくるWORD SYNC IN信号は、 GA(CXD8971BR) (IC406) に入力し(WDFS信号)、SPブロッ クのCLOCK CONTROLに送られる。ここで、 WDFS,DIFD,VRFS信号の中から選択された信号がMASTER PLLブロックに送られ、SYSTEM CLOCKが作られる。 WORD SYNC OUT信号は、SYNC (EXT/INT/VIDEO)ス イッチでEXTが選択されている時、WORD SYNC IN信号が そのまま出力され、INTの時には、内部Fs信号がライント ランシーバ(IC806)を介してCP-269基板に出力される。

DIO Block

The DIO block consists of RS-422 receiver/transceiver, DI PLL, line receiver/transceiver and GA(CXD8971BR, DIO block) (IC406).

The input and output word sync signal, and the digital audio input signal (AES/EBU D-IN) of the AES/EBU specifications are decoded and output (DTDI) to the SP block. At the same time, the digital signal (DOUT) which is output from the SP block is encoded and output as the digital audio output signal (AES/EBU D-OUT).

1. DIGITAL IN Block

The digital audio input signal (AES/EBU D-IN) of the AES/EBU specifications is decoded here and converted to the L/R 16-bit slot signal. The channel status and the user's bit information are read here.

The AES/EBU digital audio input signal (DI) is converted from balanced to unbalanced by the RS-422 receiver (IC801), then input to the GA (CXD8971BR) (IC406). In the SYNC DET block, the sync pulse is detected from the DI signal (bi-phase signal). This detection is performed using the sync clock (PLCK).

In the DECODER block, the signal decoding (NRZ signal) of the audio signal, channel status information, user's bit information (sampling frequency, emphasis) and others, is performed.

The audio signal is converted to the L/R 16-bit slot signal and is sent to the SP block as the DIDT signal. In the SP block it is processed as the external input signal in the same way as the input signal (DTAD) coming from the ADA block.

Also, the channel status information, user's bit information and Fs unlock information are sent to the SY block (CXD8970R) through the data bus, where they are processed by CPU.

The sync signal (LRCK) which is extracted by the sync pulse detection, receives the phase correction with respect to the DIDT signal, and is sent to the CLOCK CONTROL of the SP block as the DIFS signal, where the signal selected from the DIFS, WDFS and VRFS signals is sent to the master PLL block where the system clock is generated.

2. DIGITAL OUT Block

The output audio signal (DOUT) which is supplied from the SP block, is converted to 16/32-bits, and input (DADT signal) to the encoder block. The information which is supplied through the data bus, such as sampling frequency,

emphasis and others are encoded to the channel status (C bit) and the user's bit (U bit) in the encoder block. The DADT signal is bi-phase modulated in the transmitter block together with the C bit and U bit signals. (One word is constituted by the chain of data such as data area, channel status and user's bit after the sync signal is added

3


The modulated signal (AES OUT) is converted from balanced to unbalanced signal by the RS-422 transceiver (IC807) and is output to the CP-268 board as the AES/ EBU digital audio output signal (DO).

3. Word Sync Block

The WORD SYNC IN signal which is supplied from the CPU-269 board, is input (WDFS signal) to GA (CXD8971BR) (IC406), then is sent to the clock control of the SP block. In the clock control, the signal selected from the WDFS, DIFD and VRFS signals, is sent to the master PLL block where the system clock is generated. When the SYNC (EXT/INT/VIDEO) switch is set to the EXT, the WORD SYNC IN signal is output to the WORD SYNC OUT signal as it is. When the switch is set to INT, the internal Fs signal is output to the CP-269 board via the line transceiver (IC806).

8-14

8-14



DIO BLOCK PCM-7040 B-VPCM7040-BD-SSPDIO-S/M

電源部(PSブロック)

PSプロックは、PCM-7040で使用するすべての電源を供給 しており、下記回路で構成されている。

アナログ±15 V電源(IC1, IC2) デジタル+5 V (1 A)電源(CP2) デジタル-5 V電源(IC44) デジタル+5 V (3 A)電源(IC5) メカデッキ+12 V (IC3) FL管用FL AC, +31 V MUTEコントロール回路

アナログ±15 V電源(IC1, IC2), デジタル+5 V (1 A) (CP2) は、ADAブロックに供給されて、アナログ±15 VはOP AMPの電源として、デジタル+5 VはADコンパータ (IC51), デジタルフィルタ(IC57)のデジタル系電源として 使われている。

デジタル+5 V (3 A)電源(IC5), デジタル-5 V 電源(IC44) は,SSP-11基板上のロジック回路用の電源として使われて いる。

MUTEコントロール回路は、電源ON/OFF時に、ポップ音 が出ないようにLINE OUT, MONITOR OUT. HEADPHONE OUTの各出力にあるリレーを、コントロール している。


Power Supply Block (PS Block)

The PS block supplies all powers to be used in the PCM-7040, and consists of the following circuitry. Analog ±15 V power supply circuit (IC1, IC2) Digital +5 V (1A) power supply circuit (CP2) Digital -5 V power supply circuit (IC44) Digital +5 V (3A) power supply circuit (IC5) Mechanism deck +12 V (IC3) FL AC +31 V for FL tubes Mute control circuit

The analog ± 15 V power supply (IC1, IC2) and the digital +5 V (1A) power supply (CP2) are supplied to the ADA block where the analog ±15 V is used as the power of the operational amplifiers while the digital +5 V is used as the power of the digital system of the A/D converter (IC51) and the digital filter (IC57).

The digital +5 V (3A) (IC5) and the digital -5 V (IC44) are used as the power of the logic circuit on the SSP-11

The mute control circuit drives the relays inserted in the respective output circuit of the LINE OUT, MONITOR OUT and HEADPHONE OUT amplifiers so that the pop sound must not be output when the main power is turned on and off.



8-16

8-16

KY-192ブロック

KY-192基板は、フロントパネルのKEY、SWのスキャンブ ロックとFL管、LEDの表示ブロックで構成されている。 METER IC (IC4) は16bit デジタルオーディオデータのピー ク値の保持、オーバーレベルの検出を行なっている。CPU (IC6)はROM, RAM, FL DRIVER内臓の8 bit CPUで、SSP-11基板から送られてくるシリアルデータおよびMETER IC (IC4)からのオーディオピークデータからFL管, LEDの表 示を行なう。

1. KEY, SWスキャンブロック

SSP-11基板のIC306(CXD8970R)から送られてくるスキャン ラインデータ(SL0, 1, 2)をデコード(IC1)して、リターンラ インデータ(RLO~5)をSSP-11基板に出力する。KEYスキャ ンはフロントパネルの全KEY, SWについて行なう。また、 DIALのロータリーエンコーダーのパルスデータをSW-420 基板を経由してSSP-11基板に出力する(DIALA, DIALB)。

2. FL管、LED表示ブロック

SSP-11基板から入力された16bitデジタルオーディオデータ (DOUT) は、LRCK、BCK信号と共にIC4 (MSM6338)に入力 される。ここでは、S/P変換、絶対値変換された後、PEAK 値が保持される。また、設定されたオーバーレベル値、 オーバー回数(WORD)に従って、オーバーレベルの検出を 同時に行なう。

IC6 (MSC62408)は、SSP-11基板のIC304:MAIN CPU (µPD70216 (V50))とシリアル通信を行い、METERの表示 モード (ex. PEAK HOLD MODE, HOLD TIME)制御やFL 管、LEDの点灯、点滅、消灯を行う。また、METER IC (IC4)からピークデータを読み、MAIN CPU (V50)から設定 されたパラメーターに従って、これを表示データに変換し て、FL管のMETER部に表示する。

KY-192 Block

The KY-192 board consists of KEY and SELECTOR on the front panel scan block, and FL tube and LED display block. The METER IC (IC4) performs a holding of a peak value of 16 bit serial audio data and a detection of over level. CPU (IC6) is a 8bits CPU with ROM, RAM, and FL DRIVER. It display FL tube and LED according to the serial data from SSP-11 board and the audio peak data from the METER IC (IC4).

1. KEY, SW SCAN block

It decode (IC1) the scan line data (SL0, 1, 2) transmitted from IC306 (CXD8970R) on the SSP-11 board and output the return line data (RL0-5) to the SSP-11 board. The Key scan is performed for all keys and selectors on the front panel. Also it outputs the rotary encoder pulse data of the dial to the SSP-11 board (Dial A, B) via the SW-420 board.

2. FL tube, LED display block

The 16bit digital audio data (DOUT) input from the SSP-11 board will be inserted into IC4 (MSM6338) together with LRCK, BCK signals.

3

In this division, the peak value is held after the S/P conversion and the absolute value conversion. The detection of over level is performed simultaneously according to the over level value and over level sensitivity.

The IC6 (MSC62408) executes serial communication with IC304: MAIN CPU (µPD70216 (V50)) on the SSP-11 board and performs lighting, and flashing of FL tube and LED as well as the METER display mode (ex. PEAK HOLD MODE, HOLD TIME).

It reads the peak data from the METER IC (IC4) and converts it to the segments data according to the parameter specified from the main CPU (V50), and converted data is indicated by METER block of FL tube.

PCM-7040

8-17


8-17

3

Section 9 Board Layouts

Board	Function	Page
SSP-11	System Control, Signal Processor	9-1
KY-192	Display, Key Switch	9-6
CP-268	Connector	
VR-109	REC Volume	9-9
SW-420	Menu Switch	9-9
LED-104	LED Indicator	9-9
HP-48	Headphones	9-9
PS-451	Power Supply (primary side)	9-9
PS-452	Power Supply (secondary side)	9-9
CN-1487	Power Relay (secondary side)	9-9
CP-269	Connector	9-10
RF-53	RF Amplifier	9-10
SV-147A	Servo	9-11
Others		
Capstan	Flexible	9-10
Reel FO	B. Dew Flexible	9-10
Reel FO	9-10	
Recogni	9-10	
Goma	·	9-11
Tenregi	Motor Encoder Flexible	9-11
Tenregi	•••••	9-11

SSP-11 BOARD A (Component) Side



1-663-709-11

9-2

9-2


SSP-11 BOARD 1-663-709-11				
	D308 A1 D309 A1 D310 A1 D311 B2 D312 B2 D313 B2 D314 B1 D315 B1 D316 A1 D317 A1 D318 D1 D401 A4 D402 D5 D405 D6 D405 D6 D406 D6 D407 D6 D408 D6 D409 D6 D409 D6 D401 A3 D602 A3 D602 A3 D603 A3 D604 A3 D605 A3 D606 A3 D606 A3 D606 A3 D607 D808 C1 D803 A2 D804 D2 D807 C1 D808 C1 E1 F2 E2 C1 E3 A2 E4 D2 E55 C5 E6 A5 E11 F6 E12 E6 IC1 H2 IC2 H4 IC51 E5 IC52 E5 IC53 E5 IC54 F5 IC55 F5 IC56 E5 IC57 E5 IC56 E5 IC57 E5 IC58 E4 IC101 F6 IC102 E6 IC101 F6 IC102 E6 IC103 F4 IC105 E4 IC106 F4 IC105 E4 IC106 F4 IC107 F4 IC107 F4 IC201 E6 IC202 E6 IC202 E6 IC203 E4 IC206 E4 IC206 E4 IC207 E4 IC20	IC304 C2 IC305 D2 IC306 C3 IC307 B3 IC308 B2 IC310 B2 IC311 C2 IC312 A2 IC313 A2 IC314 C2 IC315 B2 IC316 D3 IC317 B1 IC319 B1 IC320 E1 IC321 D1 IC322 E1 IC323 E1 IC324 D1 IC325 B2 IC326 D3 IC327 B3 IC327 B3 IC327 B3 IC401 D4 IC402 D4 IC403 D4 IC404 IC405 C4 IC406 B4 IC407 A4 IC408 A4 IC409 A4 IC409 A4 IC411 D5 IC412 D5 IC413 D5 IC414 D5 IC414 D5 IC414 D5 IC417 B5 IC419 B5 IC420 A5 IC421 A5 IC420 A5 IC421 A5 IC422 D6 IC423 D6 IC424 C5 IC425 C6 IC426 C5 IC427 C5 IC426 C5 IC427 C5 IC428 C5 IC429 A5 IC431 B6 IC432 B6 IC433 C6 IC434 A6 IC435 D6 IC424 C5 IC426 C5 IC427 C5 IC426 C5 IC427 C5 IC428 C5 IC429 A5 IC430 A5 IC431 B6 IC432 B6 IC433 C6 IC434 A6 IC435 D6 IC436 D6 IC437 C6 IC436 D6 IC436 D6 IC437 C6 IC436 D6 IC437 C6 IC436 D6 IC436 D6 IC437 C6 IC436 D6 IC436	IC714 F2 IC715 F2 IC716 F2 IC716 F2 IC717 C4 IC718 F2 IC720 F2 IC720 F2 IC801 D1 IC802 A3 IC803 A3 IC803 A3 IC804 A3 IC805 D2 IC806 D2 IC807 C1 IC808 E2 IC809 D1 IS58 E4 IS304 C2 IS307 B3 IV401 D5 IV402 D6 IV403 E6 IV40	TP38 F4 TP39 C5 TP41 D4 TP42 D4 TP43 B4 TP44 B4 TP45 A4 TP46 C5 TP47 C5 TP49 C5 TP50 C5 TP51 C5 TP52 C5 TP52 C5 TP53 D6 TP56 D6 TP56 D6 TP56 D6 TP56 D6 TP61 A5 TP62 A6 TP63 A5 TP71 F2 TP72 F2 TP81 C1 TP82 C1 TP83 A3 TP84 A3 TP85 A3 TP84 B3 TP85 B3 TP81 B3 TP512 B3 TP513 B5 TP514 B3 TP515 B3 TR01 D1 T802 C1 X301 D1 X302 D2 X303 C1 X304 C2 X305 B1 X401 C4 X402 C4 * : B (Soldering) Side mount
D307 A1	IC303 C1	IC713 F2	TP37 C3	

9-4

SSP-11 BOARD 1-663-709-11				
BT301 A2 CN1 G1 CN2 H1 CN3 H1 CN11 G4 CN12 G4 CN51 F1 CN52 F4 CN101 F6 CN102 F6 CN103 F1 CN201 E6 CN203 F1 CN301 D3 CN304 D3 CN305 B1 CN305 B1 CN308 A1 CN308 A1 CN309 B6 CN400 D4 CN402 D4 CN402 D4 CN402 D4 CN403 F4 CN406 B6 CN701 C1 CN702 A1 COP401 D6 COP402 D6 CN701 C1 CN702 A1 COP401 C1 CN402 C4 CN406 B6 CN701 C1 CN702 A1 COP401 C1 CN402 C4 D5 G4 D6 G4 D7 G4 D6 G4 D7 G4 D7 G4 D8 G4 D9 G4 D11 G4 D11 G4 D12 G4 D11 G4 D11 G4 D11 G4 D12 G4 D11 G5 D102 F6 D102 F6 D103 F6 D102 F6 D103 F6 D100 F6 D10	D308 A1 D310 A1 D311 B2 D312 B2 D313 B2 D314 B1 D315 B1 D316 A1 D317 A1 D318 D1 D401 A4 D402 D5 D405 D6 D407 D6 D408 D6 D409 D6 D401 A3 D602 A3 D603 A3 D604 A3 D605 A3 D606 A3 D607 A3 D608 A3 D607 C1 D803 A2 D804 D2 D805 D1 D806 D2 D807 C1 D808 C1 E1 F2 E2 E4 E1	C304 C2 C305 D2 C306 C3 C307 B3 C308 B2 C309 B2 C310 B2 C311 C2 C312 A2 C313 A2 C314 C2 C315 B2 C316 D3 C317 B1 C318 A1 C319 B1 C320 E1 C321 E1 C321 E1 C322 E1 C323 E1 C324 D1 C325 B2 C326 D3 C327 B3 C401 D4 C402 D4 C403 D4 C404 C405 C407 A4 C406 B4 C407 A4 C408 A4 C408 A4 C410 A4 C411 D5 C412 D5 C413 D5 C414 D5 C412 D5 C413 D5 C414 D5 C412 D5 C413 D6 C424 C409 A4 C410 A4 C411 A5 C412 D5 C413 D6 C424 C5 C422 C6 C423 D6 C424 C5 C425 C6 C426 C5 C427 C5 C428 C5 C429 A5 C431 B6 C433 C6 C433 C6 C433 C6 C434 A6 C435 D6 C436 C5 C427 C5 C428 C5 C429 A5 C431 B6 C433 C6 C430 A5 C431 B6 C433 C6 C430 A5 C431 B6 C433 C6 C424 C5 C426 C5 C427 C5 C428 C5 C429 B5 C430 A5 C431 B6 C433 C6 C433 C6 C433 C6 C433 C6 C436 C6 C601 B4 C605 A6 C437 C6 C438 C6 C439 B5 C430 A5 C431 B6 C433 C6 C430 A5 C431 B6 C433 C6 C429 A5 C429 A5 C429 A5 C429 A5 C430 A5 C430 A5 C430 A6 C435 D6 C437 C6 C437 C6 C438 C6 C439 B5 C440 D4 C441 D4 C441 D4 C441 D4 C441 D4 C425 C6 C429 A5 C430 A5 C430 A5 C430 A5 C430 A6 C430 A5 C430	C714 F2 C715 F2 C716 F2 C716 F2 C717 C4 C718 F2 C717 C4 C718 F2 C717 C4 C718 F2 C717 C4 C718 F2 C710 F2 C801 D1 C802 A3 C803 A3 C803 A3 C805 D2 C806 D2 C807 C1 C808 E2 C809 D1 C808 E2 C809 D1 C808 E2 C809 D1 C808 E2 C809 D1 C808 E4 C809 D1 C808 E2 C809 D1 C808 E4 C809 D1 C808 E4 C809 D1 C808 E4 C809 D1 C809	TP38 F4 TP39 C5 TP41 D4 TP42 D4 TP43 B4 TP44 B4 TP45 A4 TP46 C5 TP47 C5 TP48 C5 TP49 C5 TP50 C5 TP51 C5 TP52 C5 TP53 D6 TP54 D6 TP55 D6 TP56 D6 TP61 A5 TP62 A6 TP63 A5 TP71 F2 TP72 F2 TP81 C1 TP83 A3 TP84 A3 TP85 A3 TP84 A3 TP85 B3 TP81 B3 TP512 B3 TP513 B5 TP514 B3 TP515 B3 T801 D1 T802 C1 X301 D1 X302 D2 X303 C1 X304 C2 X305 B1 X401 C4 X402 C4 * : B (Soldering) Side mount

7

SSP-11 BOARD B (Soldering) Side




1-663-709-11

PCM-7040

9-5

9-5


KY-192 BOARD A (Component) Side



1-637-268-13

KY-192 1-637-2										
1-007-2	200-13									
CN1	H6	D25	J2	1C8	* D5	Q29	* E3	S24	J2	
CN2	J 2	D26	J2	IC9	* E3	Q30	* E3	S25		
CN3	J2	D27	J2	IC10	* K6	Q31	* E3		J1	
CN4	A6	D28	A3		110	Q32	* E3	S26	J1	
CN5	A5	D29	G5	Q1	* D1	Q33	* K4	S27	A3	
CN6	G6	D30	F4	Q2	* D1	Q34	* K3	+ · P /O	. Later to the control of	
CN7	H4	D31	F4	Q3	* C2	Q35	* K4	* : B (S	oldering) Side mo	ount
		D32	G4	Q4	* D1	Q36	* H4			
D1	A4	D33	E3	Q5	* D1	Q30	" □4			
D2	B5	D34	D3	Q6	* D1	S1	40			
D3	B 5	D35	D4	Q7	* D1	S2	A3			
D4	A5	D36	E4	Q8	* E1	S3	B3			
D5	A6	D37	E4	Q9	* F1		B5			
D6	G6	D38	K3	Q10	* A4	S4	A6			
D7	B5	D39	K3	Q11	* A5	S5	A5			
D8	C6	D40	K3	Q12	* A5	S6	H5			
D9	B4	D41	G3	Q12	* B4	S7	A5			
D10	C4	D53	J1	Q14	* B5	S8	C5			
D11	D6	D54	J1	Q15	* B5	S9	B3			
D12	H5	D55	J3	Q15	* C6	S10	C3			
D13	F4	D56	J3	Q17	* H4	S11	D5			
D14	G4	D30	33	Q17	* B3	S12	нз			
D15	E5	E1	A3	Q19	* B3	S13	F3			
D16	E6	E2	G4	Q20		S14	F4			
D17	D4	E2	G4		* B3	\$15	E6			
D18	G5	101	+ 10	Q21	* B3	S16	E5			
D19	J2	IC1	* J6	Q22	* B3	\$17	D4			
D20	E6	IC2	* H2	Q23	* C3	S18	G4			
D21	F5	IC3	* J3	Q24	* C3	S19	J2			
D22	G6	IC4	* H1	Q25	* F4	S20	F5			
D23	E3	IC5	* J3	Q26	* F4	S21	F5			
D23		IC6	* G3	Q27	* G4	S22	G5			
U44	J3	IC7	* C5	Q28	* D3	S23	E4			

KY-192 BOARD B (Soldering) Side




1-637-268-13

KY-192 1-637-2									
CN1	H6	D25	J2	IC8	* D5	Q29	* E3	S24	J2
CN2	J2	D26	J2	IC9	* E3	Q30	* E3	S25	J1
CN3	J2	D27	J2	IC10	* K6	Q31	* E3	S26	J1
CN4	A6	D28	A3			Q32	* E3	S27	A3
CN5	A5	D29	G5	Q1	* D1	Q33	* K4	-	
CN6	G6	D30	F4	Q2	* D1	Q34	* K3	* :B (S	oldering) Side mount
CN7	H4	D31	F4	Q3	* C2	Q35	* K4	(g/ 0.00
		D32	G4	Q4	* D1	Q36	* H4		
D1	A4	D33	E3	Q5	* D1				
D2	B5	D34	D3	Q6	* D1	S1	A3		
D3	B5	D35	D4	Q7	* D1	S2	B3		
D4	A5	D36	E4	Q8	* E1	S3	B5		
D5	A6	D37	E4	Q9	* F1	S4	A6		
D6	G6	D38	КЗ	Q10	* A4	S5	A5		
D7	85	D39	КЗ	Q11	* A5	S6	H5		
D8	C6	D40	K3	Q12	* A5	S7	A5		
D9	B4	D41	G3	Q13	* B4	S8	C5		
D10	C4	D53	J1	Q14	* B5	S9	B3		
D11	D6	D54	J1	Q15	* B5	S10	C3		
D12	H5	D55	J3	Q16	* C6	S11	D5		
D13	F4	D56	J3	Q17	* H4	S12	H3		
D14	G4			Q18	* B3	S13	F3		
D15	E5	Ε1	A3	Q19	* B3	S14	F4		
D16	E6	E2	G4	Q20	* B3	S15	E6		
D17	D4			Q21	* B3	S16	E5		
D18	G5	IC1	* J6	Q22	* B3	S17	D4		
D19	J2	IC2	* H2	Q23	* C3	S18	G4		
D20	E6	IC3	* J3	Q24	* C3	S19	J2		
D21	F5	IC4	* H1	Q25	* F4	S20	F5		
D22	G6	IC5	* J3	Q26	* F4	S21	F5		
D23	E3	106	* G3	Q27	* G4	S22	G5		
D24	J3	IC7	* C5	Q28	* D3	S23	E4		


9-7

CP-268 BOARD A (Component) Side



1-663-717-11


CP-268 BOARD **B** (Soldering) Side



1-663-717-11


્ 9-8

VR-109 BOARD A (Component) Side




SW-420 BOARD A (Component) Side

1-637-270-11



PS-451 BOARD A (Component) Side



1-663-710-11


PS-451 BOARD B (Soldering) Side



1-663-710-11

1-637-284-13

LED-104 BOARD A (Component) Side



1-637-269-11

PS-452 BOARD A (Component) Side




1-663-711-11

PS-452 BOARD B (Soldering) Side



1-663-711-11


HP-48 BOARD A (Component) Side



1-637-283-14

PCM-7040

CN-1487 BOARD A (Component) Side




1-664-248-11

9-9


9-9

CP-269 BOARD A (Component) Side

1-663-718-11




CP-269 BOARD B (Soldering) Side




1-663-718-11

RF-53 BOARD A (Component) Side




1-650-046-12

RF-53 BOARD B (Soldering) Side




1-650-046-12


CAPSTAN FLEXIBLE BOARD



REEL FG.DEW FLEXIBLE BOARD



RECOGNI END FLEXIBLE BOARD



1-642-056-12

9-10

9-10

SV-147A BOARD 1-650-045-12 **SV-147A BOARD** A (Component) Side Q1 Q2 Q3 Q4 Q5 Q6 Q7 Q8 Q10 Q11 Q12 Q13 Q14 Q15 Q16 D-6 C-3 A-6 A-6 D-1 D-2 A-6 C-1 C-1 B-1 A-4 B-4 B-4 A-5 A-4 CN1 CN2 CN3 CN4 CN5 CN6 CN7 CN8 CN10 CN11 D-5 D-5 C-6 D-3 D-3 D-2 D-3 D-6 * D-6 C-6 D1 D2 D3 D4 D5 D6 D7 D8 D9 D10 D11 D12 D13 D14 D15 D16 * A-6 * A-6 * A-6 D-2 D-1 A-1 B-1 C-1 B-5 B-5 B-4 B-4 B-4 * B-6 S1 **GOMA BOARD** *: B (Soldering) Side mount 1-650-045-12 1-642-088-11 TENREGI MOTOR ENCODER FLEXIBLE BOARD **SV-147A BOARD** B (Soldering) Side to CN3 -**TENREGI BOARD** to CN10 -1-648-982-11 to ROTARY ENCODER to DRIVE MOTOR 1-650-045-12 1-648-976-12

9-11

9-11

Section 10 Schematic Diagrams

Board	Function	Page
SSP-11	AD Block	10-2
	DA Block	10-3
	PS Block	10-4
	SY Block	10-6
	RM Block	10-8
	SP Block	10-10
	MEM Block	10-12
	TC Block	10-14
	DIO Block	10-16
KY-192	Display, Key Switch	10-18
CP-268A(UC,CE)	Connector	10-20
CP-268B(J)	Connector	10-21
RF-53	RF Amplifier	10-23
SV-147A	Servo	10-24
FRAME WIRING (1/2)	—	10-26
CN-1487	Power Relay (secondary side)	10-26
PS-451	Power Supply (primary side)	10-26
PS-452	Power Supply (secondary side)	10-26
FRAME WIRING (2/2)		10-27
CP-269	Connector	10-27
HP-48	Headphones	10-27
LED-104	LED Indicator	10-27
SW-420	Menu Switch	10-27
VR-109	REC Volume	10.25

PCM-7040 (J) : S/N 10001 and Higher PCM-7040 (UC) : S/N 20001 and Higher PCM-7040 (CE) : S/N 50001 and Higher

1

IC51 AK5339-YP 1C52 (3/7) SN74HC04ANS-E05 R2 28 GAIN Ø RV102 ICS2 (7/7) SN74HC04ANS-E0S 2 1052 (6/7) SN74HC04ANS-E05 D52 155184-TE85L 5y-2 155184-TE85L IC102 (2/2) NE5532P 051 DTA124EKA-T146 P ON RESET 1C54 (2/3) 1C55 (3/3) SN74HC74ANS-E05 SN74HC74ANS-E05 GAIN Ø MORMAL 3 TEST (5V-3 1S\$123-T1 R204 : 0201 25K170-GRBLY-TP 25K170-GRBLY-TP R224 G202 2SK170-GRBLV-TP 1 C 5 4 (3/3) SN 7 4 H C 7 4 A N S - E 0 5 R214 C217 HESS32P 0203 25K170-GRBLY-TP IC54 (1/3) SN74HC74ANS-EDS CH2 AG 1056 t2/2) 15V IC52 (1/7) SN74HC04ANS-EBS C171 C115 C217 C215 C66 L 1C52 (2/7) SN74HC04ANS-E05 151 47:H 256FS 1C52 (4/7) 1C52 (5/7) 5N74HC04ANS-E05 SN74HC04ANS-E05 AD BLOCK SSP-11 (1/9) 5 BOARD NO. 1-663-709-11 054 1SS184-TE85L D53 15\$184-TE85L B-VPCM7040-SSP11-S/M

10-2


D

10-2

F

PCM-7040

SONY-SP0529 / Druck 32



10-3

E

Н

10-3

D

SONY-SP0529 / Druck 33

1

2

3

Ŧ

+5724 +5Y1AG 4/9 --- +5Y2AG 1/9 U1GC44-TE12R 2700
U1GC44-TE12R 2700
U1GC44-TE12R 2700
U1GC44-TE12R 2700 +5V1 AG 1/9 0 0047 250V 1C1 TA7815S DB U1GC44-TE12R 4/9 +127 D22 1SS352-TPH3 1C3 TA7612S U1GC44-TE12R D10 U1GC44-TE12R CN2. CN-1487 1 2 3 4 5 6 7 8 9 9 020 R05 6H-T1B CN6. KY-192 2/9 PS BLOCK SSP-11 (3/9) BOARD NO. 1-663-709-11

5

10-4 10-4 PCM-7040
D | E | F | G | H

B-YPCM7040-SSP11-S/M

SONY-SP0529 / Druck 34

.

PCM-7040 (J) : S/N 10001 and Higher PCM-7040 (UC) : S/N 20001 and Higher PCM-7040 (CE) : S/N 50001 and Higher

1

2/9 TC7S04FU (TEBSR) TP31 DATE O +5V2AG TP32 TEGQ 9999 3/9 2 O 12V 12V 1933 TER P 1934 PCER Q O :39 150R-CD-T 5V 3/9 R307 CLK16 155 PCK CLK10 156 CLK10 1C301 (1/2) 1C301 (2/2) TC7W00FU (TE12R) TC7W00FU (TE12R) CL37 [WT] HEADY INTP: INTP: INTP: INTP: INTP: INTP: FL301 100P 4 38 166 AD1 167 AD2 168 AD3 169 AD4 170 AD5 FC306 (1/2) CXD8970R 3 IC304 #P070216L-10 CXD8970 x303 ≟ P05 243 P06 244 P07 245 0311 10s V50 1C302 (1/2) 1C302 (2/2) TC7W00FU (TE12R) TC7W00FU (TE12R) A012 CL34 SY SV O 5306 O 0.01 108 SYSTEM 249 CLIS CONTROLLER 8302 GL-150Y-CD-7 EFF 8310 0 ASTB 50 IBBA ASTB UBE 51 192 UBE 10RD 61 192 10RD 10RD 62 MRD 195 10RD MRD 62 MRD 195 WER 55 BUFFN 197 BUFFN 57 BUFFN 197 BUFFN 58 TRD 20 10RDAK 10RRAK 197 AD 10RDAK 10RRAK IC325 TC7SOBFU (TE85R) 5V C346 HLDAK REFRO P21 259 259 P23 260 P24 261 P25 262 P26 263 P27 264 RESET 1C303 TL7705CPS-8-E05 C312 DMARGO 205

DMARCO 205

DMARCO 205

DMARCO 207

DMARCO 201

DMARCO R305 VS VCC GES) 1 C308 ST93CS56#1013TR TEST1 200 TEST2 216 TEST3 237 27 5V 8308 10a g 1\$394 9000 5


A | B | C | D | E | G | H

10-6

PCM-7040

10-6

3



PCM-7040

I J K L M N O

PCM-7040 (J) : S/N 10001 and Higher PCM-7040 (UC) : S/N 20001 and Higher PCM-7040 (CE) : S/N 50001 and Higher

4/9 DCD SP BUS IC317 LT1134ACS-E2 SL01 ALGO RLO1 R314 22 RS-232C RLOG RL04 TXD CTS RTS DSR DTR CH302 SL11 SL12 SL11 CH305 (2/3) RL10 RL11 AL12 RL13 RL13 CH205 (3/3) | SWP-A | 23 | SWPA | EXSYA | SWP-D | 25 | SWPD | EXSY-D | 36 | EXSYD | BPA0 BPA1 142 BPA1 143 BPA2 7 RL15 BPA2 144 BPA2 145 BPA4 145 BPA5 146 BPA5 147 BPA6 GMD SBOTA EXCKA DTG1A DTG2A 146 BPA5 147 BPA6 2-لرا 10326 (1/2) TC7W125FU-TE12R 10306 (2/2) CXD8970R SBOTO EXCKD DTC1D DTC2D DTR R338 104 10316 (3/3) TC7W04FU (TE12R) CXD8970 T 5336 + 5337 10326 (2/2) TG7W125FU-TE12R AES1 1-2 _3 5 VSS AVSS FS

BFS

SYAO

SYDO

VSYNC TXD LRCK TP37
VSTNC CL310 SSA 0-TMRCK SV/SCC/FL/KEY/IF/RM SYDO VSYNC # R330 DIALA 1C316 (2/3) 5V C131 TC7W04FU (TE12R) 01 59 RESO REST 1C316 (1/3) TC7W04FU (TE12R) SVINT SYTARDY SYTERDY 5∀ ℃ SVS0 SVS1 5420 5420 ##30° | *** *** SVSCK INTS FLSCK FLTX INT TXD1 5 - 6 - 7 FLSCK FLBUSY FLERR SLOD

10-8

D

C

10-8

F


G

SONY-SP0529 / Druck 38

_


Н


3




RM BLOCK SSP-11 (5/9) BOARD NO. 1-663-709-11 B-IPCM7040-SSP11-SM

10-9 10-9 I J K L M N O F





PCM-7040 (J) : S/N 10001 and Higher PCM-7040 (UC) : S/N 20001 and Higher PCM-7040 (CE) : S/N 50001 and Higher




10-12


10-12

D

SONY-SP0529 / Druck 42

5





DIO BLOCK SSP-11 (9/9) BOARD NO. 1-663-709-11 B-PCM7040-SSP11-SM

3

10-16 10-16 PCM-7040 PCM-7040

SONY-SP0529 / Druck 46

5

1

997 5Z 15811979 53 185119TB \$10 1\$\$11979 \$12 13B12 511 185119TD 33 135³⁸1373 2 \$12 135119TP \$16 15\$11979 \$17 15511910 \$15 1551.1978 514 1\$\$11979 FLTEINT 119 153119TB \$23 15\$11970 822 15511971 3 9 9 FLORES -5

10-18

D

C

10-18

E

SONY-SP0529 / Druck 47

PCM-7040

F

G

н

S6. \$11 - \$23 \$24. 26. 27 S1. 2. 9. 10 \$28 - \$31 25 0 14 ٠. 4. c - 5. d (() 25 0 30 RIO RIT 812 RIS RIG RES RIG RIT 10a 10a 10a 10a 10a 10a 10a 10a **€** DISPLAY, KEY SWITCH **KY-192** BOARD NO. 1-637-268-

10-19


| **K** |

10-19

SONY-SP0529 / Druck 49

PCM-7040

N O



CONNECTOR **CP-268A (UC, CE)**BOARD NO. 1-663-717-11
B-JPCM7040-CP268A-SM

10-20


PCM-7040

E

-

G

Н




CONNECTOR CP-268A (UC, CE)
BOARD NO. 1-663-717-11 B-VPCM7040-CP268A-S/M

10-20 10-20 PCM-7040 D

SONY-SP0529 / Druck 50

PCM-7040 (J) : S/N 10001 and Higher PCM-7040 (UC) : S/N 20001 and Higher PCM-7040 (CE) : S/N 50001 and Higher



CONNECTOR **CP-268B (J)**BOARD NO. 1-663-717-11
B-VPCM7040-CP268B-S/M

Ī

BOARD NO. 1-650-046-12

10-23 10-23

A | B | C | D | E | F | G | H

PBX2 C265 0.33 35Y 1230 1230 1230 1230 R228 151 ≢R239 0202 2SC2223 P ENV OUT 10

E0 OUT 9 7 470s RF-A Q C205 C216 0209 25C2712Y 2238 2238 C209 C213 15 6 3V D 1 C237 220s C211 0 1 F236 C210 0 31 35V C232 15 0.1 6.3V C202 C212 59 33e 509 R202 0201 R206 10 25C2223 R206 R201 R205 224 10e R235 ₹ 9212 151 I C219 ≢8233 5 61 SWP-D SWP-D REPBOR REDT-D IC301 MB883468PFV 6 5 4 3 R301 R302 R303 47t 47t 67t C226 + C227 T 0 0033 C226 + C227 T T 5 3V \$1207 F100H 1 V4 S 2 AO3 3 AO4 4 AO5 5 AO6 6 AO7 7 AO8 8 AO9 9 AO10 V44 REPBOR REDT-D CN401. SSP-11 GND PBDT-A SWP-A REDT-A SWP-A C196 0.33 35V A012 11 11 Vec C301 C122 C125 0 1 C126 0 1 C125 0 1 C125 18 PBX2 AGC PILOT-D 17 16 15 14 R103 R107 R1 28 15t 242322212 0102 25622223 G114 339 50V R138 ≢ AFENV-D R132 0107 PB07-0 6 3r T C139 6.001 13 12 11 10 9 8 7 6 5 C105 C116 C306 4 C307 I 1 C129 C134 T CN8. SV-147A PILOT-A PILOT-A RFENV-A PBDT-A 0109 25CZ712Y C109 C113 15 6 3V G.1 C137 7200 3 ₹ 9136 3.3 R130 C110 0.33 35V C102 C112 59 339 SOV R102 0101 R106 10 25C7223 R106 R101 R105 221 R105 ≢ R:25 0108 25411624 Ic107 To: 125 C125 T T T T 10 pH RF AMPLIFIER 1 C305 C304 15 0 1 6.3V **RF-53** C363 0 1 BOARD NO. 1-650-046-12


10-23 10-23 A | B | C | D | E | G | H

<CAPSTAN-DRIVER> GOMA BOARD 67 4132 8 340 1 REEL FG BOARD PHI-PHA RECOGNI END FLEXIBLE BOARD 10-24 10-24 PCM-7040 D

3

SONY-SP0529 / Druck 54

2




SONY-SP0529 / Druck 55

2

POWER TRANSFORMER PS-452 BOARD No. 1-663-711-11 PS-451 BOARD NO. 1-663-710-11 MECHANISM DECK ASSY RF-53 (M)CAPSTAIN MOTOR M REEL MOTOR (M) REEL FG. DEW SENSOR CONTROL MOTOR M FRAME WIRING (1/2) ROTARY ENCODER CN-1487 BOARD NO. 1-664-284-11 PS-451 BOARD NO. 1-663-710-11 RECOG. SWITCH T. S END SENSOR PS-452 SSP-11 SV-147A BOARD NO. 1-663-710-11 PCM-7040

> 10-26 10-26 D | E | F | G | H

SONY-SP0529 / Druck 56



このマニュアルに記載されている事柄の著作権は当社に あり、説明内容は機器購入者の使用を目的としていま す。

従って、当社の許可なしに無断で複写したり、説明内容 (操作、保守等)と異なる目的で本マニュアルを使用する ことを禁止します。

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

Check the metal trim, "metallized" knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.

LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 3.5 mA. Leakage current can be measured by any one of three methods.

- A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
- A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
- 3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The "limit" indication is 5.25 V, so analog meters must have an accurate lowvoltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 20 V AC range are suitable. (See Fig. A)

